


# RWF II

## ROTARY SCREW COMPRESSOR UNITS

ALL REFRIGERANTS

### MODELS 100 through 1080



**THIS MANUAL CONTAINS RIGGING, ASSEMBLY, START-UP,  
AND MAINTENANCE INSTRUCTIONS. READ THOROUGHLY  
BEFORE BEGINNING INSTALLATION. FAILURE TO FOLLOW THESE  
INSTRUCTIONS COULD RESULT IN DAMAGE OR IMPROPER  
OPERATION OF THE UNIT.**

## Contents

PREFACE.....	3	BALANCE PISTON PRESSURE REGULATOR.....	22
DESIGN LIMITATIONS.....	3	INITIAL START-UP.....	23
JOB INSPECTION.....	3	INITIAL START-UP PROCEDURE.....	23
TRANSIT DAMAGE CLAIMS.....	3	NORMAL START-UP PROCEDURE.....	23
COMPRESSOR and UNIT IDENTIFICATION.....	3		
COMPRESSOR IDENTIFICATION.....	4		
<b>INSTALLATION</b>		<b>MAINTENANCE</b>	
FOUNDATION.....	5	GENERAL INFORMATION.....	24
RIGGING and HANDLING.....	5	NORMAL MAINTENANCE OPERATIONS.....	24
SKID REMOVAL.....	5	GENERAL MAINTENANCE.....	24
CHECKING MOTOR/COMPRESSOR ROTATION.....	6	COMPRESSOR SHUTDOWN and START-UP.....	24
COMPRESSOR/MOTOR COUPLING		GENERAL INSTRUCTIONS FOR REPLACING	
INSTALLATION.....	6	COMPRESSOR UNIT COMPONENTS.....	24
BP SERIES COUPLING DATA TABLE.....	6	OIL FILTER (OF-1) MAIN SINGLE/DUAL.....	25
OIL PUMP COUPLING.....	7	STRAINER - DEMAND OIL PUMP.....	25
HOLDING CHARGE AND STORAGE.....	7	STRAINER - LIQUID INJECTION.....	25
OIL CHARGE.....	7	COALESCER FILTER ELEMENT(S).....	26
OIL HEATER(S).....	7	CHANGING OIL.....	26
OIL FILTER(S).....	7	DEMAND PUMP DISASSEMBLY.....	27
SUCTION ISOLATION VALVE MOUNTING.....	8	DEMAND PUMP ASSEMBLY.....	28
THERMOSYPHON OIL COOLING.....	8	THRUST BEARING ADJUSTMENT.....	29
LIQUID INJECTION OIL COOLING (Optional).....	9	INSTALLATION OF CARBON GRAPHITE BUSHINGS.....	29
LIQUID LINE SIZES/RECEIVER VOLUME.....	9	TROUBLESHOOTING THE DEMAND PUMP.....	29
WATER-COOLED OIL COOLING (OPTIONAL).....	9	PREVENTATIVE MAINTENANCE.....	30
ECONOMIZER - HIGH STAGE (OPTIONAL).....	10	RECOMMENDED MAINTENANCE PROGRAM.....	30
ECONOMIZER LOAD BALANCING.....	11	VIBRATION ANALYSIS.....	30
ELECTRICAL.....	11	OIL QUALITY AND ANALYSIS.....	31
MOTOR STARTER PACKAGE.....	12	MAINTENANCE SCHEDULE.....	31
CURRENT TRANSFORMER (CT) RATIOS.....	13	OIL SAMPLING PROCEDURE.....	32
MINIMUM BURDEN RATINGS.....	13	OPERATING LOG.....	32
CONTROL POWER REGULATOR.....	13	MOTOR BEARINGS.....	32
		GREASE COMPATIBILITY.....	32
		NLGI GREASE COMPATIBILITY CHART.....	32
		TROUBLESHOOTING GUIDE.....	33
		ABNORMAL OPERATION	
		ANALYSIS and CORRECTION.....	33
		SERVICING THE COLD-START VALVE.....	34
		PRESSURE TRANSDUCERS - TESTING.....	35
		PRESSURE TRANSDUCERS - REPLACEMENT.....	35
		VOLUME RATIO CONTROL TRANSMITTER -	
		SLIDE STOP.....	36
		TEMPERATURE SENSOR.....	36
		CAPACITY LINEAR TRANSMITTER - SLIDE VALVE.....	36
		OIL LEVEL TRANSMITTER.....	37
		TROUBLESHOOTING THE RWF II COMPRESSOR.....	38
		THE OIL SEPARATION SYSTEM.....	38
		THE HYDRAULIC SYSTEM.....	39
		THE DEMAND PUMP SYSTEM.....	40
		MOTOR and BARE COMPRESSOR REPLACEMENT.....	40
		SHUTDOWN DUE TO IMPROPER OIL PRESSURE.....	40
		COMPRESSOR PORT LOCATIONS.....	41
		P & I DIAGRAM.....	49
		PROPER INSTALLATION OF ELECTRONIC EQUIPMENT	
		IN AN INDUSTRIAL ENVIRONMENT.....	52
		FORMS.....	57
<b>OPERATION</b>			
OPERATION and START-UP INSTRUCTIONS.....	14		
SGC COMPRESSOR.....	14		
COMPRESSOR LUBRICATION SYSTEM.....	14		
NO PUMP OIL SYSTEM.....	14		
DEMAND PUMP OIL SYSTEM.....	15		
COMPRESSOR OIL SEPARATION SYSTEM.....	15		
COLD-START SYSTEM.....	15		
COMPRESSOR HYDRAULIC SYSTEM.....	16		
VOLUME RATIO CONTROL.....	16		
COMPRESSOR OIL COOLING SYSTEMS.....	16		
SINGLE-PORT LIQUID INJECTION.....	17		
DUAL-PORT LIQUID INJECTION.....	17		
QUANTUM™LX EZ-COOL™ LIQUID INJECTION			
ADJUSTMENT PROCEDURE.....	18		
OPERATION OF DANFOSS			
LIQUID INJECTION VALVE.....	19		
SUCTION CHECK VALVE BYPASS.....	22		
LOW AMBIENT OPERATION.....	22		
SUCTION CHECK VALVE			
POWER ASSIST KIT.....	22		

**PREFACE**

This manual has been prepared to acquaint the owner and serviceman with the INSTALLATION, OPERATION, and MAINTENANCE procedures as recommended by Johnson Controls for Frick® RWF II Rotary Screw Compressor Units.

For information about the functions of the *Quantum™LX* control panels, communications, specifications, and wiring diagrams, see publication series O90-020 O, M, CS, and E90-020 SPC.

It is most important that these units be properly applied to an adequately controlled refrigeration system. Your authorized Frick® representative should be consulted for their expert guidance in this determination.

Proper performance and continued satisfaction with these units is dependent upon:

- CORRECT INSTALLATION**
- PROPER OPERATION**
- REGULAR, SYSTEMATIC MAINTENANCE**

To ensure correct installation and application, the equipment must be properly selected and connected to a properly designed and installed system. The Engineering plans, piping layouts, etc. must be detailed in accordance with the best practices and local codes, such as those outlined in ASHRAE literature.

A refrigeration compressor is a VAPOR PUMP. To be certain that it is not being subjected to liquid refrigerant carryover it is necessary that refrigerant controls are carefully selected and in good operating condition; the piping is properly sized and traps, if necessary, are correctly arranged; the suction line has an accumulator or slugging protection; that load surges are known and provisions made for control; operating cycles and defrosting periods are reasonable; and that high side condensers are sized within system and compressor design limits.

It is recommended that the entering vapor temperature to the compressor be superheated to 10°F above the refrigerant saturation temperature. This assures that all refrigerant at the compressor suction is in the vapor state.

**DESIGN LIMITATIONS**

The compressor units are designed for operation within the pressure and temperature limits as shown in Frick® Pub. E70-610 SED.

**JOB INSPECTION**

Immediately upon delivery examine all crates, boxes and exposed compressor and component surfaces for damage. Unpack all items and check against shipping lists for any discrepancy. Examine all items for damage in transit.

**TRANSIT DAMAGE CLAIMS**


All claims must be made by consignee. This is an ICC requirement. Request immediate inspection by the agent of the carrier and be sure the proper claim forms are executed.

Report damage or shortage claims immediately to Johnson Controls Inc., Frick® Sales Administration Department, in Waynesboro, PA.

**COMPRESSOR and UNIT IDENTIFICATION**

Each compressor unit has 2 identification data plates. The **compressor data plate** containing compressor model and serial number is mounted on the compressor body. The **unit data plate** containing unit model, serial number and Frick® sales order number is mounted on the side of the Quantum™LX control panel.

**NOTE: When inquiring about the compressor or unit, or ordering repair parts, provide the MODEL, SERIAL, and FRICK® SALES ORDER NUMBERS from these data plates.**



BY JOHNSON CONTROLS

**ROTARY SCREW COMPRESSOR UNIT**

SALES ORDER NUMBER:	<input style="width: 95%;" type="text"/>
MODEL NO:	<input style="width: 95%;" type="text"/>
SERIAL NO:	<input style="width: 95%;" type="text"/>
REFRIGERANT:	<input style="width: 95%;" type="text"/>
MAX DESIGN PRESSURE:	PSIG <input style="width: 80%;" type="text"/>
	kPa <input style="width: 80%;" type="text"/>

100 CV AVENUE, WAYNESBORO, PA. 17268  
PHONE: 717-762-2121

**UNIT DATA PLATE**

**SAFETY PRECAUTION DEFINITIONS**



Indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.



Indicates a potentially hazardous situation or practice which, if not avoided, will result in death or serious injury.



Indicates a potentially hazardous situation or practice which, if not avoided, will result in damage to equipment and/or minor injury.

**NOTE:**

Indicates an operating procedure, practice, etc., or portion thereof which is essential to highlight.

### COMPRESSOR IDENTIFICATION

Each compressor has an identification data plate (see below), containing compressor model and serial number mounted on the compressor body.

### COMPRESSOR DATA PLATE

Rotary screw compressor serial numbers are defined by the following information:

EXAMPLE: 10240A90000015Z

PLANT	DECADE	MONTH	YEAR	GLOBAL SEQ NO.	ADDITIONAL REMARKS
1024	0	A	9	0000015	Z

Month: A = JAN, B = FEB, C = MAR, D = APR, E = MAY, F = JUN, G = JUL, H = AUG, K = SEP, L = OCT, M = NOV, N = DEC.

Additional Remarks: R = Remanufactured; Z = Deviation from Standard Configuration.

### GEOMETRICAL SWEPT VOLUME TABLE

Compressor Model	Rotor Diameter mm	Rotor L/D	Max Speed RPM	Geometrical Swept Volume Drive Shaft End		CFM 3550 RPM	M <sup>3</sup> /H 2950 RPM
				Ft <sup>3</sup> / Rev	M <sup>3</sup> /Rev		
SGC1913	193	1.35	4,500	0.16653	0.004713	591	834
SGC 1918	193	1.8	4,500	0.22204	0.006284	788	1,112
SGC 2313	233	1.35	4,500	0.29301	0.008292	1,040	1,468
SGC 2317	233	1.7	4,500	0.36897	0.010442	1,310	1,848
SGC 2321	233	2.1	4,500	0.45580	0.012899	1,618	2,283
SGC 2813	283	1.35	4,200	0.52501	0.014858	1,864	2,630
SGC 2817	283	1.7	4,200	0.66115	0.018711	2,347	3,312
SGC 2821	283	2.1	4,200	0.79546	0.022512	2,824	3,985
SGC 2824	283	2.4	4,200	0.89858	0.025430	3,190	4,501
SGCH/B 3511	355	1.1	4,200	0.82248	0.023276	2,920	4,120
SGCH/B 3515	355	1.5	4,200	1.12154	0.031739	3,981	5,618
SGCH/B 3519	355	1.9	4,200	1.42748	0.040398	5,068	7,150
SGCB 3524	355	2.4	4,200	1.80328	0.051033	6,402	9,033

# Installation

## FOUNDATION

If RWF II Rotary Screw Compressor Unit is shipped mounted on a wood skid, it must be removed prior to unit installation.

**⚠️ WARNING** Allow space for servicing the unit per factory drawings.

The first requirement of the compressor foundation is that it must be able to support the weight of the compressor package including coolers, oil, and refrigerant charge. Screw compressors are capable of converting large quantities of shaft power into gas compression in a relatively small space and a mass is required to effectively dampen these relatively high-frequency vibrations.

Firmly anchoring the compressor package to a suitable foundation by proper application of grout and elimination of piping stress imposed on the compressor is the best insurance for a trouble-free installation. Use only the certified general arrangement drawings from Frick to determine the mounting foot locations and to allow for recommended clearances around the unit for ease of operation and servicing. Foundations must be in compliance with local building codes and materials should be of industrial quality.

The floor must be a minimum of 6 inches of reinforced concrete and housekeeping pads are recommended. Anchor bolts are required to firmly tie the unit to the floor. Once the unit is rigged into place (See RIGGING and HANDLING), the feet must then be shimmed in order to level the unit. The shims should be placed to position the feet roughly one inch above the housekeeping pad to allow room for grouting. An expansion-type epoxy grout must be worked under all areas of the base with no voids and be allowed to settle with a slight outward slope so oil and water can run off of the base.

When installing on a steel base, the following guidelines should be implemented to properly design the system base:

1. Use I-beams in the skid where the screw compressor will be attached to the system base. They should run parallel to the package feet and support the feet for their full length.
2. The compressor unit feet should be continuously welded to the system base at all points of contact.
3. The compressor unit should not be mounted on vibration isolators in order to hold down package vibration levels.
4. The customer's foundation for the system base should fully support the system base under all areas, but most certainly under the I-beams that support the compressor package.

When installing on the upper floors of buildings, extra precautions should be taken to prevent normal package vibration from being transferred to the building structure. It may be necessary to use rubber or spring isolators, or a combination of both, to prevent the transmission of compressor vibration directly to the structure. However, this may increase package vibration levels because the compressor is not in contact with any damping mass. The mounting and support of suction and discharge lines is also very important. Rubber or spring pipe supports may be required to avoid exciting the building structure at any pipe supports close to the compressor package. It is best to employ a vibration expert in the design of a proper mounting arrangement.

In any screw compressor installation, suction and discharge lines should be supported in pipe hangers (preferably within 2 ft. of vertical pipe run) so that the lines won't move if

disconnected from the compressor. See table for Allowable Flange Loads.

NOZ. SIZE NPS	ALLOWABLE FLANGE LOADS					
	MOMENTS (ft.-lbf)			LOAD (lbf)		
	AXIAL	VERT.	LAT.	AXIAL	VERT.	LAT.
	M <sub>R</sub>	M <sub>C</sub>	M <sub>L</sub>	P	V <sub>C</sub>	V <sub>L</sub>
1	25	25	25	50	50	50
1.25	25	25	25	50	50	50
1.5	50	40	40	100	75	75
2	100	70	70	150	125	125
3	250	175	175	225	250	250
4	400	200	200	300	400	400
5	425	400	400	400	450	450
6	1,000	750	750	650	650	650
8	1,500	1,000	1,000	1,500	900	900
10	1,500	1,200	1,200	1,500	1,200	1,200
14	2,000	1,800	1,800	1,700	2,000	2,000

Consult a licensed architect to determine the proper foundation requirements for any large engine or turbine drive.

When applying screw compressors at high pressures, the customer must be prepared for package vibration and noise higher than the values predicted for normal refrigeration duty. Proper foundations and proper installation methods are vital; and even then, sound attenuation or noise curtains may be required to reduce noise to desired levels.

**For more detailed information on Screw Compressor Foundations, please request Frick® publication S70-210 IB.**

## RIGGING and HANDLING

**⚠️ WARNING** This screw compressor package may be top-heavy. Use caution in rigging and handling.

The unit can be moved with rigging, using a crane and spreader bar, by hooking into the four lifting eyes on the oil separator. If a motor is mounted, appropriate adjustment in the lifting point should be made to compensate for motor weight. Adjustment of the lifting point must also be made for any additions to the standard package such as an external oil cooler, etc., because the center of balance will be affected. Refer to supplied engineering drawings to determine the package center of gravity.

The unit can be moved with a forklift by forking **under the skid**, or it can be skidded into place with pinch bars by pushing against the skid. **NEVER MOVE THE UNIT BY PUSHING OR FORKING AGAINST THE SEPARATOR SHELL OR ITS MOUNTING SUPPORTS.**

## SKID REMOVAL

**This screw compressor package may be top-heavy. Use caution to prevent unit from turning over.**

If the unit is rigged into place, the skid can be removed by taking off the nuts and bolts that are fastening the unit mounting supports to the skid before lowering the unit onto the mounting surface.


If the unit is skidded into place, remove the cross members from the skid and remove the nuts anchoring the unit to the skid. Using a 10-ton jack under the separator raise the unit at the compressor end until it clears the two mounting bolts. Spread the skid to clear the unit mounting support, then lower the unit to the surface. Repeat procedure on opposite end.

### CHECKING MOTOR/COMPRESSOR ROTATION

**WARNING** Make sure coupling hubs are tightened to the shaft before rotating the motor to prevent them from flying off and possibly causing serious injury or death.

**WARNING** Injury may occur if loose clothing, etc, becomes entangled on the spinning motor shaft.

**COMPRESSOR ROTATION IS CLOCKWISE WHEN FACING THE END OF THE COMPRESSOR SHAFT.** Under **NO** conditions should the motor rotation be checked with the coupling center installed as damage to the compressor may result. Bump the motor to check for correct compressor rotation. After verification, install disc drive spacer, as applicable.



### COMPRESSOR/MOTOR COUPLING INSTALLATION

The RWF II unit has compressor to motor alignment through the use of a machined cast iron tunnel. This tunnel is factory set through machining tolerances ensuring motor compressor alignment. **No alignment is required in the field.** See Figure 1.

#### BP COUPLING INSTALLATION PROCEDURE




Figure 1 - BP Coupling

1. Install the motor and compressor coupling hubs and keys on their respective shafts. Ensure that they can slide horizontally so that once the disc packs are installed, no axial stress is transferred to the disc packs by a stuck coupling hub. Use no lubricants.
2. Rotate both hubs so that the keys are 180° opposed. With the hubs mounted and the axial spacing set, proceed to

place the spacer between the two hub flanges. Care should be taken when handling the spacer. Be sure the spacer is fully supported at this time. Damage to the unitized flex discs may result after they have been installed if the spacer is not fully supported.

Install the unitized flex disc at this time. Start a bolt through a bolt hole in the spacer. Put the unitized flex disc between the hub and spacer until a bushing hole in the unitized flex disc lines up with the bolt. Slide the bolt through the bushing hole in the unitized flex disc. Install the locknut until it is snug. Make sure that all bolt threads are clean and lightly oiled. Do not torque any locknuts at this time. Now pivot the unitized flex disc until the other bushing holes in the flex disc are in line with the bolt holes in the spacer. Install the rest of the spacer bolts at this time. The remaining bolts for this end of the coupling can be installed through the hub bolt holes and flex disc bushing holes.

Install the unitized flex disc in the other end of the coupling. The unitized flex disc, as installed, should look flat and parallel with the mating hub and spacer flanges.

Torque the disc pack locknuts as recommended in the BP COUPLING DATA TABLE. The bolts should be held in place while the locknuts are torqued.

3. Center the coupling between the shafts. Ensure that the keys are fully engaged in their keyways.
4. Tighten the motor and compressor shaft clamping bolts evenly. Torque to the recommended specification in the BP coupling data table.
5. Torque the keyway setscrews as recommended in the BP COUPLING DATA TABLE.

**IMPORTANT: Only after the shaft clamping bolts are tightened to their final torque can the keyway set screws be tightened. If the keyway set screws are tightened before the shaft clamping bolts are tightened, then the hubs can be cocked on the shaft.**

#### CH COUPLING INSTALLATION PROCEDURE

The T. B. Woods Elastomeric Type CH Coupling is used in most applications. This coupling consists of two drive hubs and a gear-type Hytrel or EDPM and neoprene drive spacer. The split hub is clamped to the shaft by tightening the clamp screws. Torque is transmitted from the motor through the elastomeric gear which floats freely between the hubs. Because of the use of the motor/compressor adapter housing on the RWF II, no field alignment is necessary.

1. Inspect the shaft of the motor and compressor to ensure that no nicks, grease, or foreign matter is present.
2. Inspect the bores in the coupling hubs to make sure that they are free of burrs, dirt, and grit.

BP SERIES COUPLING DATA TABLE									
BP SERIES	DISC PACK LOCKNUT			HUB CLAMPING BOLTS			KEYWAY SETSCREW		
	TORQUE (Lube*)		SIZE UNF	TORQUE		SIZE UNF	TORQUE		SIZE NC
	FT-LB	NM		FT-LB	NM		FT-LB	NM	
BP 43	40	54.2	7/16-20	49	66.4	3/8-24	10	13.6	3/8-16
BP 48	40	54.2	7/16-20	49	66.4	3/8-24	20	27.1	1/2-13
BP 53	60	81.4	1/2-20	78	105.8	7/16-20	20	27.1	1/2-13
BP 58	120	162.7	5/8-18	120	162.7	1/2-20	20	27.1	1/2-13
BPU-38*	22	30	5/16-24	N/A	N/A	N/A	22	30	3/8-16
BPU-41*	55	75	7/16-20	N/A	N/A	N/A	22	30	3/8-16
BPU-47*	120	162.7	9/16-18	N/A	N/A	N/A	50	68	1/2-13
BPU-54*	120	162.7	9/16-18	N/A	N/A	N/A	50	68	1/2-13

**CH COUPLING DATA TABLE**

CH Series	Coupling Hub															
	Between Shaft Spacing				Shaft Engagement				Face Spacing		Clamp Bolt			Keyway		Size UNC
	Min.		Max.		Min.		Max.		In.	mm	Torque (Dry)		Size		Setscrew Torque	
Size	In.	mm	In.	mm	In.	mm	In.	mm	In.	mm	Ft-Lb	Nm		Ft-Lb	Nm	
6	2	50.8	2 $\frac{3}{4}$	69.9	1	25.4	1 $\frac{15}{16}$	49.2	7/8	22.2	15	20.3	1/4-20 UNC	13	17.6	5/16-18
7	2 $\frac{5}{16}$	58.7	3 $\frac{7}{16}$	87.3	1	25.4	2 $\frac{3}{16}$	55.6	1 $\frac{1}{16}$	27.0	30	40.7	5/16-24 UNF	13	17.6	5/16-18
8	2 $\frac{5}{16}$	65.1	4	101.6	1 $\frac{1}{16}$	27.0	2 $\frac{1}{2}$	63.5	1 $\frac{1}{8}$	28.6	55	74.6	3/8-24 UNF	13	17.6	5/16-18
9	3 $\frac{1}{16}$	77.8	4 $\frac{5}{8}$	117.5	1 $\frac{1}{16}$	36.5	3	76.2	1 $\frac{7}{16}$	36.5	55	74.6	3/8-24 UNF	13	17.6	5/16-18
10	3 $\frac{3}{16}$	90.5	5 $\frac{1}{4}$	133.4	1 $\frac{1}{16}$	42.9	3 $\frac{1}{2}$	88.9	1 $\frac{1}{16}$	42.9	130	176.3	1/2-20 UNF	13	17.6	5/16-18
11	4 $\frac{1}{8}$	104.8	5 $\frac{7}{8}$	149.2	1 $\frac{1}{8}$	47.6	4	101.6	1 $\frac{1}{8}$	47.6	130	176.3	1/2-20 UNF	13	17.6	5/16-18

- Check that the keys fit the hubs and shafts properly.
- Slide one hub onto each shaft as far as possible. It may be necessary to use a screwdriver as a wedge in the slot to open the bore before the hubs will slide on the shafts.
- Hold the elastomeric gear between the hubs and slide both hubs onto the gear to fully engage the mating teeth. Center the gear and hub assembly so there is equal engagement on both shafts. Adjust the space between hubs as specified in the CH COUPLING DATA TABLE.
- Torque the clamping bolts in both hubs to the torque value given in the CH COUPLING DATA TABLE. **DO NOT USE ANY LUBRICANT ON THESE BOLTS.**

**OIL PUMP COUPLING**

Compressor units with direct motor/pump coupled pumps need no pump/motor coupling alignment since this is maintained by the close-coupled arrangement.

**HOLDING CHARGE AND STORAGE**

Each RWF II compressor unit is pressure and leak tested at the factory and then thoroughly evacuated and charged with dry nitrogen to ensure the integrity of the unit during shipping and short term storage prior to installation.

**NOTE: Care must be taken when entering the unit to ensure that the nitrogen charge is safely released.**



**Holding-charge shipping gauges on separator and external oil cooler are rated for 30 PSIG and are for checking the shipping charge only. They must be removed before pressure testing the system and before charging the system with refrigerant. Failure to remove these gauges may result in catastrophic failure of the gauge and uncontrolled release of refrigerant resulting in serious injury or death.**

ing the shipping charge only. They must be removed before pressure testing the system and before charging the system with refrigerant. Failure to remove these gauges may result in catastrophic failure of the gauge and uncontrolled release of refrigerant resulting in serious injury or death.

All units must be kept in a clean, dry location to prevent corrosion damage. Reasonable consideration must be given to proper care for the solid-state components of the microprocessor. Please contact Frick® service for long term storage requirements.

**COMPRESSOR UNIT OIL**



**DO NOT MIX OILS of different brands, manufacturers, or types. Mixing of oils may cause excessive**

oil foaming, nuisance oil level cutouts, oil pressure loss, gas or oil leakage and catastrophic compressor failure.

**NOTE: The Frick oil charge shipped with the unit is the best suited lubricant for the conditions specified at the time of purchase. If there is any doubt due to the refrig-**

**erant, operating pressures, or temperatures, refer to Frick Oil publication 160-802 SPC.**

**OIL CHARGE**

**The normal charging level is midway in the top sight glass located midway along the oil separator shell. Normal operating level is midway between the top sight glass and bottom sight glass. The table gives the approximate oil charge quantity.**

Add oil by attaching the end of a suitable pressure type hose to the oil drain valve, located under the oil separator. Using a pressure-type pump and the recommended Frick® oil, open the drain valve and pump oil into the separator. **NOTE: Evacuation of the oil separator will assist the flow of oil into the unit. Also, fill slowly because oil will fill up in the separator faster than it shows in the sight glass.**

Oil distillers and similar equipment which act to trap oil must be filled prior to unit operation to normal design outlet levels. The same pump used to charge the unit may be used for filling these auxiliary oil reservoirs.

**NOTE: The sight glass located in the coalescing end of the separator near the discharge connection should remain empty.**

**OIL HEATER(S)**

Standard units are equipped with one to three 1000 watt oil heaters, providing sufficient heat to maintain the oil temperature for most indoor applications during shutdown cycles to permit safe start-up. Should additional heating capacity be required because of low ambient temperature, contact Johnson Controls-Frick®. The heaters are energized only when the unit is not in operation.



**DO NOT ENERGIZE THE HEATERS when there is no oil in the unit, the heaters will burn out. The oil heaters will be energized whenever 120 volt control power is applied to the unit and the compressor is not running, unless the 16 amp circuit breaker in the micro enclosure is turned off.**

**OIL FILTER(S)**



**Use of filter elements other than Frick® may cause warranty claim to be denied.**

RWF II MODEL NO.	BASIC* CHARGE (gal.)
100	45
134	45
177	90
222	90
270	120
316	120
399	120
480	130
496	190
546	130
676	220
856	220
1080	220

\*Includes total in horizontal oil separator and piping. Add 5 gal. for oil cooler up to Model 270, 10 gal. for 316 - 1080.

The oil filter(s) and coalescer element(s) shipped with the unit are best suited to ensure proper filtration and operation of the system.

### SUCTION ISOLATION VALVE MOUNTING

The suction isolation valve is shipped loose from the factory, so it can be installed at various positions within the suction line piping to the compressor. **DO NOT INSTALL** the valve at the compressor suction with flow **against the cone/button** (see Figure 2). When the isolation valve is installed in this position, uneven flow is generated across the suction check valve which is mounted at the inlet to the compressor. This uneven flow causes the disks in the check valve to strike against the stop pin, and eventually damage the internals of the check valve. If the isolation valve is mounted at the compressor suction, **DO INSTALL** with flow **across the cone/button** (see Figure 3). Please design your system piping accordingly.




Figure 2 - INCORRECT Valve Installation




Figure 3 - CORRECT Valve Installation

### THERMOSYPHON OIL COOLING

Thermosyphon oil cooling is an economical, effective method for cooling oil on screw compressor units. Thermosyphon cooling utilizes liquid refrigerant at condenser pressure and temperature that is partially vaporized at the condenser temperature in a plate and shell vessel, cooling the oil to within 35°F of that temperature. The vapor, at condensing pressure, is vented to the condenser inlet and reliquified. This method is the most cost effective of all currently applied cooling systems since no compressor capacity is lost or compressor power penalties incurred. The vapor from the cooler need only be condensed, not compressed. Refrigerant flow to the cooler is automatic, driven by the thermosyphon principle and cooling flow increases as the oil inlet temperature rises.

**EQUIPMENT** - The basic equipment required for a thermosyphon system consists of:

1. A source of liquid refrigerant at condensing pressure and temperature, located in close proximity to the unit to minimize piping pressure drop. The liquid level in the refrigerant source must be 6 to 8 feet minimum above the center of the oil cooler.
2. A plate and shell oil cooler with:
  - Plate Side: Oil 400 psi design
  - Shell Side: Refrigerant 400 psi design

Due to the many variations in refrigeration system design and physical layout, several systems for assuring the above criteria are possible.




Figure 4

**SYSTEM OPERATION** - Liquid refrigerant fills the cooler shell side up to the Thermosyphon receiver liquid level.

Hot oil (above the liquid temperature) flowing through the cooler will cause some of the refrigerant to boil and vaporize. The vapor rises in the return line. The density of the refrigerant liquid/vapor mixture in the return line is considerably less than the density of the liquid in the supply line. This imbalance provides a differential pressure that sustains a flow condition to the oil cooler. This relationship involves:

1. Liquid height above the cooler.
2. Oil heat of rejection.
3. Cooler size and piping pressure drops.

Current thermosyphon systems are using two-pass oil coolers and flow rates based on 3:1 overfeed.

The liquid/vapor returned from the cooler is separated in the receiver. The vapor is vented to the condenser inlet and need only be reliquified since it is still at condenser pressure (Figure 4).

**OIL TEMPERATURE CONTROL** - Oil temperature will generally run about 15 - 35°F above condensing temperature. In many cases, an oil temperature control is not required if condensing temperature is above 65°F as oil temperature can be allowed to float with condenser temperature.


Condensing Temperature: 65°F - 105°F  
Oil Temperature: 80°F - 140°F

**INSTALLATION** - The plate-and-shell type thermosyphon oil cooler with oil-side piping and a thermostatically controlled mixing valve are factory mounted and piped. The customer must supply and install all piping and equipment located

outside of the shaded area on the piping diagram with consideration given to the following:

1. The refrigerant source, thermosyphon or system receiver, should be in close proximity to the unit to minimize piping pressure drop.
2. The liquid level in the refrigerant source must be 6 to 8 feet minimum above the center of the oil cooler.
3. A safety valve should be installed if refrigerant isolation valves are used for the oil cooler.

**NOTE: The component and piping arrangement shown in Figure 5 is intended only to illustrate the operating principles of thermosyphon oil cooling. Other component layouts may be better suited to a specific installation. Refer to publication 070-900E for additional information on Thermosyphon Oil Cooling.**



**Figure 5 - TSOC Piping Arrangement**

1. The thermosyphon oil cooler is supplied with oil side piped to the compressor unit and stub ends supplied on the refrigerant side.
2. A refrigerant-side safety valve is required in this location only when refrigerant isolation valves are installed between the cooler and thermosyphon receiver. If no valves are used between the cooler and TSOC receiver, the safety valve on the TSOC receiver must be sized to handle the volume of both vessels. Then, the safety valve on the cooler vent (liquid refrigerant side) can be eliminated.
3. The system receiver must be below the thermosyphon receiver in this arrangement.

### LIQUID INJECTION OIL COOLING (Optional)


The liquid injection system provided on the unit is self-contained but requires the connection of the liquid line sized as shown in Table 1.

It is **IMPERATIVE** that an uninterrupted supply of high pressure liquid refrigerant be provided to the injection system at all times. Two items of **EXTREME IMPORTANCE** are the design of the receiver/liquid injection supply and the size of the liquid line.

It is recommended that the receiver be oversized sufficiently to retain a 5-minute supply of refrigerant for oil cooling. The evaporator supply must be secondary to this consideration. Two methods of accomplishing this are shown.


The dual dip tube method (Figure 6) uses two dip tubes in the receiver. The liquid injection tube is below the evaporator

ator tube to ensure continued oil cooling when the receiver level is low.



**Figure 6 - Dual Dip Tube**

The level-control method (Figure 7) utilizes a float level control on the receiver to close a solenoid valve feeding the evaporator when the liquid falls below that amount necessary for 5 minutes of liquid injection oil cooling.



**Figure 7 - Level Control**

### LIQUID LINE SIZES/RECEIVER VOLUME

Liquid line sizes and the additional receiver volume (quantity of refrigerant required for 5 minutes of liquid injection oil cooling) are given in TABLE 1.

### WATER-COOLED OIL COOLING (OPTIONAL)

The plate-and-shell type water-cooled oil cooler is mounted on the unit complete with all oil piping. The customer must supply adequate water connections. Determine the size of the water-cooled oil cooler supplied with the unit, as outlined on the Frick P&I diagram and arrangement drawings. **The water supply must be sufficient to meet the required flow.**

A closed-loop system is recommended for the waterside of the oil cooler. Careful attention to water treatment is essential to ensure adequate life of the cooler if cooling tower water is used. **It is imperative that the condition of cooling water and closed-loop fluids be analyzed regularly and as necessary and maintained at a pH of 7.4, but not less than 6.0 for proper heat exchanger life.** After initial start-up of the compressor package, the strainer at the inlet of the oil cooler should be cleaned several times in the first 24 hours of operation.

In some applications, the plate and shell oil cooler may be subjected to severe water conditions, including high temperature and/or hard water conditions. This causes accelerated scaling rates which will penalize the performance of the heat exchanger. A chemical cleaning process will extend the life of the Plate and Shell heat exchanger. It is important to establish regular cleaning schedules.

**Cleaning:** A 3% solution of Phosphoric or Oxalic Acid is recommended. Other cleaning solutions can be obtained from

your local distributor, but they must be suitable for stainless steel. The oil cooler may be cleaned in place by back flushing with recommended solution for approximately 30 minutes. After back flushing, rinse the heat exchanger with fresh water to remove any remaining cleaning solution.

**TABLE 1 - LIQUID LINE SIZE and RECEIVER VOLUME**

**CONDITIONS:** Booster: -40°F Evap, 95°F Cond and 10°F Intermediate; HI Stage: 0°F Evap, and 95°F Cond

REFRIG	RWF II MODEL	PIPING LINE SIZE	POUND PER MIN. PER 5 MIN.	LIQUID VOLUME CU FT
R-717 High Stage*	100-134	1½	81.0	2.2
	177-270	2	132.0	3.6
	316-480	3	236.5	6.4
	496	3	305.0	8.3
	546	3	323.5	8.8
	676	4	417.0	11.4
R-717 Booster*	100-134	¾	11.5	0.3
	177-270	1¼	17.0	0.4
	316-480	1½	31.0	0.8
	496	1½	38.5	0.9
	546	1½	42.5	1.0
	676	2	54.0	1.3
R-507 High Stage*	100-134	1¼	229.0	3.7
	177-270	2	370.5	6.0
	316-480	2	664.0	10.7
	496	2½	878.5	14.1
	546	2½	908.5	14.6
	676	3	1200.0	19.3
R-507 Booster*	100-134	½	28.5	0.5
	177-270	½	38.5	0.6
	316-480	¾	69.0	1.1
	496	1	103.0	1.7
	546	1	94.5	1.5
	676	1¼	141.5	2.3
	856	1¼	160.0	2.6
	1080	2	336.0	5.4

\*Based on 100 foot liquid line. For longer runs, increase line size accordingly.


**ECONOMIZER - HIGH STAGE (OPTIONAL)**

The economizer option provides an increase in system capacity and efficiency by subcooling liquid from the condenser through a heat exchanger or flash tank before it goes to the evaporator. The subcooling is provided by flashing liquid in the economizer cooler to an intermediate pressure level. The intermediate pressure is provided by a port located part way down the compression process on the screw compressor.


As the screw compressor unloads, the economizer port will drop in pressure level, eventually being fully open to suction. Because of this, an output from the microprocessor is generally used to turn off the supply of flashing liquid on a shell and coil or DX economizer when the capacity falls below approximately 60%-70% capacity (85%-90% slide valve position). This is done because the compressor will be more efficient operating at a higher slide valve position with the economizer turned off, than it will at a low slide valve position with the economizer turned on. Please note however that shell and coil and DX economizers can be used at low

compressor capacities in cases where efficiency is not as important as assuring that the liquid supply is subcooled. In such cases, the economizer liquid solenoid can be left open whenever the compressor is running.


Due to the tendency of the port pressure to fall with decreasing compressor capacity, a back-pressure regulator valve (BPR) is generally required on a flash economizer system (Figure 10) in order to maintain some preset pressure difference between the subcooled liquid in the flash vessel and the evaporators.




**Figure 8 - Shell and Coil Economizer System**



**Figure 9 - Direct Expansion Economizer System**



**Figure 10 - Flash Economizer System**



**Figure 11 - Multiple Compressor Economizer System**

If the back-pressure regulator valve is not used on a flash economizer, it is possible that no pressure difference will exist to drive liquid from the flash vessel to the evaporators, since the flash vessel pressure will approach suction pressure at a decreased slide valve position. In cases where wide swings in pressure are anticipated in the flash economizer vessel, it may be necessary to add an outlet pressure regulator to the flash vessel outlet to avoid overpressurizing the economizer port, which could result in motor overload. Example: A system feeding liquid to the flash vessel in batches.

The recommended economizer systems are shown in Figures 8-11. Notice that in all systems there should be a strainer (STR) and a check valve (VCK) between the economizer vessel and the economizer port on the compressor. The strainer prevents dirt from passing into the compressor and the check valve prevents oil from flowing from the compressor unit to the economizer vessel during shutdown.



**Other than the isolation valve needed for strainer cleaning, it is essential that the strainer be the last**

**device in the economizer line before the compressor. Also, piston-type check valves are required for installation in the economizer line, as opposed to disc-type check valves. The latter are more prone to gas-pulsation-induced failure. The isolation and check valves and strainer should be located as closely as possible to the compressor, preferably within a few feet.**

For refrigeration plants employing multiple compressors on a common economizing vessel, regardless of economizer type, each compressor must have a back-pressure regulating valve in order to balance the economizer load, or gas flow, between compressors. The problem of balancing load becomes most important when one or more compressors run at partial load, exposing the economizer port to suction pressure. In the case of a flash vessel, there is no need for the redundancy of a back-pressure regulating valve on the vessel and each of the multiple compressors. Omit the BPR valve on the flash economizer vessel and use one on each compressor, as shown in Figure 11. It is also recommended that the back-pressure regulating valves, used on economizer lines, should be specified with electric shutoff option. The electric shutoff feature is necessary to prevent flow from the common economizer vessel to the suction side of a stopped compressor, through the suction check valve bypass line, if the other compressors and the common economizer vessel are still operating and the HV2 valve on the suction bypass is open.

For refrigeration plants using a Packaged Refrigerant Recirculation Unit and a direct expansion (DX) economizer system it is necessary to operate the liquid feed solenoid on the unit and the liquid feed solenoid on the DX vessel off of a common signal to avoid liquid overfeed on the DX economizer system.

If multiple compressors are operated with a common economizer vessel, it is necessary to install a back-pressure regulator valve with an electric shutoff option in the vapor line piped to the compressor's economizer port.

### ECONOMIZER LOAD BALANCING

The most energy efficient manner to operate an economizer system, when using multiple compressors on a common economizer vessel, is to take as much of the flash gas as possible to the compressors that are fully loaded. This can be done in at least two ways.

1. Use the economizer output from the microprocessor to turn off a solenoid, or to actuate the electric shutoff option on a back-pressure regulator, based on percent of slide valve travel. This will direct all the flash vapor to the other loaded compressors.

2. A dual-setpoint, back-pressure regulator valve can be used in each of the individual economizer vapor lines. When a compressor is running near full load, the BPR valve will operate on the desired setpoint, or basically wide open, to minimize pressure drop in the line. When one compressor unloads below the slide valve position where the economizer output on the microprocessor turns on, the dual-setpoint feature of the regulator can be actuated by this output to control the pressure, on the vessel side of the regulator, to be a few psi higher. Consequently, the flash gas will be sent to the loaded compressors first, until they can't handle all the vapor and the pressure in the vessel starts to rise. Then, some of the vapor will go to the unloaded compressor to help maintain the vessel at the desired pressure. An example of a back-pressure regulator with electric shutoff and the dual-setpoint feature is an R/S A4ADS.

### ELECTRICAL

**NOTE: Before proceeding with electrical installation, read the instructions in the section "Proper Installation of Electronic Equipment in an Industrial Environment".**

RWF II units are supplied with a **Quantum™LX** control system. Care must be taken that the controls are not exposed to physical damage during handling, storage, and installation. The single-box control door must be kept tightly closed to prevent moisture and foreign matter from entry.

**NOTE: All customer connections are made in the single-box control mounted on the oil separator. This is the ONLY electrical enclosure and it should be kept tightly closed whenever work is not being done in it.**

### VOLTAGE PROTECTION

Frick® does not advise nor support the use of UPS power systems in front of the Quantum™LX panel. With a UPS power system providing shutdown protection for the Quantum™LX, the panel may not see the loss of the 3-phase voltage on the motor because the UPS could prevent the motor starter contactor from dropping out. With the starter contactor still energized, the compressor auxiliary will continue to feed an "Okay" signal to the panel. This will allow the motor to be subjected to a fault condition on the 3-phase bus. Some fault scenarios are:

1. The 3-phase bus has power "on" and "off" in a continuous cyclic manner which may cause the motor to overheat due to repeated excessive in-rush currents.
2. Motor cycling may damage the coupling or cause other mechanical damage due to the repeated high torque motor "bumps".
3. Prolonged low voltage may cause the motor to stall and overheat before the motor contactor is manually turned off.

Under normal conditions, the loss of 3-phase power will shut down the Quantum™LX panel and it will restart upon power return. If the panel was in:

- Auto – Compressor motor will return to running as programmed.

- **Remote** – The external controller would reinitialize the panel and proceed to run as required.
- **Manual** – The compressor will have to be restarted manually after the 3-phase bus fault has been cleared.

If the local power distribution system is unstable or prone to problems, there are other recommendations to satisfy these problems. If power spikes or low or high line voltages are the problem, then we recommend the use of a Sola® constant voltage (CV) transformer with a line suppression feature. If a phase loss occurs, then you will typically get a high motor amp shutdown. If problems continue to exist, then an examination of the plant's power factor may be in order.

Unless careful design failure analysis is considered in the implementation of power systems, the alternative solutions provide a safer and less expensive implementation. In either case, only one Sola® may be used per compressor. Each compressor needs to be individually isolated from each other through a dedicated control transformer. Sharing a common control power source is an invitation for ground loops and the subsequent unexplainable problems.

### MOTOR STARTER PACKAGE

Motor starter and interlock wiring requirements are shown in the **Starter Wiring Diagram**. All of the equipment shown is supplied by the installer unless a starter package is purchased separately from Johnson Controls-Frick®. Starter packages should consist of:

1. The compressor motor starter of the specified HP and voltage for the starting method specified (across-the-line, wye-delta, or solid-state).

**NOTE: If starting methods other than across-the-line are desired, a motor/compressor torque analysis must be done to ensure that sufficient starting torque is available, particularly in booster applications. Contact Johnson Controls-Frick® if assistance is required.**

2. If specified, the starter package can be supplied as a combination starter with circuit breaker disconnect. However, the motor overcurrent protection/disconnection device can be applied by others, usually as a part of an electrical power distribution board.

3. The oil pump starter with fuses, or in the case where the compressor motor is a different voltage from the oil pump motor, with a circuit breaker disconnect suitable for separate power feed.

4. A 3.0 KVA control power transformer (CPT) to supply 120 volt control power to the microprocessor control system and separator oil heaters is included. If environmental conditions require more than the usual two 500 watt oil heaters, an appropriately oversized control transformer will be required. If frequent power fluctuations are anticipated or extremely noisy power lines are encountered, a regulating control transformer should be considered. Contact Johnson Controls-Frick® for assistance.

5. For customer-supplied across-the-line starters, a shunting device must be installed across the Current Transformer (terminals 3 & 4).

**WARNING** If the shunting device is not installed, the Analog I/O board on the Quantum™ LX panel may be severely damaged at start-up. See Figure 12.

6. One each normally open compressor motor and oil pump motor starter auxiliary contact should be supplied. In addition to the compressor and oil pump motor starter coils, the CT and CPT secondaries should be wired as shown on the starter package wiring diagram. The load on the control panel for the compressor motor starter coil should not exceed a 2 amp load. For larger starters, an interposing relay must be used to switch the compressor motor starter coil(s).

**NOTE: Do not install a compressor HAND/OFF/AUTO switch in the starter package as this would bypass the compressor safety devices.**

7. The compressor motor Current Transformer (CT) is installed on any one phase of the compressor leads.

**NOTE: The CT must see all the current of any one phase, therefore in wye-delta applications BOTH leads of any one phase must pass through the CT.**





Figure 12 - Starter Wiring Diagram



**Figure 13 - Point-To-Point Wiring Diagram**

**CURRENT TRANSFORMER (CT) RATIOS**

The CT ratio for various motor sizes (with a 5 amp secondary) is given in the following table:

HP	VOLTAGE						
	200	230	380	460	575	2300	4160
20	100:5	100:5	50:5	50:5	50:5	-	-
25	100:5	100:5	50:5	50:5	50:5	-	-
30	200:5	100:5	100:5	50:5	50:5	-	-
40	200:5	200:5	100:5	100:5	50:5	-	-
50	200:5	200:5	100:5	100:5	100:5	-	-
60	300:5	200:5	200:5	100:5	100:5	-	-
75	300:5	300:5	200:5	200:5	100:5	-	-
100	400:5	300:5	200:5	200:5	200:5	-	-
125	500:5	400:5	300:5	200:5	200:5	-	-
150	600:5	500:5	300:5	300:5	200:5	-	-
200	800:5	600:5	400:5	300:5	300:5	100:5	50:5
250	800:5	800:5	500:5	400:5	300:5	100:5	50:5
300	1000:5	1000:5	600:5	500:5	400:5	100:5	50:5
350	-	1000:5	800:5	500:5	500:5	100:5	100:5
400	-	-	800:5	600:5	500:5	200:5	100:5
450	-	-	1000:5	800:5	600:5	200:5	100:5
500	-	-	1000:5	800:5	600:5	200:5	100:5
600	-	-	1200:5	1000:5	800:5	200:5	100:5
700	-	-	-	1200:5	1000:5	200:5	200:5
800	-	-	-	-	1000:5	300:5	200:5
900	-	-	-	-	1200:5	300:5	200:5
1000	-	-	-	-	-	300:5	200:5
1250	-	-	-	-	-	400:5	200:5
1500	-	-	-	-	-	500:5	300:5


**MINIMUM BURDEN RATINGS**

The following table gives the minimum CT burden ratings. This is a function of the distance between the motor starting package and the compressor unit.

BURDEN RATING		MAXIMUM DISTANCE FROM FRICK PANEL		
ANSI	VA	USING # 14 AWG	USING # 12 AWG	USING # 10 AWG
B-0.1	2.5	15 ft	25 ft	40 ft
B-0.2	5	35 ft	55 ft	88 ft
B-0.5	12.5	93 ft	148 ft	236 ft

**CONTROL POWER REGULATOR**

Compressor units that will be used in areas that suffer brown-outs and other significant power fluctuations can be supplied with a control power regulator. See Figure 14, Recommended Regulator Installation.



**Figure 14 - Recommended Regulator Installation**

## Operation

### OPERATION and START-UP INSTRUCTIONS

The Frick® RWF II Rotary Screw Compressor Unit is an integrated system consisting of seven major subsystems:

1. Quantum™LX Control Panel  
(See publications 090-020 O, M, & CS)
2. Compressor
3. Compressor Lubrication System
4. Compressor Oil Separation System
5. Compressor Hydraulic System
6. Compressor Oil Cooling System
7. Compressor Easy-Start System

The information in this section of the manual provides the logical step-by-step instructions to properly start up and operate the RWF II Rotary Screw Compressor Unit.

**THE FOLLOWING SUBSECTIONS MUST BE READ AND UNDERSTOOD BEFORE ATTEMPTING TO START OR OPERATE THE UNIT.**

### SGC COMPRESSOR


The Frick® RWF II rotary screw compressor utilizes mating asymmetrical profile helical rotors to provide a continuous flow of refrigerant vapor and is designed for both high-pressure and low-pressure applications. The compressor incorporates the following features:

1. High-capacity roller bearings to carry radial loads at both the inlet and outlet ends of the compressor.
2. Heavy-duty, four-point angular-contact ball bearings to carry axial loads are mounted at the discharge end of compressor.
3. Balance pistons located in the inlet end of the compressor to reduce axial loads on the axial load bearings and increase bearing life.
4. Movable slide valve to provide fully modulating capacity control from 100% to approximately 10% of full load capacity.
5. Volume ratio control to allow infinitely variable volume ratio from 2.2 to 5.0 during compressor operation for all models.
6. A hydraulic unloader cylinder to operate the slide stop and slide valve.
7. Bearing and casing design for 400 PSI discharge pressure. This PSI rating applies only to the compressor and does not reflect the design pressure of the various system components.
8. All bearing and control oil vented to closed thread in the compressor instead of suction port to avoid performance penalties from superheating suction gas.
9. Shaft seal design to maintain operating pressure on seal well below discharge pressure, for increased seal life.
10. Oil injected into the rotors to maintain good volumetric and adiabatic efficiency even at very high compression ratios.
11. Shaft rotation clockwise facing compressor, suitable for all types of drives. **SEE FOLLOWING WARNING.**



**Compressor rotation is clockwise when facing the compressor drive**

shaft. See Figure 15. The compressor should never be operated in reverse rotation as bearing damage will result.



**Figure 15 - Shaft Rotation Direction**

**12.** Dual compressor casing design for very low airborne noise transmission.

**13.** Suction flange is 300 psig ANSI type.

**14.** Integral suction strainer is provided on models 100 – 480 and 546. Models 496 – 1080 have external strainer.

**15.** "D" Flange adapter for bolting directly to motor.

### COMPRESSOR LUBRICATION SYSTEM

The lubrication system on an RWF II screw compressor unit performs several functions:

1. Provides lubrication to bearings and seal.
2. Provides a cushion between the rotors to minimize noise and vibrations.
3. Helps keep the compressor cool and prevents overheating.
4. Provides an oil supply to hydraulically actuate the slide valve and slide stop.
5. Provides oil pressure to the balance pistons to help increase bearing life.
6. Provides an oil seal between the rotors to prevent rotor contact or gas bypassing.

The compressor unit may be equipped with either a no pump or a demand pump lubrication system. Additionally, either system may contain dual oil filters and liquid injection, water-cooled, or thermosyphon oil cooler for compressor oil cooling.

### NO PUMP OIL SYSTEM

The RWF II screw compressor unit is designed to be self-lubricating. Oil being supplied to the compressor from the oil separator is at system head pressure. Within the compressor, oil porting to all parts of the compressor is vented back to a point in the compressor's body that is at a pressure lower than compressor discharge pressure. The compressor's normal operation makes the compressor unit operate essentially as its own oil pump. All oil entering the compressor is moved by the compressor rotors out the compressor outlet and back to the oil separator.

For normal high-stage operation, an oil pump is not required.

### DEMAND PUMP OIL SYSTEM

This system is designed to provide adequate compressor lubrication when there is low differential oil pressure across the compressor suction and discharge for some high stage applications and booster applications as required.

On start-up, Quantum™LX will calculate the pressure differential between the compressor discharge and the main oil injection port. If this differential is less than 35 psi, then the demand pump will turn on and will continue to run until 45 psi differential is obtained. Then, the pump will shut down and start only when the differential pressure falls below 35 psi.

**NOTE: For alarm descriptions and shutdown or cutout parameters, see publication 090-020 O.**

### COMPRESSOR OIL SEPARATION SYSTEM

The RWF II is an oil flooded screw compressor. Most of the oil discharged by the compressor separates from the gas flow in the oil charge reservoir. Some oil, however, is discharged as a mist which does not separate readily from the gas flow and is carried past the oil charge reservoir. One or more coalescer filter elements then COALESCE the oil mist into droplets which fall to the bottom of the coalescer section of the oil separator. See Figure 16. The return of this oil to the compressor is controlled by a throttling valve on both high stage and booster applications.

**NOTE: Open throttling valve only enough to keep coalescer end of separator free of oil.**

The sight glass located near the bottom of the coalescer section of the oil separator should remain empty during normal operation. If an oil level develops and remains in the sight glass, a problem in the oil return separation system or compressor operation has developed. Refer to **MAINTENANCE** for information on how to correct the problem.

**NOTE: The normal operating level is midway between the two sight glasses located midway along the oil separator shell.**




Figure 16 - Oil Separation System

### COLD-START SYSTEM

The RWF II package is equipped with a special "cold-start" discharge check valve (Figure 17) on the gas outlet connection of the oil separator. This valve causes the oil separator to develop oil pressure rapidly on initial start in order to lubricate the compressor without requiring an oil pump, even in cold ambient temperatures with all pressures equalized.

**For high-stage packages,** the cold-start valve is equipped with a large spring that creates 30 psi of pressure in the oil separator (above suction pressure), for lubrication of the compressor.

Once the compressor is running it will begin to force gas to the condenser at connection P2. As the condenser heats up it will begin to rise in pressure as the compressor suction pulls down in pressure. As soon as differential pressure is developed between the condenser and suction, these pressures act across a piston inside the cold-start valve to partially overcome the spring force. When the differential pressure reaches and exceeds 30 psi, the piston fully overcomes the spring force and powers the valve fully open for very low operating pressure drop.

**For booster applications,** the valve is equipped with a lighter spring which produces 7 psi oil pressure above suction pressure before it fully powers open. An oil pump is required to ensure compressor lubrication.

The RWF II package is also equipped with a suction check valve bypass. The oil separator will slowly bleed down to approximate system suction pressure when the unit is stopped. This allows the compressor drive motor to have an easier start, and the discharge check valve will seat more tightly. See the "SUCTION CHECK VALVE BYPASS" section for operation.

**NOTE: For alarm descriptions and shutdown or cutout parameters, see publication 090-020 O.**




Figure 17 - Cold-Start Valve

## COMPRESSOR HYDRAULIC SYSTEM

The compressor hydraulic system moves the movable slide valve (MSV) to load and unload the compressor. It also moves the movable slide stop (MSS) to increase or decrease the compressor's volume ratio ( $V_i$ ).

The hydraulic cylinder located at the inlet end of the SGC compressor serves a dual purpose. It is separated by a fixed bulkhead into two sections. The movable slide valve (MSV) section is to the left of the bulkhead and the movable slide stop (MSS) to the right. Both sections are considered double-acting hydraulic cylinders as oil pressure moves the pistons in either direction.

Both sections are controlled by double-acting, four-way solenoid valves which are actuated when a signal from the appropriate microprocessor output energizes the solenoid valve. Valves V1, V2, SC1, SC3, and SC4 are always open. **NOTE: The solenoid coils can be serviced or replaced without evacuating the package. However, if the hydraulic solenoid valves or manifold block needs to be serviced or replaced, then the compressor package must be evacuated.**

### SINGLE-ACTING MODE - High Stage

Close valve at SC2  
Open valve at BP (bypass)

**High stage compressor loading:** The compressor loads when MSV solenoid YY2 is energized and oil flows from the unload side of the cylinder out port SC1, through valve ports A and T to compressor suction. Simultaneously, discharge pressure loads the slide valve.

**High stage compressor unloading:** The compressor unloads when MSV solenoid YY1 is energized and oil flows from the oil manifold through valve ports P and A to cylinder port SC1 and enters the unload side of the cylinder. Simultaneously, gas on the load side of the cylinder is vented through port SC2 and valve BP to compressor suction.

**NOTE: To control the rate of loading and unloading, change cycle time, proportional band, and dead band setpoints with Quantum control. If additional control is needed, throttle SC2 or BP.**

### DOUBLE-ACTING MODE - Booster

Open valve at SC2  
Close valve at BP (bypass)

**Booster Compressor Loading:** The compressor loads when MSV solenoid YY2 is energized and oil flows from the oil manifold through valve ports P and B to cylinder port SC2 and enters the load side of the cylinder. Simultaneously, oil contained in the unload side of the cylinder flows out cylinder port SC1 through valve ports A and T to compressor suction.

**Booster Compressor Unloading:** The compressor unloads when MSV solenoid YY1 is energized and oil flows from the oil manifold through valve ports P and A to cylinder port SC1 and enters the unload side of the cylinder. Simultaneously, oil contained in the load side of the cylinder flows out of compressor port SC2 through valve ports B and T to compressor suction.

**NOTE: To control the rate of loading and unloading, change cycle time, proportional band, and dead band setpoints with Quantum control. If additional control is needed, throttle SC2 or BP.**




Figure 18



**NEVER open valve BP and valve SC2 at the same time during compressor operation.**

## VOLUME RATIO CONTROL

**NOTE: See Figure 19 for port references.**

Open valve at SC3  
Open valve at SC4 (not used on models 496,676,856,1080)

**Compressor  $V_i$  increase:** The volume ratio  $V_i$  is increased when MSS solenoid valve YY3 is energized and oil flows from the oil manifold through valve ports P and A to compressor port SC3, enters the increase side of the cylinder and overcomes the decrease spring tension. Simultaneously, oil flows from SC4 port through valve ports B and T to compressor suction. On models 496, 676, 856, and 1080 the SC4 port does not exist. The inboard side of the slide stop piston is at suction pressure.

**Compressor  $V_i$  decrease:** The volume ratio  $V_i$  is decreased when MSS solenoid valve YY4 is energized and oil flows from the oil manifold through valve ports P and B to compressor port SC4, enters the decrease side of the cylinder. Simultaneously, oil flows from SC3 port through valve ports A and T to compressor suction. On models 496, 676, 856, and 1080 the SC4 port does not exist. On these models, YY4 is energized which permits oil to vent from port A to T with assistance from the unloader spring.

TO CONTROL THE RATE OF  $V_i$  CHANGE, THROTTLE THE NEEDLE VALVE AT SC3 PORT.


## COMPRESSOR OIL COOLING SYSTEMS

The RWF II unit can be equipped with one of several systems for controlling the compressor oil temperature. They are single or dual-port liquid injection and thermosyphon or water-cooled oil coolers. Each system is automatically controlled, independent of compressor loading or unloading.

Oil cooling systems should maintain oil temperature within the following ranges for R-717:

Liquid Injection Oil Cooling	External* Oil Cooling
130 - 170°F	120 - 160°F

\* Thermosyphon oil cooling (TSOC) or Water cooled oil cooling (WCOC).



**Figure 19 - Port Locations**

**SINGLE-PORT LIQUID INJECTION**

The single-port liquid injection system is designed to permit liquid refrigerant injection into one port on the compressor at any given moment and operates as outlined.

The liquid injection solenoid valve is energized by the microprocessor when the temperature sensor, installed in the compressor discharge, exceeds the setpoint. High-pressure liquid refrigerant is then supplied to the temperature control valve (TCV). **Refer to P & I DIAGRAMS section for piping and instrumentation drawings.**

**DUAL-PORT LIQUID INJECTION**

The dual-port liquid injection system is designed to obtain the most efficient compressor performance at high and low compression ratios by permitting injection of liquid refrigerant into one of two ports optimally located on the compressor. This minimizes the performance penalty incurred with liquid injection oil cooling.

The dual-port system contains all the components of the single-port system with the addition of a double-acting solenoid valve and operates as outlined.

The liquid injection solenoid valve is energized by the microprocessor when the temperature sensor, installed in the oil manifold, exceeds the setpoint. Liquid refrigerant is then passed through the temperature control valve (TCV) to the double-acting solenoid valve. Depending on the compressor's operating volume ratio (Vi), the microprocessor will select the flow of the liquid refrigerant to the optimum compressor port.

## QUANTUM™LX EZ-COOL™ LIQUID INJECTION ADJUSTMENT PROCEDURE

Use the following directions to set up and tune the EZ-Cool LIOC with a Quantum™LX Control Panel. Also refer to publication 090-022 O, Quantum™LX Operation, for an overview of PID control.

First, complete calibration of the analog output used for EZ-Cool™ LIOC. Typically, this will be analog output #1 for PID #1.

- Power down the panel and remove the two control wires for the valve from terminals 1 & 2 of the P11A terminal strip of analog board #1.
- Place the leads of a calibrated, quality meter to terminal one (positive) and terminal two (negative). Set the meter to read mA DC and power up the panel.
- Set operating session to session [2] and go to the screen shown in Figure 20 by pressing [Menu] > [Calibration] > [Analog Outputs] > [Output Calibration].
- Press #1 on the keypad to drive the output to the low end. Using numbers 4, 7 and 0 on the keypad to increase and decrease the output and change the "Delta For Changing Output Percentage" setpoint, set the output to 4mA.
- If the read value is less than the objective of 4 or 20mA use 7 on the keypad, increase the output by the Delta. If the read value is more than the objective, use 4 to decrease the value by the Delta.
- Use the 0 key to change the Delta from 10 to 1, .10 or .01% to tune the output to the objective of 4 or 20mA.
- Press #3 on the keypad to set the output to the high end and repeat the process in the preceding steps to set the output to 20mA.
- Power down the panel, remove the meter and reconnect the control wires for the EZ-Cool LIOC valve as they were removed to terminals 1 & 2 of the P11A terminal strip of analog board #1.

### Description of Proportional Band and Gain setpoints:

- **Proportional Band** – This setpoint determines the size of a region either above or below the Control Setpoint. Within this region the Proportional component of the PID Output value is the number between 0% and 100% that directly corresponds to the difference between the Control Input (Actual) and the Control Setpoint (Setpoint). Outside of this region the Proportional component is either 100% or 0%. If the PID Action is Forward, the Proportional Band extends above the Control Setpoint. If the PID Action is Reverse, the Proportional Band extends below the Control Setpoint.
- **Proportional Gain** – This value is calculated from the Proportional Band setpoint and is the same value that was entered as a Proportional Gain setpoint in the Quantum. The control setpoint will not be achieved with proportional control only. Integral control is needed to further correct the control input to achieve the setpoint.
- **Integral Gain** – This setpoint controls the influence the Integral component exerts on the PID Output value. The Integral component works to push the Control Input toward the Control Setpoint by tracking the difference between the Control Input and the Control Setpoint over time.
- **Derivative Gain** – This setpoint controls the influence the Derivative component exerts on the PID Output value. The Derivative component reacts to rapid changes in the value of the Control Input by predicting the direction the Control Input is traveling and then turning it back toward the Control Setpoint.

### Example of Proportional Only Control:

Control Input:	Discharge Temperature
Control Setpoint:	150°F
Dead Band:	0°F
Proportional Band:	25
Action:	Forward




Figure 20 - Analog Output Calibration




Figure 21 - PID Setup

**NOTES:**

1. Set the "Liquid Slugging" Alarm and Shutdown setpoints to 90 to prevent nuisance shutdowns during the tuning process. Be sure to return these setpoints to their original values when finished.
2. While the discharge temperature will be the Control Point, it reacts quickly to adjustments. Be sure to allow an adjustment to the proportional band or integral gain setpoints the opportunity to counter and correct the control input (discharge temperature) before making additional adjustments.
3. Tune the output by making small adjustments of 1-5 to the Proportional Band and .1-.5 of the Integral Gain setpoints. Adjust only one at a time, allowing each adjustment time to settle out.
  - Using the chart below, as long as the control input is 155°F the output will be at 20% with proportional control only. Integral control will increase the output in increments, over time, to correct the control input to the setpoint.

Control Input	Output %
150°F	0%
155°F	20%
160°F	40%
165°F	60%
170°F	80%
175°F	100%

Based on these descriptions set PID #1 for EZ-Cool™ LIOC per Figure 21 as a starting point. Tuning of the output will be required. There should be no need to use a derivative gain.




Figure 22

**OPERATION OF DANFOSS  
LIQUID INJECTION VALVE**

ICAD (Industrial Control Actuator with Display) is equipped with an MMI (Man Machine Interface) from which it is possible to monitor and change the setting of parameters to adapt the ICAD and the corresponding ICM (Motorized Industrial Control Valve) to the actual refrigeration application.

The setting of parameters is managed by means of the integrated ICAD MMI (Figures 22 and 23) and consists of:

- "Down" arrow push button (Figure 22)
  - Decreases parameter number by 1 at each activation
- "Up" arrow push button (Figure 22)
  - Increases parameter number by 1 at each activation




Figure 23

- Enter push button (Figure 22)
  - Gives access to the Parameter list by keeping the push button activated for 2 seconds. A Parameter list example is shown below (parameter j08, Figure 24).
  - Gives access to change a value once the Parameter list has been accessed.




Figure 24

- Acknowledge and save change of value of a parameter.
- To exit from the Parameter list and return to the display of Opening Degree (OD), keep the push button activated for 2 seconds.
- Display (Figure 22)
  - Normally the Opening Degree (OD) 0 - 100% of the ICM valve is displayed. No activation of push buttons for 20 seconds means that the display will always show OD (Figure 25).




Figure 25

- Displays the parameter.

- Displays the actual value of a parameter.
- Displays the function status by means of text (Figure 22).
  - **Mod** represents that ICAD is positioning the ICM valve according to an analog input signal (Current or Voltage).
  - **Low** represents that ICAD is operating the ICM valve like an ON/OFF solenoid valve with low speed according to a digital input signal.
  - **Med** represents that ICAD is operating the ICM valve like an ON/OFF solenoid valve with medium speed according to a digital Input signal.
  - **High** represents that ICAD is operating the ICM valve like an ON/OFF solenoid valve with high speed according to a digital input signal (Figure 26).




Figure 26

**Alarms** - ICAD can handle and display different alarms.

Description	ICM Alarm Text	Comments
No valve type Selected	<b>A1</b>	At start-up <b>A1</b> and <b>CA</b> will be displayed
Controller fault	<b>A2</b>	Internal fault inside electronics
All input error	<b>A3</b>	Not active if <b>j01</b> = 2 or <b>j02</b> = 2 When <b>j03</b> = 1 and AI A > 22 mA When <b>j03</b> = 2 and AI A > 22 mA Or AI A < 2mA When <b>j03</b> = 3 and AI A > 12V When <b>j03</b> = 4 and AI A > 12V or AI A < 1 V
LOW voltage of fail-safe supply	<b>A4</b>	If 5 V d.c. < Fail-safe supply < 18 V d.c.
Check Supply to ICAD	<b>A5</b>	If supply voltage < 18 V d.c.

If an alarm has been detected the ICAD display (Figure 22) will alternate between showing Actual alarm and present Opening Degree.

If more than one alarm is active at the same time, the alarm with the highest priority will take preference. **A1** has the highest priority, **A5** the lowest.

Any active alarm will activate the Common Digital Alarm output (Normally Open).

All alarms will automatically reset themselves when they physically disappear.

Old alarms (alarms that have been active, but have physically disappeared again) can be found in parameter **j11**.

**Reset to factory setting:**

1. Remove the power supply.
2. Activate down arrow and up arrow push buttons at the same time.

Parameter list

Description	Display Name	Min.	Max.	Factory Setting	Unit	Comments (Standard Setting)
ICM OD (Opening Degree)	-	0	100	-	%	ICM valve Opening Degree is displayed during normal operation. Running display value (see <b>j01, j05</b> ).
Main Switch	<b>j01</b>	1	2	1	-	Internal main switch <b>1: Normal operation</b> 2: Manual operation. Valve Opening Degree will be flashing. With the down arrow and the up arrow push buttons the OD can be entered manually.
Mode	<b>jo2</b>	1	2	1	-	Operation mode <b>1: Modulating - ICM positioning according to Analogue input (see j03)</b> 2: ON/OFF - operating the ICM valve like an ON/OFF solenoid valve controlled via Digital Input. See also <b>j09</b> .
Analog Input signal	<b>j03</b>	1	4	2	-	Type of Analog input signal from external controller 1: 0-20mA <b>2: 4-20mA</b> 3: 0-10V 4: 2-10V
Speed at ON/OFF and Modulating Mode	<b>j04</b>	1	100	100	%	Speed can be decreased. Max. speed is 100 % Not active when <b>j01</b> = 2 If <b>j02</b> = 2, the display will indicate speed in display. <b>Low, Med, and High</b> also means ON/OFF operation. If <b>j04</b> < = 33, <b>Low</b> is displayed 33 < If <b>j04</b> < = 66, <b>Med</b> is displayed If <b>j04</b> > = 67, <b>High</b> is displayed
Automatic calibration	<b>j05</b>	0	1	0	-	Not active before <b>j26</b> has been operated. Always auto reset to 0. <b>CA</b> will flash in the display during calibration.
Analog Output signal	<b>j06</b>	0	2	2	-	Type of AO signal for ICM valve position 0: No signal 1: 0 - 20mA <b>2: 4 - 20mA</b>
Fail-safe	<b>j07</b>	1	4	1	-	Define condition at power cut when fail-safe is installed. <b>1: Close valve</b> 2: Open valve 3: Maintain valve position 4: Go to OD given by <b>j12</b>
Digital Input function	<b>j09</b>	1	2	1	-	Define function when DI is ON (short circuited DI terminals) when <b>j02</b> = 2 <b>1: Open ICM valve (DI = OFF = &gt; Close ICM valve)</b> 2: Close ICM valve (DI = OFF = > Open ICM valve)
Password	<b>j10</b>	0	199	0	-	Enter number to access password protected parameters: <b>j26</b>
Old Alarms	<b>j11</b>	A1	A99	-	-	Old alarms will be listed with the latest shown first. Alarm list can be reset by means of activating down arrow and up arrow at the same time for 2 seconds.
OD at powercut	<b>j12</b>	0	100	50	-	Only active if <b>j07</b> = 4 If fail-safe supply is connected and powercut occurs, ICM will go to entered OD.
ICM configuration	<b>j26</b>	0	6	0	-	<b>NB:</b> Password protected. Password = <b>11</b> At first start-up, <b>A1</b> will flash in display. Enter valve type. 0: No valve selected. Alarm <b>A1</b> will become active. 1: ICM20 with ICAD 600 2: ICM25 with ICAD 600 3: ICM32 with ICAD 600 4: ICM40 with ICAD 900 5: ICM50 with ICAD 900 6: ICM65 with ICAD 900 } <b>You must get number off Valve Body</b>
OD%	<b>j50</b>	0	100	-	%	ICM valve Opening Degree is displayed during normal operation.
AI [mA]	<b>j51</b>	0	20	-	mA	Analog input signal
AI [V]	<b>j52</b>	0	10	-	V	Analog input signal
AO [mA]	<b>j53</b>	0	20	-	mA	Analog output signal
Digital Input function	<b>j54</b>	0	1	-	-	Digital Input signal
DO Close	<b>j55</b>	0	1	-	-	Digital Output Closed status. ON when OD < 3%
DO Open	<b>j56</b>	0	1	-	-	Digital Output Open status. ON when OD > 97%
DO Alarm	<b>j57</b>	0	1	-	-	Digital Output alarm status. ON when an alarm is detected
MAS mP SW ver.	<b>j58</b>	0	100	-	-	Software version for MASTER Microprocessor
SLA mP SW ver.	<b>j59</b>	0	100	-	-	Software version for SLAVE Microprocessor

3. Connect the power supply.
4. Release down arrow and up arrow push buttons.
5. When the display on ICAD (Figure 22) is alternating between showing: **CA** and **A1** the factory resetting is complete.

### SUCTION CHECK VALVE BYPASS

The RWF II unit is equipped with a low-pressure-drop suction check valve bolted directly to the compressor housing. Units that have an 8" stop valve or larger should be piped as shown in the shaded area of Figure 27. During normal operation, valve NV-1 is closed. This is a pump-out connection to allow refrigerant removal to the system suction prior to evacuation for servicing. Valve NV-2 must be open in most systems at all times. **It should normally be cracked open to allow the oil separator to slowly bleed down to approximately system suction pressure when the unit is stopped** (having this valve cracked open allows the compressor drive motor to have an easier start, and the discharge check valve will seat more tightly). If the drive coupling backspins, start closing the valve until the backspin stops. If the separator oil level foams excessively on shutdown, NV-2 should be closed slightly. If the separator takes more than 20 – 30 minutes to equalize to suction pressure after shutdown, NV-2 can be opened slightly. See Figure 27.

Check valve CV-4 is installed on all RWF II packages. On high-stage systems, check valve CV-4 is installed with a 45 psi spring to avoid the possibility of back-feeding to a shut-down compressor from a common economizer vessel.

On booster systems, check valve CV-4 is installed with a 25 psi spring to avoid the possibility of air ingress into the system, if the system suction pressure is below atmospheric.




Figure 27 - Suction Check Valve Bypass

### LOW AMBIENT OPERATION

It is recommended that oil separators be insulated as a minimum requirement to preserve the heat generated by the oil heaters. It is important that the coalescer end of the separator be insulated to prevent refrigerant condensation.

On systems located outdoors or in unheated buildings where the ambient temperature could drop below +40°F, insulating

and/or heat tracing of the compressor lube oil systems is highly recommended.

When low ambient temperatures (below +20°F) are a possibility, it is recommended that lube oil lines, oil filters, oil pumps, and oil coolers be heat traced and insulated.

Freeze-up protection must also be provided for all water-cooled equipment

### SUCTION CHECK VALVE POWER ASSIST KIT

Low temperature booster compressor applications require hot gas to assist the suction check valve closure for RWF II models 496, 676, 856, and 1080. This is accomplished by using the high pressure discharge gas from the oil separator (power assist kit).

The power assist kit (Figure 28) is factory installed with the discharge gas pressure being supplied from a connection on the dry end of the oil separator. The kit consists of a mounted and wired solenoid valve, timer, and metering valve. The timer limits the high pressure gas feed to the suction check valve to thirty seconds via the solenoid valve. This is sufficient time to warm the suction check valve piston and provide proper operation. The metering valve is provided for use as a service valve and to allow discharge gas flow regulation to prevent excessive force and resulting closure "hammering". The valve should be adjusted accordingly to prevent such an occurrence.




Figure 28 - Power Assist Kit

### BALANCE PISTON PRESSURE REGULATOR

A Balance Piston Pressure Regulator may be required on Models 496 – 1080 to reduce the extended overbalance from the thrust balance piston at part load.

**High-Stage SB-2 Oil Supply Line Diagram**, Figure 29, shows the three additions described below arranged in parallel.

**PRESSURE-REGULATING VALVE:** Discharge pressure determines compressor thrust balance. The proper setting for the pressure-regulating valve is 50 psi (±15) below DISCHARGE pressure when slide valve is less than 65%.

**SOLENOID VALVE:** Energizing, or opening, the solenoid valve pressurizes the balance piston with full oil pressure from the oil manifold, bypassing the A4ALE Pressure Regulating Valve. De-energizing, or closing, the solenoid valve pressurizes the balance piston with oil pressure regulated by the A4ALE Pressure Regulating Valve.

Signals from the control panel operate the solenoid valve (output module 12 on micro panel). The solenoid valve should open when the slide valve position is 70% or greater, and close when the slide valve position is 65% or less.

**ORIFICE:** The orifice ensures oil supply to the inlet end bearings during upset conditions such as start-up.




Figure 29 - High-Stage SB-2 Oil Supply Line Diagram

### INITIAL START-UP

Initial start-up must be performed under the supervision of a Johnson Controls-Frick authorized start-up representative to prevent voiding the compressor warranty. Prior to the start-up, the prestart check must be accomplished. See Prestart Checklist in the Forms section of this manual.

#### INITIAL START-UP PROCEDURE

Having performed the checkpoints on the prestart checklist (see FORMS section), the compressor unit is ready for start-up. It is important that an adequate refrigerant load be available to load test the unit at normal operating conditions. The following points should be kept in mind during initial start-up.

**1. It is imperative that during the initial start-up of the package that the hand expansion valve on the main oil injection line is fully open to ensure adequate oil flow.** There is still an orifice installed in the compressor to control maximum oil flow. At initial start-up of the package the hand expansion valve must be fully open. After initial start-up of the package the hand expansion valve should be adjusted. There are two methods of determining the correct adjustment of this valve.

The best method to determine target discharge temperature is to run CoolWare™ with the operating conditions of the compressor. The program will give you a theoretical discharge temperature of the compressor. Once this temperature is known, you may adjust the hand expansion valve. The ideal discharge temperature is within 5°F + or - of the theoretical discharge temperature. Adjust the valve to achieve the theoretical discharge temperature. If you do not have access to CoolWare™, 180°F is a good target discharge temperature for a high stage ammonia compressor. Booster applications and compressors using HFC and HCFC refrigerants may run cooler. Compressors with high discharge pressure may run hotter.

The first method is used for compressors with External Oil Cooling (Thermosyphon, Water Cooled, and Glycol Cooled). Before the initial startup of the compressor close the hand expansion valve completely. Open the valve back up and count the turns that it takes to fully open the valve. After

the initial startup close the valve to achieve approximately 180° F discharge temperature or the theoretical temperature from CoolWare. Do not fully close the valve at any time while the compressor is running.

The second method is used for compressors with Liquid Injection Oil Cooling. Because the discharge temperature is controlled by the Liquid Injection Thermal Expansion Valve you will not be able adjust for the correct oil flow by using the discharge temperature. Before the initial startup of the compressor close the hand expansion valve completely. Open the valve back up and count the turns that it takes to fully open the valve. After the initial startup close the valve ½ way. If it took 10 turns to open the valve completely, then turn it in 5 turns. If it took 7 turns to open, then close the valve 3½ turns. Do not close the valve any further than ½ the number of turns required to fully open it.

**WARNING** Failure to properly adjust this valve can lead to excessive noise and vibration of the compressor and package, premature failure of the bearings, liquid loading of the rotors, liquid starvation of the rotors and catastrophic failure of the compressor.

2. For proper and safe operation, the compressor must be run at the proper speed and discharge pressure. Exceeding design conditions creates a potential hazard.
3. Rotate and lubricate motor bearings according to manufacturer's recommendations **PRIOR** to initial start-up as required.
4. After running the unit for approximately three hours, adjust liquid injection oil cooling if applicable. If unit has water cooled oil cooling, adjust water control valve to cooler.
5. The compressor slide valve and slide stop linear transmitters should be calibrated.
6. Perform vibration analysis if equipment is available.

#### NORMAL START-UP PROCEDURE

1. Confirm system conditions permit starting the compressor.
2. Press the **[RUN]** key.
3. Allow the compressor to start-up and stabilize. Press the **[AUTO]** key immediately below the V ratio label on the operating display screen. Press the **[AUTO]** key immediately below the SV POS label on the operating display. The compressor is now operating in the automatic mode.
4. Observe the compressor unit for mechanical tightness of the external piping, bolts and valves. Ensure that the machine is clean from oil and refrigerant leaks. If any of these occur, shut down the compressor and correct the problem as necessary using good safety precautions.
5. **RETIGHTEN MANWAY BOLTS at condenser design pressure (while system is running).**

#### RESTARTING COMPRESSOR UNIT AFTER CONTROL POWER INTERRUPTION (PLANT POWER FAILURE)

1. Check variable setpoints.
2. Follow normal start-up procedure.

## Maintenance

### GENERAL INFORMATION

This section provides instructions for normal maintenance, a recommended maintenance program, troubleshooting and correction guides, and typical P and I diagrams. For typical wiring diagrams and information about the *Quantum™LX* control panel, consult publication 090-020 M.

**WARNING** THIS SECTION MUST BE READ AND UNDERSTOOD BEFORE ATTEMPTING TO PERFORM ANY MAINTENANCE OR SERVICE TO THE UNIT.

### NORMAL MAINTENANCE OPERATIONS

When performing maintenance you must take several precautions to ensure your safety:



1. IF UNIT IS RUNNING, PRESS [STOP] KEY.
2. DISCONNECT POWER FROM UNIT BEFORE PERFORMING ANY MAINTENANCE.
3. WEAR PROPER SAFETY EQUIPMENT WHEN COMPRESSOR UNIT IS OPENED TO ATMOSPHERE.
4. ENSURE ADEQUATE VENTILATION.
5. TAKE NECESSARY SAFETY PRECAUTIONS REQUIRED FOR THE REFRIGERANT BEING USED.

**WARNING** CLOSE ALL COMPRESOR PACKAGE ISOLATION VALVES PRIOR TO SERVICING THE UNIT. FAILURE TO DO SO MAY RESULT IN SERIOUS INJURY.

### GENERAL MAINTENANCE

Proper maintenance is important in order to assure long and trouble-free service from your screw compressor unit. Some areas critical to good compressor operation are:

1. Keep refrigerant and oil clean and dry, avoid moisture contamination. After servicing any portion of the refrigeration system, evacuate to remove moisture before returning to service. Water vapor condensing in the compressor while running, or more likely while shut down, can cause rusting of critical components and reduce life.
2. Keep suction strainer clean. Check periodically, particularly on new systems where welding slag or pipe scale could find its way to the compressor suction. Excessive dirt in the suction strainer could cause it to collapse, dumping particles into the compressor.
3. Keep oil filters clean. If filters show increasing pressure drop, indicating dirt or water, stop the compressor and change filters. Running a compressor for long periods with high filter pressure drop can starve the compressor for oil and lead to premature bearing failure.
4. Avoid slugging compressor with liquid refrigerant. While screw compressors are probably the most tolerant to ingestion of some refrigerant liquid of any compressor type available today, they are not liquid pumps. Make certain to maintain adequate superheat and properly size suction accumulators to avoid dumping liquid refrigerant into compressor suction.

Keep liquid injection valves properly adjusted and in good condition to avoid flooding compressor with liquid. Liquid can cause a reduction in compressor life and in extreme cases can cause complete failure.

5. Protect the compressor during long periods of shut down. If the compressor will be sitting for long periods without running it is advisable to evacuate to low pressure and charge with dry nitrogen or oil. This is particularly true on systems known to contain water vapor.
6. Preventive maintenance inspection is recommended any time a compressor exhibits a noticeable change in vibration level, noise or performance.

### COMPRESSOR SHUTDOWN and START-UP

For seasonal or prolonged shutdowns the following procedure should be followed:

1. Reduce the system pressure to the desired condition.
2. Press [STOP] key to cease operation of the compressor.
3. Open disconnect switches for compressor motor and oil pump starters.
4. Turn on oil heater circuit breaker.
5. Close suction and discharge service valves, also liquid injection and economizer service valves, if applicable. **Attach CLOSED TAGS.**
6. Shut off cooling water supply valve to oil cooler, if applicable. **Attach CLOSED TAG.**
7. Protect oil cooler from ambient temperatures below freezing or remove water heads.

To start up after a seasonal or prolonged shutdown the following procedure should be followed:

1. Any water necessary for the operation of the system that may have been drained or shut off should be restored and turned on.
2. Open suction and discharge service valves, also liquid injection and economizer service valves, if applicable. Remove tags.
3. Close disconnect switches for compressor, motor and oil pump starters.
4. Turn off oil heater circuit breaker.
5. Perform checkpoints on prestart check list, then start unit.

### GENERAL INSTRUCTIONS FOR REPLACING COMPRESSOR UNIT COMPONENTS

**NOTE: See Publication 070-660 SM for procedures covering replacement motor and compressor mounting.**

When replacing or repairing components which are exposed to refrigerant pressure (including suction strainer) proceed as follows:

1. Push [STOP] key on control panel to shut down unit.
2. Open disconnect switches for compressor and pump motor starters.
3. Close suction and discharge service valves, also liquid injection and economizer service valves, if applicable.

4. SLOWLY vent separator to low-side system pressure using the bypass line on the suction trap. NOTE: Recover or transfer all refrigerant vapor, in accordance with local ordinances, before opening to atmosphere. The separator MUST be equalized to atmospheric pressure.



**Oil-entrained refrigerant may vaporize, causing a separator pressure increase. Repeat venting and recovery procedure, if necessary.**

5. Make replacement or repair. NOTE: Replace all gaskets and O-rings with new ones. Suction Strainer: remove, inspect and clean as necessary and replace using a new gasket.

6. Isolate the low pressure transducer, PE-4, to prevent damage during pressurization and leak test.

7. Pressurize unit and leak test.

8. Evacuate unit.

9. Open suction and discharge service valves, low pressure transducer, and also liquid injection and economizer service valves, if applicable.

10. Close disconnect switches for compressor and oil pump motor starters.

11. Unit is ready to put into operation.

12. Perform checkpoints on prestart checklist, then start unit.

### OIL FILTER (OF-1) MAIN SINGLE/DUAL

RWF II compressor units are furnished with one main oil filter (OF-1). A second oil filter (OF-2) is installed as optional equipment to facilitate the changing of the filter element(s) without unit shutdown.



**Use of filter elements other than Frick® may cause warranty claim to be denied.**

The procedure to change filter cartridge(s) is as follows:

1. If a single oil filter is installed, push [STOP] key on microprocessor panel to shut down unit, then open disconnect switches for compressor and oil pump motor starters.

If dual oil filters are installed, open the outlet, then inlet service valves of the standby filter.



**Open inlet service valve slowly to prevent a sudden pressure drop which could cause an oil filter differential alarm.**

2. Close outlet then inlet service valves of filter being serviced.

3. Open bleed valve and purge pressure from the oil filter cartridge. NOTE: Recover or transfer all refrigerant vapor, in accordance with local ordinances, before opening to atmosphere.

4. Remove the plug from the bottom of the filter canister and drain the oil. Remove the canister cover and discard the gasket. Remove the screws securing the filter assembly. Pull the filter assembly from the canister and discard the gasket and the element.

5. Flush the canister with clean compressor oil; wipe dry with a clean, lint-free cloth; and replace the plug.

6. Install a new element\* and tighten the nut on the end plate to 10 ft-lb torque. Then, while holding the nut with a wrench, apply a second nut to act as a locknut. Replace the gasket and reinstall the filter assembly into canister, securing with screws tightened to 7 ft-lb torque. Fill the canister with new Frick refrigeration oil.

\*After January 2010, the SuperFilter™II element was changed to a single piece. The rod and nuts were eliminated and the end plate and gasket are now part of the filter. Refer to the Oil Filter page in the SPL for detailed graphic.



**DO NOT MIX OILS of different brands, manufacturers, or types. Mixing of oils may cause excessive oil foaming, nuisance oil level cutouts, oil pressure loss, gas or oil leakage and catastrophic compressor failure.**

Replace the gasket and reinstall the canister cover. Torque cover bolts first to finger tight, then 65 ft-lb, then 130 ft-lb.

7. Close purge valve.

8. Open outlet service valve and leak test.

9. Filter is ready to place in service.

### STRAINER - DEMAND OIL PUMP

To clean the demand oil pump strainer, the unit must be shut down. The procedure is as follows:

1. Push [STOP] key on microprocessor panel to shutdown unit, then open disconnect switches for compressor and oil pump motor starters.

2. Close strainer inlet service valve.

3. Open drain valve located in the strainer cover and drain oil into a container.

4. Remove capscrews securing strainer cover, strainer cover, gasket and element. Retain gasket.

5. Wash element in solvent and blow clean with air.

6. Wipe strainer body cavity clean with a lint-free clean cloth.

7. Replace cleaned element, gasket and reattach cover using retained capscrews.

8. Close drain valve and open strainer inlet service valve.

9. Check for leakage.

10. Close disconnect switches for compressor and oil pump motor starters.

11. Start the unit.

### STRAINER - LIQUID INJECTION

To clean the liquid injection strainer the unit must be shut down. The procedure is as follows:

1. Push [STOP] key on microprocessor panel to shut down unit, then open disconnect switches for compressor and oil pump motor starters.

2. Close liquid supply service valve located before liquid solenoid.

**WARNING** Excessive pressure from expanding refrigerant trapped between stop valve and solenoid may cause gasket and O-ring failure and uncontrolled refrigerant release.

3. Close service valve located between the compressor and the liquid injection thermostatic valve.
4. Carefully loosen capscrews securing the strainer cover to the strainer. Allow pressure to relieve slowly.
5. When all entrapped refrigerant has been relieved, carefully remove loosened capscrews (as liquid refrigerant is sometimes caught in the strainer), strainer cover and strainer basket.
6. Wash the strainer basket and cover in solvent and blow clean with air.
7. Reassemble strainer.
8. Open service valve between compressor and liquid injection thermostatic valve and check for leakage.
9. Screw out manual solenoid valve stem.
10. Carefully open liquid supply service valve.
11. Leak test.
12. Close disconnect switches for compressor and oil pump motor starters.
13. Start unit.

### COALESCER FILTER ELEMENT(S)

When changing the coalescer filter element(s) it is recommended that the oil be changed, cartridge(s) in oil filters OF-1 and OF-2 if applicable be changed and the following applicable strainer elements be removed and cleaned.

**WARNING** Use of filter elements other than Frick® may cause warranty claim to be denied.

1. Refer to **CHANGING OIL**, Steps 1 through 8.
2. Loosen manway cover retainer bolts, remove retainers, manway cover and cover gasket. Discard cover gasket.
3. Remove and retain nut securing coalescer filter retainer.
4. Remove retainer, coalescer filter element and 2 O-rings. Discard filter elements.
5. Install new coalescer filter element(s). **NOTE: Frick Super-Coalescer™ element (with drain feature) must be installed with the "DRAIN DOWN" tag on the bottom at the 6 o'clock position.**

**CAUTION** Seat element in center of locating tabs on separator bulkhead.

6. Replace coalescer filter retainer and nut. Tighten the nut to 21 ft/lb torque. **DO NOT OVERTIGHTEN NUT. Excessive torque can damage the element and result in oil carryover.** Install jam nut and tighten.
7. Install new manway gasket and replace manway cover.
8. Tighten manway bolts. **NOTE: RETIGHTEN AFTER THE COMPRESSOR UNIT IS REPRESSURIZED, SINCE MANWAY BOLTS WILL LOOSEN.**

9. Refer to **CHANGING OIL**, Steps 9 through 14.

### CHANGING OIL

**WARNING** DO NOT MIX OILS of different brands, manufacturers, or types. Mixing of oils may cause excessive oil foaming, nuisance oil level cutouts, oil pressure loss, gas or oil leakage and catastrophic compressor failure.

Shut down the unit when changing oil. At the same time all oil filter cartridges must be changed and all oil strainer elements removed and cleaned. The procedure is as follows:

1. Press the **[STOP]** key on the microprocessor panel to stop the compressor unit.
2. Open the disconnect switch for the compressor motor starter.
3. Close the suction and discharge service valves; also close the liquid-injection and economizer service valves, if applicable.
4. **SLOWLY** vent separator to low-side system pressure using the bypass line on the suction trap. **NOTE: Recover or transfer all refrigerant vapor, in accordance with local ordinances, before opening to atmosphere. The separator MUST be equalized to atmospheric pressure.**

**WARNING** Oil-entrained refrigerant may vaporize, causing a separator pressure increase. Repeat venting and recovery procedure, if necessary.

5. Open the drain valve(s) located on the underside of the separator and drain the oil.
6. Drain the oil filter(s) OF-1 and, if applicable, the oil coolers and filter OF-2.
7. Remove the old filter cartridges, then install new ones (as previously described in the section **OIL FILTER (OF-1) MAIN SINGLE/DUAL**).
8. Remove, clean, and reinstall strainer elements in the strainers.
9. Evacuate unit to 29.88" Hg (1000 microns) vacuum.
10. Open the suction service valve and pressurize the unit to system suction pressure. Close the suction valve and leak test.
11. Add oil by attaching a suitable pressure-type hose to the oil drain valve located under the separator. Using a pressure-type oil pump and recommended Frick® oil, open the drain valve and fill the separator until the oil level is midway in the top sight glass. **NOTE: Evacuation of the oil separator will assist the flow of oil into the unit. Also, fill slowly because oil will fill up in the separator faster than it shows in the sight glass.** Refer to the table in the **OIL CHARGE** section for approximate oil charge quantities.
12. Open the suction and discharge service valves, and also the liquid injection and economizer service valves, if applicable.
13. Close the disconnect switch for the compressor motor starter.
14. Start the unit.

**DEMAND PUMP DISASSEMBLY**



**BEFORE OPENING ANY VIKING PUMP LIQUID CHAMBER (PUMPING CHAMBER, RESERVOIR, JACKET, ETC.) ENSURE:**

1. That any pressure in the chamber has been completely vented through suction or discharge lines or other appropriate openings or connections.
2. That the driving means (motor, turbine, engine, etc.) Has been "locked out" or made nonoperational so that it cannot be started while work is being done on the pump.

**FAILURE TO FOLLOW ABOVE LISTED PRECAUTIONARY MEASURES MAY RESULT IN SERIOUS INJURY OR DEATH.**

1. Mark head and casing before disassembly to ensure proper reassembly. The idler pin, which is offset in the pump head, must be positioned up and equal distance between port connections to allow for proper flow of liquid through the pump.
2. Remove the head capscrews.
3. Tilt top of head back when removing to prevent idler from falling off idler pin.
4. Remove idler and bushing assembly. If idler bushing needs replacing, see **INSTALLATION OF CARBON GRAPHITE BUSHINGS**.
5. Insert a brass bar or piece of hardwood in the port opening and between rotor teeth to keep shaft from turning. Turn the locknut counterclockwise and remove locknut. See Figure 30 or 31.
6. Loosen two setscrews in face of bearing housing and turn thrust bearing assembly counterclockwise and remove from casing. See Figure 30 or 31.
7. **GG, HJ, HL:** Remove snap ring from shaft. See Figure 30. **AS, AK, AL:** Remove bearing spacer from shaft. See Figure 31.
8. Remove brass bar or piece of hardwood from port opening.
9. The rotor and shaft can now be removed by tapping on end of shaft with a lead hammer or, if using a regular hammer, use a piece of hardwood between shaft and hammer.

The rotary member of the seal will come out with rotor and shaft.

**10. AS, AK, AL:** Remove bearing retainer washer. The washer may have stayed with rotor and shaft when removed or is against ball bearing. See Figure 31.

**11.** Remove the mechanical seal rotary member and spring from rotor and shaft assembly.

**12. GG, HJ, HL:** Remove inner snap ring and single-row ball bearing from casing.

**AS, AK, AL:** Remove single-row ball bearing from casing.

**13.** Remove seal seat or stationary part of seal from casing.

**14.** Disassemble thrust-bearing assembly.

**GG, HJ, HL:** Remove outer snap ring from bearing housing and remove ball bearing. See Figure 30.

**AS, AK, AL:** Loosen two set screws in flange outside diameter. Rotate end cap and lip seal counterclockwise and remove. Remove ball bearing. See Figure 31.

The casing should be examined for wear, particularly in the area between ports. All parts should be checked for wear before pump is put together.

When making major repairs, such as replacing a rotor and shaft, it is advisable to also install a new mechanical seal, head and idler pin, idler, and bushing. See **INSTALLATION OF CARBON-GRAPHITE BUSHINGS**.

Clean all parts thoroughly and examine for wear or damage. Check lip seals, ball bearings, bushing, and idler pin and replace if necessary. Check all other parts for nicks, burrs, excessive wear and replace if necessary.

Wash bearings in clean solvent. Blow out bearings with compressed air. Do not allow bearings to spin; turn them slowly by hand. Spinning bearings will damage race and balls. Make sure bearings are clean, then lubricate with refrigeration oil and check for roughness. Roughness can be determined by turning outer race by hand. Replace bearings if bearings have roughness.

Be sure shaft is free from nicks, burrs and foreign particles that might damage mechanical seal. Scratches on shaft in seal area will provide leakage paths under mechanical seal. Use fine emery cloth to remove scratches or sharp edges.




Figure 30 - Thrust-Bearing assembly (GG, HJ, HL)




Figure 31 - Thrust-Bearing assembly (AS, AK, AL)

## DEMAND PUMP ASSEMBLY

Assembly Notes On Standard Mechanical Seal (Synthetic Rubber Bellows Type)

**NOTE: Read carefully before reassembling pump**

The seal used in this pump is simple to install and good performance will result if care is taken during installation.

The principle of mechanical seal is contact between the rotary and stationary members. These parts are lapped to a high finish and their sealing effectiveness depends on complete contact.

Prior to installing rotary portion of mechanical seal, prepare and organize rotor shaft, head and idler assemblies and appropriate gaskets for quick assembly

Once rotary portion of mechanical seal is installed on rotor shaft, it is necessary to assemble parts as quickly as possible to ensure that the seal does not stick to shaft in wrong axial position. The seal will stick to the shaft after several minutes setting time.

Never touch sealing faces with anything except clean hands or clean cloth. Minute particles can scratch the seal faces and cause leakage.

1. Coat idler pin with refrigeration oil and place idler and bushing on idler pin in head. If replacing a carbon-graphite bushing, refer to "Installation of Carbon Graphite Bushings".
2. Clean rotor hub and casing seal housing bore. Make sure both are free from dirt and grit. Coat outer diameter of seal seat and inner diameter of seal housing bore with refrigeration oil.
3. Start seal seat in seal housing bore. If force is necessary, protect seal face with a clean cardboard disc and gently tap it in place with a piece of wood. Be sure seal seat is completely seated in the bore.
4. Place tapered installation sleeve on shaft. Refer to Figure 32. Sleeve is furnished with GG, AS, AK, and AL replacement mechanical seals. Coat rotor shaft, tapered installation sleeve, and inner diameter of mechanical seal rotary member with a generous amount of refrigeration oil. Petrolatum may be used but grease is not recommended.
5. Place seal spring on shaft against rotor hub. Refer to Figure 33.
6. Slide rotary member, with lapped contact surface facing away from spring, over installation sleeve on shaft until

just contacting the spring. Do not compress spring. Remove installation sleeve.

7. Coat rotor shaft with refrigeration oil. Install shaft slowly pushing until the ends of rotor teeth are just below the face of the casing.
8. Leave the rotor in this position. Withdrawal of rotor and shaft may displace the carbon seal rotating face and result in damage to the seal.
9. Place O-ring gasket on head and install head and idler assembly on pump. Pump head and casing were marked before disassembly to ensure proper reassembly. If not, be sure idler pin, which is offset in pump head, is positioned up and equal distance between port connections to allow for proper flow of liquid through pump.

10. Tighten head capscrews evenly

11. Pack inner ball bearing with multipurpose grease, NLGI #2.

**GG, HJ, HL:** Install bearing in casing with sealed side towards head end of pump. Drive the bearing into the bore. Tap the inner race with a brass bar and lead hammer to position bearing. Install inner snap ring.

**AS, AK, AL:** Install bearing retainer washer over the shaft before installing ball bearing. Install ball bearing in casing with sealed side towards head end of pump. Drive the bearing into the bore. Tap the inner race with a brass bar and lead hammer to position bearing.

12. **GG, HJ, HL:** Install shaft snap ring in groove in the shaft. See Figure 30.

**AS, AK, AL:** Install bearing spacer over shaft and against single row ball bearing. See Figure 31.

13. Pack lubrication chamber between inner ball bearing and double-row ball bearing in the thrust-bearing assembly approximately one-half full of multipurpose grease, NLGI #2. The thrust-bearing assembly will take the remaining space. See Figure 30 and 31.

14. Pack double-row ball bearing with multipurpose grease, NLGI #2.

**GG, HJ, HL:** Install ball bearing into bearing housing with shield side toward coupling end of shaft. See Figure 30. Install snap ring into bearing housing to retain ball bearing. This snap ring has a tapered edge to fit tapered groove in bearing housing. The tapered edge is located away from ball bearing.




Figure 32




Figure 33

**AS, AK, AL:** Install ball bearing into bearing housing. Install lip seal in bearing housing end cap. The lip should face towards end of shaft. Put bearing spacer collar in lip seal and install in bearing housing and tighten setscrews securely. See Figure 31.

15. Insert brass bar or hardwood through port opening between rotor teeth to keep shaft from turning.

16. Start thrust-bearing assembly into casing. Turn by hand until tight. This forces rotor against head. Replace and tighten locknut or shaft.

17. Remove brass bar or hardwood from port opening.

18. Adjust pump end clearance.

**⚠ DANGER** BEFORE STARTING PUMP, ENSURE THAT ALL DRIVE EQUIPMENT GUARDS ARE IN PLACE. FAILURE TO PROPERLY MOUNT GUARDS MAY RESULT IN SERIOUS INJURY OR DEATH.

**THRUST BEARING ADJUSTMENT**

See Figures 30 and 31.

Loosen two screws in face of thrust-bearing assembly. If shaft cannot be rotated freely, turn thrust-bearing assembly counterclockwise until shaft can be turned easily.

1. While turning rotor shaft, rotate thrust-bearing assembly clockwise until noticeable drag occurs. This is zero end clearance.
2. Mark position of bearing housing with respect to the casing.
3. Rotate thrust-bearing assembly counterclockwise the distance listed below as measured on outside of bearing housing.
4. Tighten two setscrews in face of bearing housing after adjustment is made to secure thrust-bearing assembly position.

For viscosities above 2500 SSU, add additional end clearance (0.004" for GG, HJ and HL size pumps and 0.005" for AS, AK and AL size pumps).

Pump Size	Distance (in.) on O.D. of Bearing Housing	End Clearance (in.)
GG	7/16	.003
HJ, HL	9/16	.003
AS, AK, AL	1/2	.003

**INSTALLATION OF  
CARBON GRAPHITE BUSHINGS**

When installing carbon graphite bushings, extreme care must be taken to prevent breaking. Carbon graphite is brittle and easily cracked. If cracked, the bushing will quickly disintegrate. Using a lubricant and adding a chamfer on the bushing and the mating part will help in installation. The additional precautions listed below must be followed for proper installation:

1. A press must be used for installation.
2. Be certain bushing is started straight.

3. Do not stop pressing operation until bushing is in proper position. Starting and stopping will result in a cracked bushing.

4. Check bushing for cracks after installation.

**TROUBLESHOOTING THE DEMAND PUMP**

**⚠ DANGER** BEFORE OPENING ANY PUMP LIQUID CHAMBER (PUMPING CHAMBER, RESERVOIR, JACKET ETC.) ENSURE:

1. THAT ANY PRESSURE IN CHAMBER HAS BEEN COMPLETELY VENTED THROUGH SUCTION OR DISCHARGE LINES OR OTHER APPROPRIATE OPENINGS OR CONNECTIONS.
2. THAT THE DRIVING MEANS (MOTOR, TURBINE, ENGINE, ETC.) HAS BEEN "LOCKED OUT" OR MADE NON-OPERATIONAL SO THAT IT CANNOT BE STARTED WHILE WORK IS BEING DONE ON PUMP.

**FAILURE TO FOLLOW ABOVE LISTED PRECAUTIONARY MEASURES MAY RESULT IN SERIOUS INJURY OR DEATH.**

Mark valve and head before disassembly to ensure proper reassembly.

If trouble does develop, one of the first steps toward finding the difficulty is to install a vacuum gauge in the suction port and a pressure gauge in the discharge port. Readings on these gauges often will give a clue as to where to start looking for the trouble.

**Vacuum Gauge–Suction Port**

1. High reading would indicate:
  - a. Suction line blocked – foot valve stuck, gate valve closed, strainer plugged.
  - b. Liquid too viscous to flow through the piping.
  - c. Lift too high.
  - d. Line too small.
2. Low reading would indicate –
  - a. Air leak in suction line.
  - b. End of pipe not in liquid.
  - c. Pump is worn.
  - d. Pump is dry – should be primed.
3. Fluttering, jumping, or erratic reading:
  - a. Liquid vaporizing.
  - b. Liquid coming to pump in slugs – possibly an air leak or insufficient liquid above the end of the suction pipe.
  - c. Vibrating from cavitation, misalignment, or damaged parts.

**Pressure Gauge - Discharge Port**

1. High reading would indicate:
  - a. High viscosity and small and/or long discharge line.
  - b. Gate valve partially closed.
  - c. Filter plugged.
  - d. Vertical head did not consider a high specific gravity liquid.
  - e. Line partially plugged from buildup on inside of pipe.
  - f. Liquid in pipe not up to temperature.
  - g. Liquid in pipe has undergone a chemical reaction and has solidified.
  - h. Relief valve set too high.

2. Low reading would indicate:
  - a. Relief valve set too low
  - b. Relief valve poppet not seating properly.
  - c. Too much extra clearance.
  - d. Pump worn.
3. Fluttering, jumping, or erratic reading:
  - a. Cavitation.
  - b. Liquid coming to pump in slugs.
  - c. Air leak in suction line.
  - d. Vibrating from misalignment or mechanical problems.

**Some of the following may also help pinpoint the problem:**

1. Pump does not pump.
  - a. Lost its prime - air leak, low level in tank.
  - b. Rotating in wrong direction.
  - c. Motor does not come up to speed.
  - d. Suction and discharge valves not open.
  - e. Strainer clogged.
  - f. Relief valve set too low, relief valve poppet stuck open.
  - g. Pump worn out.
  - h. Any changes in the liquid system, or operation that would help explain the trouble, e.g. new source of supply, added more lines, inexperienced operators, etc.
  - i. Tighten end clearance.
  - j. Head position incorrect.
2. Pump starts, then loses its prime.
  - a. Low level in tank.
  - b. Liquid vaporizing in the suction line.
  - c. Air leaks or air pockets in the suction line; leaking air through packing or mechanical seal.
  - d. Worn out.
3. Pump is noisy
  - a. Pump is being starved (heavy liquid cannot get to pump fast enough). Increase suction pipe size or reduce length.
  - b. Pump is cavitating (liquid vaporizing in the suction line). Increase suction pipe size or reduce length; if pump is above the liquid, raise the liquid level closer to the pump; if the liquid is above the pump, increase the head of liquid.
  - c. Check alignment.
  - d. May have a bent shaft or rotor tooth. Straighten or replace.
  - e. May be a foreign object trying to get into the pump through the suction port.
4. Pump not up to capacity
  - a. Starving or cavitating - increase suction pipe size or reduce length.
  - b. Strainer partially clogged - clean.
  - c. Air leak in suction piping or along pump shaft.
  - d. Running too slowly - is motor the correct speed and is it wired up correctly
  - e. Relief valve set too low or stuck open.
  - f. Pump worn out.
  - g. Tighten end clearance.
  - h. Head position incorrect.
5. Pump takes too much power.
  - a. Running too fast - is correct motor speed, reducer ratio, sheave size, etc. being used.
  - b. Liquid more viscous than unit sized to handle - heat the liquid, increase the pipe size, slow the pump down, or get a bigger motor.
  - c. Discharge pressure higher than calculated - check with pressure gauge. Increase size or reduce length of pipe, reduce speed (capacity), or get bigger motor.

- d. Pump misaligned.
  - e. Extra clearance on pumping elements may not be sufficient for operating conditions. Check parts for evidence of drag or contact in pump and increase clearance where necessary
6. Rapid Wear.
    - a. Examination of a pump that has gradually lost its ability to deliver capacity or pressure would show a smooth wear pattern on all parts. Rapid wear shows up as heavy grooving, galling, twisting, breaking, or similar severe signs of trouble.

## PREVENTATIVE MAINTENANCE

Performing a few preventative maintenance procedures will extend the life of your pump and reduce the cost per gallon pumped.

**1. Lubrication** - Grease all zerks after every 500 hours of operation or after 60 days, whichever occurs first. If service is severe, grease more often. Do it gently with a hand gun. Use #2 ball bearing grease for normal applications. For hot or cold applications, use appropriate grease.

**2. Packing Adjustment** - Occasional packing adjustment may be required to keep leakage to a slight weep; if impossible to reduce leakage by gentle tightening, replace packing or use different type. See Technical Service Manual on particular model series for details on repacking.

**3. End Clearance Adjustment** - After long service the running clearance between the end of the rotor teeth and the head may have increased through wear to the point where the pump is losing capacity or pressure. Resetting end clearance will normally improve pump performance. See Technical Service Manual on particular model series for procedure on adjusting end clearance for the pump involved.

## RECOMMENDED MAINTENANCE PROGRAM

In order to obtain maximum compressor unit performance and ensure reliable operation, a regular maintenance program should be followed.

The compressor unit should be checked daily for leaks, abnormal vibration, noise, and proper operation. A log should also be maintained. Initial Oil analysis and Vibration analysis should be done at start-up and continued as recommended by the Maintenance Schedule.

## VIBRATION ANALYSIS

Periodic vibration analysis can be useful in detecting bearing wear and other mechanical failures. If vibration analysis is used as a part of your preventive maintenance program, take the following guidelines into consideration.

1. Always take vibration readings from exactly the same places and at exactly the same percentage of load.
2. Use vibration readings taken from the new unit at start-up as the base line reference.
3. Evaluate vibration readings carefully as the instrument range and function used can vary. Findings can be easily misinterpreted.

4. Vibration readings can be influenced by other equipment operating in the vicinity or connected to the same piping as the unit.

**OIL QUALITY AND ANALYSIS**

High quality refrigeration oil is necessary to ensure compressor longevity and reliability. Oil quality will rapidly deteriorate in refrigeration systems containing moisture and air or other contaminants. In order to ensure the quality of the refrigeration oil in the compressor unit.



**DO NOT MIX OILS of different brands, manufacturers, or types. Mixing of oils may cause excessive**

oil foaming, nuisance oil level cutouts, oil pressure loss, gas or oil leakage and catastrophic compressor failure.

**NOTE: The Frick® oil charge shipped with the unit is the best suited lubricant for the conditions specified at the time of purchase. If there is any doubt due to the refrigerant, operating pressures, or temperatures, refer to Frick® Oil publication 160-802 SPC for guidance.**

1. Only use Frick® oil filter elements or warranty claim may be denied.

2. Participate in a regular, periodic oil analysis program to maintain oil and system integrity. Oil Analysis Kit part number: 333Q0001853.

**MAINTENANCE SCHEDULE**

This schedule should be followed to ensure trouble-free operation of the compressor unit.

MAINTENANCE	FREQUENCY OR HOURS OF OPERATION (MAXIMUM)																						
	200	1000	5000	8000	10,000	15,000	20,000	25,000	30,000	35,000	40,000	45,000	50,000	55,000	60,000	65,000	70,000	75,000	80,000	85,000	90,000	95,000	
Change Oil	As Directed By Oil Analysis																						
Oil Analysis		■	Every 6 Months																				
Replace Filters	■		■		■		■		■		■		■		■		■		■		■		■
Clean Oil Strainers	■		■		■		■		■		■		■		■		■		■		■		■
Clean Liquid Strainers	■		■		■		■		■		■		■		■		■		■		■		■
Replace Coalescers									■						■								■
Check and Clean Suction Strainer	■		■		■		■		■		■		■		■		■		■		■		■
Check Coupling (a)	■	Annually Regardless of Operating Hours																					
Suction & Disch Flange Bolts (d)	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■
VFD Units Check Skip Freq. (f)	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■
Check Electrical Connections (b)	■		■		■		■		■		■		■		■		■		■		■		■
Check Sensor Calibration (c)	■	■	■		■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■
Vibration Analysis (e)	■	Every 6 Months, More Frequently If Levels Increase																					
Replace Shaft Seal	When Leak Rate Exceeds 7 - 8 Drops Per Minute																						

- a. Check bolts, shim packs, center inserts, keys, and all bolt torques.
- b. Check and torque all terminals in the processor and starter panel per the specification posted in the enclosure.
- c. Check calibration of Slide Valve, Slide Stop, pressures and temperatures. Calibration should be conducted with NIST certified devices.
- d. Verify tightness of bolts on suction and discharge flanges. See table below for torque requirements.
- e. Vibration measurement must be carried out continuously to obtain optimum preventative control on bearings. If not continuously controlled, then every 6 months, more frequently if levels increase.
- f. Units with variable speed drives - check for excess vibration and skip frequencies anytime unit operating conditions change.

RWF II MODEL	Compressor Model	Discharge Flange to Separator Flange		Suction Flange	
		Bolt Size	Torque* (ft-lb)	Bolt Size (in.)	Torque* (ft-lb)
100	SGC 1913	M20 X 2.5	140	M20 X 2.5	180
134	SGC 1918	M20 X 2.5	140	M20 X 2.5	160
177	SGC 2313	M20 X 2.5	160	M20 X 2.5	160
222	SGC 2317	M20 X 2.5	160	M20 X 2.5	200
270	SGC 2321	M20 X 2.5	160	M22 X 2.5	220
316	SGC 2813	M22 X 2.5	230	M22 X 2.5	220
399	SGC 2817	M22 X 2.5	230	M22 X 2.5	220
480	SGC 2821	M22 X 2.5	230	M24 X 3.0	220
496	SGC 3511	M24 X 3.0	240	M30 X 3.5	350
546	SGC 2824	M22 X 2.5	240	M24 X 3.0	220
676	SGC 3515	M24 X 3.0	240	M30 X 3.5	350
856	SGC 3519	M24 X 3.0	240	M30 X 3.5	350
1080	SGC 3524	M24 X 3.0	240	M30 X 3.5	350

\* Based on: Gaskets-Garlock® Blue-Gard® 3300; Bolts-class 8.8 or stronger hex head bolts, lightly oiled and clean

3. Oil samples for analysis should be taken after the oil filter. A 1/4" purge valve is provided in the oil filter canister head.

**OIL SAMPLING PROCEDURE**

**WARNING** Exercise extreme caution in the vicinity of operating equipment. Skin contact with lube oil or inhalation of vapors can cause serious injury or death, consider gloves and eye protection.

Sample hot, active fluid while the equipment is operating. Sample after 30 minutes of compressor operation.

1. Unthread the oil sampling valve cap and locknut (Figure 34).

**CAUTION** DO NOT UNTHREAD THE VALVE FROM THE FILTER HOUSING OR PIPING OR UNCONTROLLED RELEASE OF OIL WILL RESULT.

2. Unthread the bottle cap and carefully position under the oil sampling valve spout. Place the spout inside the bottle.

3. Push the oil sampling valve to open and release to close (spring actuated, see Figure 35). Fill the bottle 3/4 full.

4. Retighten bottle cap, sampling valve cap and locknut. Please note that the locknut prevents accidental release of oil.

5. Record all necessary sample data and identification on forms and labels and send promptly to the lab for results.




Figure 34



Figure 35 - Oil Sampling Valve

**OPERATING LOG**

The use of an operating log as included in this manual (see Table of Contents) permits thorough analysis of the operation of a refrigeration system by those responsible for its maintenance and servicing. Continual recording of gauge pressures, temperatures, and other pertinent information, enables the observer and serviceman to be constantly familiar with the operation of the system and to recognize immediately any deviations from normal operating conditions. It is recommended that readings be taken at least every four hours.

**MOTOR BEARINGS**

Follow the motor manufacturer's maintenance recommendations for lubrication. See Figure 36.

**WARNING** Make sure the motor bearings are properly lubricated before start-up as required by the motor manufacturer.

**GREASE COMPATIBILITY**

If it becomes necessary to mix greases, be careful not to combine different oil bases or thickeners. DO NOT mix a mineral oil-base grease with a synthetic oil-base grease. Also, a grease with a lithium thickener should not be mixed with one containing a sodium thickener. The table illustrates the compatibility of various types of grease based on results by National Lubricating Grease Institute (NLGI). The chart indicates a great variance in compaibility with the greases tested.

**NLGI Grease Compatibility Chart**

	Aluminum Complex	Barium	Calcium	Calcium 12-hydroxy	Calcium Complex*	Clay	Lithium	Lithium 12-hydroxy	Lithium Complex	Polyurea
Aluminum Complex	-	I	I	C	I	I	I	I	C	I
Barium	I	-	I	C	I	I	I	I	I	I
Calcium	I	I	-	C	I	C	C	B	C	I
Calcium 12-hydroxy	C	C	C	-	B	C	C	C	C	I
Calcium Complex	I	I	I	B	-	I	I	I	C	C
Clay	I	I	C	C	I	-	I	I	I	I
Lithium	I	I	C	C	I	I	-	C	C	I
Lithium 12-hydroxy	I	I	B	C	I	I	C	-	C	I
Lithium Complex	C	I	C	C	C	I	C	C	-	I
Polyurea*	I	I	I	I	C	I	I	I	I	-

B = Borderline Compatibility

C = Compatible

I = Incompatible

\* Standard

## LUBRICATION SCHEDULE / INSTRUCTIONS

SYNC. RPM	FRAME SERIES	SERVICE CYCLE* - BALL BEARING**	
		8 HR/DAY OPERATION	24 HR/DAY OPERATION
3600	360-5800	150 DAYS (1200 HRS)	50 DAYS (1200 HRS)
1800	360	390 DAYS (3120 HRS)	130 DAYS (3120 HRS)
	400-440	270 DAYS (2160 HRS)	90 DAYS (2160 HRS)
	5000-5800	210 DAYS (1680 HRS)	70 DAYS (1680 HRS)
1200	360-440	390 DAYS (3120 HRS)	130 DAYS (3120 HRS)
	5000-5800	270 DAYS (2160 HRS)	90 DAYS (2160 HRS)

- LUBRICATE BEARINGS WITH POWER IN THE OFF CONDITION.
- CLEAR AND CLEAN THE GREASE FITTINGS AND SURROUNDING AREA.
- REMOVE THE PIPE PLUG FROM THE VENTING PORT OPPOSITE THE GREASE FITTING.
- USING A LOW PRESSURE GREASE GUN APPLY 1 OZ. (30 GRAMS) OF GREASE AT EACH FITTING. DO NOT OVERGREASE.
- WITH THE VENT PORTS OPEN, OPERATE THE MOTOR FOR A MINIMUM OF 15 MINUTES AND UNTIL ANY GREASE FLOW HAS CEASED AT THE VENTING PORTS.
- REMOVE POWER.
- REPLACE THE VENT PIPE PLUGS.
- REPLACE ANY AND ALL GUARDS AND COVERS THAT MAY HAVE BEEN REMOVED TO ACCESS THE MOTOR.

\* LUBRICATION SCHEDULE FOR SEVERE SERVICE (VIBRATION, SHOCK AND/OR ENVIRONMENTAL EXTREME) = 1/3 OF THE ABOVE INTERVALS.

\*\* LUBRICATION SCHEDULE FOR ROLLER BEARINGS = 1/3 OF ABOVE INTERVALS.

THE FACTORY INSTALLED, RECOMMENDED LUBRICANT IS LISTED ON THE MOTOR DATA PLATE. THIS IS A POLYUREA GREASE, AS ARE THE PRODUCTS LISTED BELOW. THE INTRODUCTION OF LUBRICANTS OF ALTERNATE CHEMICAL MAKEUP IS NOT RECOMMENDED AND WILL CAUSE MECHANICAL FAILURE WITHOUT THE COMPLETE PURGE OF THE FACTORY PRODUCT FROM THE BEARING AND RESERVOIR. WHEREVER POSSIBLE, APPLY THE POLYUREA PRODUCT.

CHEVRON OIL CO. - SRI#2      MOBILE POLYREX EM

Figure 36

### TROUBLESHOOTING GUIDE

Successful problem solving requires an organized approach to define the problem, identify the cause, and make the proper correction. Sometimes it is possible that two relatively obvious problems combine to provide a set of symptoms that can mislead the troubleshooter. Be aware of this possibility and avoid solving the "wrong problem".

#### ABNORMAL OPERATION ANALYSIS and CORRECTION

Four logical steps are required to analyze an operational problem effectively and make the necessary corrections:

1. Define the problem and its limits.
2. Identify all possible causes.
3. Test each cause until the source of the problem is found.
4. Make the necessary corrections.

The first step in effective problem solving is to define the limits of the problem. If, for example, the compressor periodically experiences high oil temperatures, do not rely on this observation alone to help identify the problem. On the basis of this information the apparent corrective measure would appear to be a readjustment of the liquid injection system. Lowering the equalizing pressure on the thermal expansion valve would increase the refrigerant feed and the oil temperature should drop.

If the high oil temperature was the result of high suction superheat, however, and not just a matter of improper liquid injection adjustment, increasing the liquid feed could lead

to other problems. Under low load conditions the liquid injection system may have a tendency to overfeed. The high suction superheat condition, moreover, may only be temporary. When system conditions return to normal the unit's liquid injection will overfeed and oil temperature will drop. In solving the wrong problem a new problem was created.

When an operating problem develops, compare all operating information on the MAIN OPERATING SCREEN with normal operating conditions. If an Operating Log has been maintained the log can help determine what constitutes normal operation for the compressor unit in that particular system.

The following list of abnormal system conditions can cause abnormal operation of the RWF II compressor unit:

1. Insufficient or excessive refrigeration load.
2. Excessively high suction pressure.
3. Excessively high suction superheat.
4. Excessively high discharge pressure.
5. Inadequate refrigerant charge or low receiver level.
6. Excessively high or low temperature coolant to the oil cooler.
7. Liquid return from system (slugging).
8. Refrigerant underfeed or overfeed to evaporators.
9. Blocked tubes in water-cooled oil cooler from high mineral content of water.
10. Insufficient evaporator or condenser sizing.

- 11. Incorrect refrigerant line sizing.
- 12. Improper system piping.
- 13. Problems in electrical service to compressor unit.
- 14. Air and moisture present in the system.

Make a list of all deviations from normal plant operation and normal compressor unit operation. Delete any items which do not relate to the symptom and separately list those items that might relate to the symptom. Use the list as a guide to further investigate the problem.

The second step in problem solving is to decide which items on the list are possible causes and which items are additional symptoms. High discharge temperature and high oil temperature readings on a display may both be symptoms of a problem and not casually related. High suction superheat or a low receiver level, however, could cause both symptoms.

The third step is to identify the most likely cause and take action to correct the problem. If the symptoms are not relieved move to the next item on the list and repeat the procedure until you have identified the cause of the problem. Once the cause has been identified and confirmed make the necessary corrections.

### SERVICING THE COLD-START VALVE




Figure 37 - Cold-Start Valve

Before beginning to disassemble the valve, the refrigerant must be removed from all associated piping.

Start room ventilation and put on a safety mask.



**WARNING** Be extremely careful when dismantling the cold-start valve on the discharge side of the unit, as condensed refrigerant often is trapped between the cold-start valve and the stop valve. A bleed valve on the side of the check valve is used to vent the space between the check valve and stop valve. Exposure to refrigerant fumes can cause injury or death.



**WARNING** Inside the valve (see Figure 37) there is a very heavy, tight spring (15). Provided the valve is intact, the spring presents no danger when dismantling. The spring is compressed with a large bolt (7). If it is necessary to repair the valve, it can be dismantled as follows:

1. To manually open the valve, mount the hexagon screw (29), the hexagon flange nut (28) and the nylon ring (27) as shown. Tighten the nut (28) a few turns, in order to redraw the valve cone from the seat.

**NOTE: Step 1 is not strictly necessary when dismantling the valve, but will prevent the valve seat gasket from being exposed to a shear load, and it will keep all internal valve parts together as a unit.**

2. Loosen the screws (24) by 0.315 in (8 mm), and ensure that the bonnet (2) is not under pressure from the spring.

If the bonnet is under pressure from the spring (15) after all the screws have been loosened by 0.315 in (8 mm), there is a damage inside the valve. In this case, it is important to remove only two screws, one from each side.

In the threaded holes from which the two screws have been removed, insert studs with nuts (see table for size) and turn the nuts down to meet the bonnet (2). Studs must be about the same length as the valve body. Then remove the remaining two screws (24), loosen the nuts on the studs, and carefully ease off the bonnet. All internal parts can then be safely removed. **NOTE: If step 1 was followed, loosen the hexagon nut (28) carefully, holding the hexagon screw (29) in place.**

If the bonnet is not under pressure from the spring, all screws (24) can be removed. The bonnet and all internal parts can now be removed from the valve body.

When internal parts have been taken out of the valve body, the spring can be removed by unscrewing the spring bolt (7).

**NOTE: When assembling the valve, the bonnet gasket (17) must be captured in the groove in the bonnet (2).**

After the bonnet assembly is mounted into the valve housing (1), install and tighten bonnet cap screws (24). The required torque is shown for each valve size in the table below.

#### BONNET CAP SCREW TORQUE VALUES

Valve Size DN (mm)	Torque (Nm)	Valve Size ANSI	Torque (lb-ft)	Screw Size (mm)
65	74	2½"	54	M12
80	44	3"	32	M10
100	74	4"	54	M12
125	183	5"	134	M16
150	183	6"	134	M16
200	370	8"	271	M20

**PRESSURE TRANSDUCERS - TESTING**

1. Shut down the compressor and allow pressures to equalize.
2. Isolate suction transducer PE-4 from the unit and depressurize. Ensure that the transducer has proper voltage for excitation. Measure across the red and black wires (power and DC common) of the transducer. Voltage should be 11.8 to 15 VDC. **NOTE: Recover or transfer all refrigerant vapor, in accordance with local ordinances, before opening to atmosphere.**
3. Measure the voltage of PE-4 on connector P6A (terminals WHT and BLK) on the Analog Board with a digital voltmeter.
4. The voltage reading should be 1.48 VDC to 1.72 VDC at standard atmospheric pressure (14.7 PSIA or 0 PSIG). When checking transducers at higher elevations, an allowance in the readings must be made by subtracting approximately 0.02 VDC per 1000 feet of elevation above sea level. Therefore, if PE-4 is measured at 5000 feet elevation under relatively normal weather conditions, the output voltage should differ by 0.10 VDC to read between 1.38 VDC and 1.62 VDC.
5. Isolate the oil pressure transducer PE-1 from the package and open it to atmosphere.
6. Measure the voltage of PE-1 on connector P5A (terminals WHT and BLK) on the Analog Board.
7. The voltage reading should be between 1.1 VDC and 1.29 VDC at standard atmospheric pressure. PE-1, PE-2, and PE-3 all have a span of 500 PSI as compared to PE-4 with a span of 200 PSI. Therefore, atmospheric pressure changes have a lesser effect which is 0.0067 VDC per 1000 feet of elevation and 0.00067 VDC per 0.1 inch Hg barometric deviation.
8. Isolate transducer PE-2 from the package and depressurize. **NOTE: Recover or transfer all refrigerant vapor, in accordance with local ordinances, before opening to atmosphere.**
9. Measure the voltage of PE-2 on connector P5B (terminals WHT and BLK) on the Analog Board.
10. The voltage reading should be between 1.1 VDC and 1.29 VDC at standard atmospheric pressure (see Step 12).
11. Since the discharge pressure, PE-3, cannot be closed off from its sensing point (code requirements), close all transducers from atmosphere and open them to their sensing points so all transducers can equalize to separator pressure.
12. Measure the voltage of PE-3 on connector P5B (terminals WHT and BLK) on the Analog Board.
13. Measure the voltage of PE-1 on connector P5A (terminals WHT and BLK) on the Analog Board.
14. These two voltages should be within .04 VDC of one another.
15. Test is complete.

**PRESSURE TRANSDUCERS - REPLACEMENT**

1. Shut off control power.
2. Close the applicable transducer isolation valve. **NOTE: To change the discharge pressure transducer (PE-3), it will be necessary to depressurize the entire compressor package. Follow "General Instructions For Replacing Compressor Unit Components" before going to step 3.**

3. Refer to the WIRING HARNESS section, External Transducers for Board #1, to identify the wiring harness connectors.
4. Loosen screw and disconnect wiring harness connector from transducer.
5. Unscrew the transducer using a wrench on the metal hex at the base of the transducer. **DO NOT ATTEMPT TO LOOSEN OR TIGHTEN TRANSDUCERS BY THEIR TOP CASING.**
6. Install new transducer.
7. Reconnect the wiring harness to the transducer.
8. Reopen the transducer isolation valve.
9. Turn on control power.

**NOTE: The Pressure Transducer is factory set. If calibration is required, refer to Analog Calibration Instruction in publication 090-020 M.**

PRESSURE TRANSDUCER CONVERSION DATA				
Sensor Voltage	200 psi		500 psi	
	Range - PSIG*		Range - PSIG*	
	low	high	low	high
1.0	29.92"	9.57"	29.92"	4.1
1.1	29.92"	0.3	29.92"	16.6
1.2	29.92"	5.3	17.10"	29.1
1.3	19.74"	10.3	4.1	41.6
1.4	9.57"	15.3	16.6	54.1
1.5	0.3	20.3	29.1	66.6
1.6	5.3	25.3	41.6	79.1
1.7	10.3	30.3	54.1	91.6
1.8	15.3	35.3	66.6	104.1
1.9	20.3	40.3	79.1	116.6
2.0	25.3	45.3	91.6	129.1
2.1	30.3	50.3	104.1	141.6
2.2	35.3	55.3	116.6	154.1
2.3	40.3	60.3	129.1	166.6
2.4	45.3	65.3	141.6	179.1
2.5	50.3	70.3	154.1	191.6
2.6	55.3	75.3	166.6	204.1
2.7	60.3	80.3	179.1	216.6
2.8	65.3	85.3	191.6	229.1
2.9	70.3	90.3	204.1	241.6
3.0	75.3	95.3	216.6	254.1
3.1	80.3	100.3	229.1	266.6
3.2	85.3	105.3	241.6	279.1
3.3	90.3	110.3	254.1	291.6
3.4	95.3	115.3	266.6	304.1
3.5	100.3	120.3	279.1	316.6
3.6	105.3	125.3	291.6	329.1
3.7	110.3	130.3	304.1	341.6
3.8	115.3	135.3	316.6	354.1
3.9	120.3	140.3	329.1	366.6
4.0	125.3	145.3	341.6	379.1
4.1	130.3	150.3	354.1	391.6
4.2	135.3	155.3	366.6	404.1
4.3	140.3	160.3	379.1	416.6
4.4	145.3	165.3	391.6	429.1
4.5	150.3	170.3	404.1	441.6
4.6	155.3	175.3	416.6	454.1
4.7	160.3	180.3	429.1	466.6
4.8	165.3	185.3	441.6	479.1
4.9	170.3	190.3	454.1	491.6
5.0	175.3	195.3	466.6	504.1
At 0 psig	1.094 V	1.494 V	0.968 V	1.268 V

\* Below 0 PSIG measured in inches of mercury.

## CAPACITY LINEAR TRANSMITTER - SLIDE VALVE

### REPLACEMENT

The Capacity Linear Transmitter is located on the end of the compressor unload cylinder, see Figure 38.

The linear transmitter with hermetic enclosure is based on the inductive measuring principle. It features removable electronics (from the sensor well) eliminating the need to evacuate the compressor for replacement. This type of transmitter is dedicated to capacity control and is not adjustable.

1. Shut off control power.
2. Remove DIN connector plug from transmitter.
3. Loosen cap screws.
4. Remove transmitter unit.
5. Install new transmitter unit.
6. Tighten cap screws.
7. Apply DIN connector plug to transmitter.
8. Turn on control power.

**NOTE:** For calibration instructions, refer to Quantum™ LX Operator's Manual, 090-020 O.




Figure 38 - Capacity Linear Transmitter

### TROUBLESHOOTING THE SENSOR

Ensure that the channel is properly configured on the Calibration or Analog board setup screen for the type sensor being used.

Check that supply voltage to the sensor is 12 - 15 VDC on red and black wire for Channel 14, P7A terminal strip of the Analog Board.

Check for a returning signal of:

- 1-5 VDC for a transducer
- 4-20mA for a linear transmitter
- 0-5 VDC for a Potentiometer
- .273 mA for an ICTD at 0C or ice water

## VOLUME RATIO CONTROL TRANSMITTER - SLIDE STOP

### TROUBLESHOOTING

Confirm the setup of channel 15 on the calibration or analog board #1 setup screen.

Troubleshoot the slide stop linear transmitter on channel 15 of the P7B terminal strip of the analog board in the same manner as the slide valve transmitter.

### REPLACEMENT

The Volume Ratio Control Transmitter is located on the right side of the compressor (facing the shaft) at the inlet end. See Figure 39.

The linear transmitter with hermetic enclosure is based on the inductive measuring principle. It features removable electronics (from the sensor well) eliminating the need to evacuate the compressor for replacement. This type of transmitter is dedicated to volume ratio control and has no user adjustments.

1. Shut off control power.
2. Remove DIN connector plug from transmitter.
3. Loosen set screws.
4. Remove transmitter unit.
5. Install new transmitter unit.
6. Tighten set screws.
7. Apply DIN connector plug to transmitter.
8. Turn on control power.

**NOTE:** For calibration of the volume ratio control unit, refer to the Calibration Instructions in publication 090-021 O for operators or 090-022 O for service technicians.





Figure 39 - Volume Ratio Control Transmitter

## TEMPERATURE SENSOR

### TROUBLESHOOTING

Confirm the setup of the channel on the calibration or analog board #1 setup screen. Is the temperature probe reading bottom end -459°F or top end +463°F? If reading bottom end, the probe or wire(s) to the probe are open or the probe is shorted to ground pulling down the power/excitation. Check the power at the analog board between the + and - of the channel for that probe. In Example, discharge temperature would be Channel 2 on the P4A terminal strip of the analog board. Is there a signal of 12 - 15 vdc? If yes, the probe is

not shorted to ground but is most likely open. Do continuity tests to determine if it is the wiring or the sensor that is open. Correct as necessary.



**Figure 40 - TEMPERATURE TRANSMITTER**

If reading top end, the sensor is being shunted and full signal is coming back to the board. Check the wiring by unplugging the connector at the sensor, disconnecting from the analog board, and doing a continuity test across the wires removed from the board. If this is open, the shunt is in the sensor. It is always a good idea to physically inspect the wiring of the Din Plug.

**REPLACEMENT**

1. Shut off control power.
2. Remove DIN connector plug from transmitter. See Figure 40.
3. Unscrew knurled ring and remove transmitter unit.
4. Apply thermal compound to new sensor assembly, insert into thermal well, and tighten knurled ring.
5. Apply DIN connector plug to transmitter.
6. Turn on control power.

**NOTE: The temperature sensor is factory set. If calibration is required, refer to Calibration Instructions in publication 090-021 O for operators or 090-022 O for service technicians.**

**OIL LEVEL TRANSMITTER**



**This device is static sensitive. Please follow proper ESD procedures when handling.**

**TROUBLESHOOTING**


Are the red indicator lights on at the sensor? If yes, check that 2CR or OLCR is energized and that module 13 of digital board #1 is energized as well as the status of module 13 is ON at the service screen for digital board #1. Correct as necessary. If No, is there oil present in the lower sight glass of the separator? If No, add oil to the separator. If Yes, confirm that 24 VDC is getting to the sensor for excitation. If yes, replace the oil level sensor. If No, check the fuse of wire 1001. If blown, check for shorts of wire 1001; correct and replace the fuse. If the fuse is good, check for 24 VDC immediately upstream of the fuse back to the power supply. Correct as necessary.

**REPLACEMENT**

The Oil Level Transmitter is located on the front of the separator near the bottom/center. See Figure 41.

The linear transmitter with hermetic enclosure is based on the capacitive measuring principle. It features removable electronics (from the sensor well) eliminating the need to evacuate the compressor for replacement. This transmitter is dedicated to oil level control and has no user adjustments.

1. Shut off control power.
2. Remove DIN connector plug from transmitter.
3. Loosen set screws.
4. Remove transmitter unit.
5. Install new transmitter unit.
6. Tighten set screws.
7. Apply DIN connector plug to transmitter.
8. Turn on control power.



**Figure 41 - OIL LEVEL TRANSMITTER**

### TROUBLESHOOTING THE RWF II COMPRESSOR

SYMPTOM	PROBABLE CAUSES and CORRECTIONS
EXCESSIVE NOISE and VIBRATION	<p>Main oil injection valve may be closed. Open valve.</p> <p>Main oil injection valve may be open too far. Adjust.</p> <p>Bearing damage or excessive wear. CONTACT Frick Factor or Frick service.</p> <p>Slide valve/slide stop out of calibration (over- or undercompression)</p> <p>Coupling loose on shaft. Tighten coupling. Replace if damaged.</p> <p>If motor or compressor have been reinstalled, check that installation done according to S70-660 SM</p> <p>Refrigerant flood back. Correct system problem.</p>
SLIDE VALVE and/or SLIDE STOP WILL NOT MOVE	<p>4-way hydraulic control valve failed. Repair or replace.</p> <p>Slide stop indicator rod stuck. Contact Frick Factor or Frick service for assistance.</p> <p>Check both S.V. and S.S. feedback devices for wiring and resistance.</p> <p>Compressor must be running with sufficient oil pressure.</p> <p>Unloader piston stuck. Contact Frick Factor or Frick service for assistance.</p> <p>Slipper seals worn out or damaged. Contact Frick Factor or Frick service for assistance.</p>

**NOTE: Troubleshooting the compressor is limited to identifying the probable cause. If a mechanical problem is suspected contact the Service Department. DO NOT ATTEMPT TO DISASSEMBLE THE COMPRESSOR.**

### TROUBLESHOOTING THE OIL SEPARATION SYSTEM

SYMPTOM	PROBABLE CAUSES and CORRECTIONS
GRADUAL OIL LOSS WITH AN OIL LEVEL IN THE COALESCER SECTION SIGHT GLASS	<p>Maintaining too high an oil level, lower level.</p> <p>Refrigerant carryover or liquid injection overfeeding, correct operation.</p> <p>Loss of suction superheat. Adjust evaporator feeds.</p> <p>Contaminated oil, damaged or not seated coalescer filter elements. Replace oil charge and coalescers.</p> <p>Coalescer return valve closed. Open return valve.</p> <p>Coalescing oil return line strainer blocked. Clean.</p>
RAPID LOSS WITH NO OIL LEVEL IN THE COALESCER SECTION SIGHT GLASS	<p>On shutdown, compressor unit suction check valve did not close. Repair valve.</p> <p>Suction check valve bypass valve open too far to meter flow. Close valve.</p> <p>Coalescers loose or not seated properly. Correct or replace.</p> <p>On economized unit: economizer check valve not working. Repair or replace.</p> <p>Economizer check valve not in automatic position or manually opened. Place in auto position.</p>
SHAFT SEAL LEAKAGE	<p>If leakage exceeds normal allowable rate of 7 drops per minute, replace seal.</p>

**TROUBLESHOOTING THE HYDRAULIC SYSTEM**

SYMPTOM	PROBABLE CAUSES and CORRECTIONS
SLIDE VALVE WILL NOT LOAD OR UNLOAD	<p>Solenoid coils may be burned out. Test and replace if necessary.</p> <p>Valve may be closed. Open hydraulic service valves.</p> <p>Solenoid spool may be stuck or centering spring broken. Replace.</p> <p>Check outputs 2 and 3 and fuses.</p> <p>Check LED on coil. If lit, there is power to the coil. Check coil.</p> <p>Solenoid may be actuated mechanically by inserting a piece of 3/16" rod against armature pin and pushing spool to opposite end. Push A side to confirm unload capability. If valve works, problem is electrical.</p>
SLIDE VALVE WILL LOAD BUT WILL NOT UNLOAD	<p>A side solenoid coil may be burned out. Test and replace if necessary.</p> <p>Dirt inside solenoid valve preventing valve from operating both ways. Clean.</p> <p>Check LED on coil. If lit, valve is functioning mechanically. Problem is electrical.</p> <p>Solenoid may be actuated mechanically by inserting a piece of 3/16" rod against armature pin and pushing spool to opposite end. Push A side to confirm unload capability. If valve works, problem is electrical.</p>
SLIDE VALVE WILL UNLOAD BUT WILL NOT LOAD	<p>A side solenoid coil may be burned out. Test and replace if necessary.</p> <p>Dirt inside solenoid valve preventing valve from operating both ways. Clean.</p> <p>Check LED on coil. If lit, valve is functioning mechanically. Problem is electrical.</p> <p>Solenoid may be actuated mechanically by inserting a piece of 3/16" rod against armature pin and pushing spool to opposite end. Push A side to confirm unload capability. If valve works, problem is electrical.</p>
SLIDE STOP WILL NOT FUNCTION EITHER DIRECTION	<p>Solenoid coils may be burned out. Test and replace if necessary.</p> <p>Solenoid service valves may be closed. Open.</p> <p>Manually actuate solenoid. If slide stop will not move mechanical problems are indicated. Consult Frick factor or Frick service.</p>

**TROUBLESHOOTING THE DEMAND PUMP SYSTEM**

SYMPTOM	PROBABLE CAUSES and CORRECTIONS
PUMP WILL NOT PRODUCE ENOUGH OIL PRESSURE TO START COMPRESSOR	Check pump rotation. Check that service valves are open. Filter cartridges may be blocked. Check PSID across filters. Strainer may be blocked. Clean. Oil pressure regulator set too low or stuck open. Readjust or repair. Pump worn out. Repair or replace.
OIL PRESSURE RAPIDLY DROPS OFF WHEN COMPRESSOR STARTS RESULTS IN COMPRESSOR DIFFERENTIAL ALARM	Main oil injection throttling valve too wide open or oil pressure regulating valve improperly adjusted. Readjust both valves.
OIL PRESSURE FLUCTUATES	Liquid injection overfeeding or refrigerant flood back from system. Make necessary adjustments or corrections
NOISE and VIBRATION	Pump strainer blocked. Clean. Liquid refrigerant overfeed. Adjust liquid injection. Pump worn out. Repair or replace.
GREASE LEAKS FROM VENT PORT	Normal leakage which will cease after initial operation. Black oil leaking
IN THE SIDE OF THE PUMP BODY	from this vent indicates oil seal wear or failure. If leakage exceeds normal allowable rate of 7 drops per minute, replace seal.
OIL PRESSURE DROPS AS HEAD PRESSURE INCREASES	Normal behavior. Set main oil injection and oil pressure for maximum head pressure condition.
MAIN FILTER PSID IS TOO HIGH	Filters clogged with dirt. Replace. Oil is too cold. Allow oil to warm up and check again. Service valve on filter outlet is partially closed. Open valves fully.

**MOTOR and BARE COMPRESSOR REPLACEMENT**

Refer to publication 070-660 SM.






**SHUTDOWN DUE TO IMPROPER OIL PRESSURE (HIGH STAGE and BOOSTER)**

**The compressor must not operate with incorrect oil pressure.**

1. Refer to **CONTROL SETUP - "OIL SETPOINTS DISPLAY"** in publication 090-022 O.






**COMPRESSOR PORT LOCATIONS - RWF II 100/134**

PORT	THREAD SIZE	O-RING
SB-3	1 1/16-12 UN-2B	980A0012K66
SC-5	9/16-18 UNF-2B	980A0012K60
SC-6	9/16-18 UNF-2B	980A0012K60
SC-8	1 1/16-12 UN-2B	980A0012K66
SC-9	9/16-18 UNF-2B	980A0012K60
SC-13	9/16-18 UNF-2B	980A0012K60
SC-14	9/16-18 UNF-2B	980A0012K60
SD-1	1 1/16-12 UN-2B	980A0012K66
SL-1	1 1/16-12 UN-2B	980A0012K66
SL-2	1 1/16-12 UN-2B	980A0012K66
SM-1	1 1/16-12 UN-2B	980A0012K66




**COMPRESSOR PORT LOCATIONS - RWF II 177/222/270**

PORT	THREAD SIZE	O-RING
SB-3	1 1/16-12 UN-2B	980A0012K66
SC-5	9/16-18 UNF-2B	980A0012K60
SC-6	9/16-18 UNF-2B	980A0012K60
SC-8	1 1/16-12 UN-2B	980A0012K66
SC-9	9/16-18 UNF-2B	980A0012K60
SC-11	1 5/16-12 UN-2B	980A0012K69
SC-13	9/16-18 UNF-2B	980A0012K60
SC-14	9/16-18 UNF-2B	980A0012K60
SD-1	1 1/16-12 UN-2B	980A0012K66
SL-1	1 1/16-12 UN-2B	980A0012K66
SL-2	1 1/16-12 UN-2B	980A0012K66
SM-1	1 5/16-12 UN-2B	980A0012K69








**COMPRESSOR PORT LOCATIONS - RWF II 316/399**






PORT	THREAD SIZE	O-RING
SC-5	3/4-16 UNF-2B	980A0012K62
SC-6	9/16-18 UNF-2B	980A0012K60
SC-8	1 5/16-12 UN-2B	980A0012K69
SC-9	9/16-18 UNF-2B	980A0012K60
SC-13	9/16-18 UNF-2B	980A0012K60
SC-14	9/16-18 UNF-2B	980A0012K60
SD-1	1 1/16-12 UN-2B	980A0012K66
SL-1	1 5/16-12 UN-2B	980A0012K69
SL-2	1 5/16-12 UN-2B	980A0012K69
SM-1	1 5/16-12 UN-2B	980A0012K69

**COMPRESSOR PORT LOCATIONS - RWF II 480/546**


PORT	THREAD SIZE	O-RING
SC-5	3/4-16 UNF-2B	980A0012K62
SC-6	9/16-18 UNF-2B	980A0012K60
SC-8	1 1/16-12 UN-2B	980A0012K69
SC-9	9/16-18 UNF-2B	980A0012K60
SC-13	9/16-18 UNF-2B	980A0012K60
SC-14	9/16-18 UNF-2B	980A0012K60
SD-1	1 1/16-12 UN-2B	980A0012K66
SL-1	1 1/16-12 UN-2B	980A0012K69
SL-2	1 1/16-12 UN-2B	980A0012K69
SM-1	1 1/8-12 UN-2B	980A0012K71





**COMPRESSOR PORT LOCATIONS - RWF II 496**





PORT	SIZE
SB-2	3/4-14 NPTF
SB-3	1½-11½ NPTF
SC-3	1/2-14 NPTF
SC-4	1/2-14 NPTF
SC-5	3/8-18 NPTF
SC-6	3/8-18 NPTF
SC-7	1/8-27 NPTF
SC-8	1¼-11½ NPTF
SC-9	1½-11½ NPTF
SC-10	1½-11½ NPTF
SD-1	1/2-14 NPTF
SL-1	1¼-11½ NPTF
SL-2	1¼-11½ NPTF
SM-1	2" SQ FLANGE
ST-1	3/4-14 NPTF
SV-1	3" SQ FLANGE
TW-1	3/4-14 NPTF
SP-1	3/4-14 NPTF




COMPRESSOR PORT LOCATIONS - RWF II 676



PORT	SIZE
SB-2	3/4-14 NPTF
SB-3	1½-11½ NPTF
SC-3	1/2-14 NPTF
SC-4	1/2-14 NPTF
SC-5	3/8-18 NPTF
SC-6	3/8-18 NPTF
SC-7	1/8-27 NPTF
SC-8	1¼-11½ NPTF
SC-9	1½-11½ NPTF
SC-10	1½-11½ NPTF
SD-1	1/2-14 NPTF
SL-1	1¼-11½ NPTF
SL-2	1¼-11½ NPTF
SM-1	2" SQ FLANGE
ST-1	3/4-14 NPTF
SV-1	3" SQ FLANGE
TW-1	3/4-14 NPTF
SP-1	3/4-14 NPTF





**COMPRESSOR PORT LOCATIONS - RWF II 856**




PORT	SIZE
SB-2	3/4-14 NPTF
SB-3	1½-11½ NPTF
SC-3	1/2-14 NPTF
SC-4	1/2-14 NPTF
SC-5	3/8-18 NPTF
SC-6	3/8-18 NPTF
SC-7	1/8-27 NPTF
SC-8	1¼-11½ NPTF
SC-9	1½-11½ NPTF
SC-10	1½-11½ NPTF
SD-1	1/2-14 NPTF
SL-1	1¼-11½ NPTF
SL-2	1¼-11½ NPTF
SM-1	2" SQ FLANGE
ST-1	3/4-14 NPTF
SV-1	3" SQ FLANGE
TW-1	3/4-14 NPTF
SP-1	3/4-14 NPTF

**COMPRESSOR PORT LOCATIONS - RWF II 1080**





PORT	SIZE
SB-2	3/4-14 NPTF
SB-3	1½-11½ NPTF
SC-3	1/2-14 NPTF
SC-4	1/2-14 NPTF
SC-5	3/8-18 NPTF
SC-6	3/8-18 NPTF
SC-7	1/8-27 NPTF
SC-8	1¼-11½ NPTF
SC-9	1½-11½ NPTF
SC-10	1½-11½ NPTF
SD-1	1/2-14 NPTF
SL-1	1¼-11½ NPTF
SL-2	1¼-11½ NPTF
SM-1	2" SQ FLANGE
ST-1	3/4-14 NPTF
SV-1	3" SQ FLANGE
TW-1	3/4-14 NPTF
SP-1	3/4-14 NPTF



SL-2:  
HIGH Vi LIQUID  
INJECTION

ST-1: THERMOWELL SUCTION


SC-5: INLET PRESSURE








**P & I DIAGRAM, LIQUID INJECTION - SINGLE PORT**



**P & I DIAGRAM, LIQUID INJECTION - DUAL PORT**



## PROPER INSTALLATION OF ELECTRONIC EQUIPMENT IN AN INDUSTRIAL ENVIRONMENT

In today's refrigeration plants, electronic controls have found their way into almost every aspect of refrigeration control. Electronic controls have brought to the industry more precise control, improved energy savings, and operator conveniences. Electronic control devices have revolutionized the way refrigeration plants operate today.

The earlier relay systems were virtually immune to radio frequency interference (RFI), electromagnetic interference (EMI), and ground loop currents. Therefore installation and wiring were of little consequence and the wiring job consisted of hooking up the point-to-point wiring and sizing the wire properly. In an electronic system, improper installation will cause problems that may outweigh the benefits of electronic control. Electronic equipment is susceptible to RFI, EMI, and ground loop currents which can cause equipment shutdowns, processor memory and program loss, as well as erratic behavior and false readings. Manufacturers of industrial electronic equipment take into consideration the effects of RFI, EMI, and ground loop currents and incorporate protection of the electronics in their designs. However, these design considerations do not make the equipment immune, so manufacturers require that certain installation precautions be taken to protect the electronics from these effects. All electronic equipment must be viewed as sensitive instrumentation and therefore requires careful attention to installation procedures. These procedures are well known to instrumentation, networking, and other professions but may not be followed by general electricians.

There are a few basic practices that if followed, will minimize the potential for problems resulting from RFI, EMI and/or ground loop currents. The National Electric Code (NEC) is a guideline for safe wiring practices, but it does not necessarily deal with procedures used for electronic control installation. Use the following procedures for electronic equipment installation. These procedures do not override any rules by the NEC, but are to be used in conjunction with the NEC code and any other applicable codes.

With exclusion of the three phase wire sizing, Frick drawing 649D4743 should be used as a reference for properly sizing control wires and other wiring specifications.

Throughout this document the term Electronic Control Panel is used to refer to the microprocessor mounted on the compressor package or a Central Control System panel.

**NOTE: It is very important to read the installation instructions thoroughly before beginning the project. Make sure you have drawings and instructions with your equipment. If not, call the manufacturer and request the proper instructions and drawings. Every manufacturer of electronic equipment should have a knowledgeable staff, willing to answer your questions or provide additional information. Following correct wiring procedures will ensure proper installation and consequently, proper operation of your electronic equipment.**

### WIRE SIZING

Control power supply wires should be sized one size larger than required for amperage draw to reduce instantaneous voltage dips caused by large loads such as heaters, contactors, and solenoids. These sudden dips in voltage can cause the electronic control panel, whether it is a microprocessor, a computer, or a PLC, to malfunction momentarily or cause a complete reset of the control system. If the wire is loaded

to its maximum capacity, the voltage dips are much larger, and the potential of a malfunction is very high. If the wire is sized one size larger than required, the voltage dips are smaller than in a fully loaded supply wire and the potential for malfunction is much lower. The NEC code book calls for specific wire sizes to be used based on current draw. An example of this would be to use #14 gauge wire for circuits up to 15 amps or #12 gauge wire for circuits of up to 20 amps. Therefore, when connecting the power feed circuit to an electronic control panel, use #12 gauge wire for a maximum current draw of 15 amp and #10 wire for a maximum current draw of 20 amp. Use this rule of thumb to minimize voltage dips at the electronic control panel.

### VOLTAGE SOURCE

Selecting the voltage source is extremely important for proper operation of electronic equipment in an industrial environment. Standard procedure for electronic instrumentation is to provide a clean, isolated, separate-source voltage in order to prevent EMI (from other equipment in the plant) from interfering with the operation of the electronic equipment. Connecting electronic equipment to a breaker panel (also known as lighting panels or utility panels) subjects the electronic equipment to noise generated by other devices connected to the breaker panel. This noise is known as electromagnetic interference (EMI). EMI flows on the wires that are common to a circuit. EMI cannot travel easily through transformers and therefore can be isolated from selected circuits. Use a control power transformer of the proper VA rating, usually provided in the compressor drive motor starter, to isolate the electronic control panel from other equipment in the plant that generate EMI. See Figure 42.




Figure 42

## GROUNDING

Grounding is the most important factor for successful operation and is typically the most overlooked. The NEC states that control equipment may be grounded by using the rigid conduit as a conductor. This worked for the earlier relay systems, but it is in no way acceptable for electronic control equipment. Conduit is made of steel and is a poor conductor relative to an insulated stranded copper wire. Electronic equipment reacts to very small currents and must have a proper ground in order to operate properly; therefore, stranded copper grounds are required for proper operation.

For proper operation, the control power ground circuit must be a single continuous circuit of the proper sized insulated stranded conductor, from the electronic control panel to the plant supply transformer (Figure 43). Driving a ground stake at the electronic control may also cause additional problems since other equipment in the plant on the same circuits may ground themselves to the ground stake causing large ground flow at the electronic control panel. Also, running multiple ground conductors into the electronic control panel from various locations can create multiple potentials resulting in ground loop currents. A single ground wire (10 AWG or 8 AWG) from the electronic control panel, that is bonded to the control power neutral at the secondary side of the control power transformer in the starter and then to the 3-phase ground point, will yield the best results.




Figure 43

**NOTE: Structural grounding can also result in multiple ground potentials and is also a relatively poor conductor. Therefore, this is not an acceptable method for proper operation of electronic equipment.**

There must be a ground for the three-phase power wiring. This must be sized in accordance to the NEC and any local codes relative to the highest rated circuit overload protection provided in the circuit. The manufacturer may require a larger ground conductor than what is required by the NEC for proper steering of EMI from sensitive circuits. This conductor must also be insulated to avoid inadvertent contact at multiple points to ground, which could create Ground Loops. In many installations that are having electronic control problems, this essential wire is usually missing, is not insulated, or improperly sized.

NEC size ratings are for safety purposes and not necessarily for adequate relaying of noise (EMI) to earth ground to avoid possible interference with sensitive equipment. Therefore sizing this conductor 1 – 2 sizes larger than required by code will provide better transfer of this noise.

Johnson Controls-Frick® requires that the ground conductor meet the following:

- Stranded Copper
- Insulated
- One size larger than NEC requirements for conventional starters
- Two sizes larger than NEC requirements for VFD starters
- Conduit must be grounded at each end
- This circuit must be complete from the motor to the starter continuing in a seamless manner back to the plant supply transformer (power source).

For Direct Coupled, Package Mounted Starters, the ground between the motor and the starter may need to be made externally (Figure 44). The connection on the starter end must be on the starter side of the vibration isolators. Be certain the connection is metal to metal. Paint may need to be removed to ensure a proper conductive circuit. The use of counter-sunk star washers at the point of connection at each end will maximize metal to metal contact.




Figure 44

## VFD APPLICATIONS

The primary ground conductor that accompanies the three-phase supply must be stranded copper, insulated and two sizes larger than the minimum required by the NEC or any other applicable codes. This is necessary due to the increased generation of EMI which is a characteristic of a VFD output to the motor when compared to a conventional starter.

For VFD applications, isolation of the control power, analog devices, and communications ground from the 3-phase ground within the starter and the electronic control panel may be necessary. This is due to the higher noise (RFI/EMI) levels generated between the VFD output and the motor, relative to a conventional starter. If these grounds are left coupled by a common back-plate in the starter/drive, this noise can be direct coupled to the control power, analog device, and communications grounding and may cause unexplained behavior and possible damage to components.

To install correctly, run a separate, properly sized (10 or 8 AWG typically) insulated ground along with and taken to ground with, the 3-phase ground at the 3-phase supply transformer (plant). This will require that the 3-phase ground and the control power ground be electrically isolated except for the connection at the plant supply transformer.

This style of grounding should steer the noise (EMI/RFI) to earth ground, reducing the potential for it to affect the sensitive equipment, which could occur if the grounds were left coupled. **NOTE: If all other recommendations for grounding are followed, this process should not be necessary.**

## CONDUIT

All national and local codes must be followed for conduit with regard to materials, spacing and grounding. In addition, **Johnson Controls-Frick requirements must be followed where they exceed or match national or local codes. Conversely, there is no allowance for any practices that are substandard to what is required by national or local codes.**

Johnson Controls-Frick conduit requirements:

- For *variable frequency drives* (VFDs) of any type, threaded metallic or threaded PVC-coated metallic is required for both the power feed (line side) from the source and between the VFD output and the motor (load side).
- PVC conduit is acceptable **only** when *VFD rated cable* of the proper conductor size and ground is used. This applies to both the line side and load side of the drive. When VFD rated cable is not used, threaded metallic or threaded PVC-coated metallic must be used.
- When threaded metallic or threaded PVC-coated metallic is used, it must be grounded at both ends.
- When not required to be in metal or other material by national or local codes, conduits for the power feed (3-phase) of constant speed starters may be PVC.
- When not required to be in metal or other material by national or local codes, conduits between a constant speed starter and the motor (3-phase) may be PVC.
- Any unshielded control voltage, signal, analog, or communication wiring that does not maintain 12 inches of separation from any 3-phase conductors for every 33 feet (10 meters) of parallel run must be in metal conduit which will be grounded.

Separation: (0-33 feet, 0-10 meters – 12 inches, .3 meters), (33-66 feet, 10-20 meters – 24 inches, .6 meters)

- Since PVC conduit does absolutely nothing to protect lower voltage lines from the magnetic field effects of higher voltage conductors, running either the lower or the higher voltage lines in PVC, does not reduce these requirements on separation. Only running in metal conduit can relieve these requirements.
- Due to the level of EMI that can be induced onto lower voltage lines when running multiple feeders in a trench, control power, communications, analog, or signal wiring cannot be run in trenches that house multiple conduits/electrical ducts carrying 3-phase power to starters/vfd or motors.

- Control power, communications, analog, or signal wiring should be run overhead (preferred) or in a separate trench. If these lines are not in threaded metallic or threaded PVC-coated metallic, abiding by the separation requirements noted above is necessary.
- Though not recommended, if cable trays are used, *metallic* dividers must be used for separation of conductors of unlike voltages and types (AC or DC).

**NOTE: When in doubt contact the factory or use threaded metallic or threaded PVC coated metallic conduit.**

## WIRING PRACTICES

Do not mix wires of different voltages in the same conduit. An example of this would be the installation of a screw compressor package where the motor voltage is 480 volts and the electronic control panel power is 120 volts. The 480 volt circuit must be run from the motor starter to the motor in its own conduit. The 120 volt circuit must be run from the motor starter control transformer to the electronic control panel in its own separate conduit. If the two circuits are run in the same conduit, transients on the 480 volt circuit will be induced onto the 120 volt circuit causing functional problems with the electronic control panel. Metallic dividers must be used in wire way systems (conduit trays) to separate unlike voltages. The same rule applies for 120 volt wires and 220 volt wires. Also, never run low voltage wires for DC analog devices or serial communications in the same conduit with any AC wiring including 120 volt wires. See Figure 45.




Figure 45

**Never run any wires through an electronic control panel that do not relate to the function of the panel.** Electronic control panels should never be used as a junction box. These wires may be carrying large transients that will interfere with the operation of the control panel. **An extreme example of this would be to run 480 volts from the starter through the electronic control panel to an oil pump motor.**

When running conduit to the electronic control panel, use the access holes (knockouts) provided by the manufacturer. These holes are strategically placed so that the field wiring does not interfere with the electronics in the panel. Never allow field wiring to come in close proximity with the controller boards since this will almost always cause problems.

Do not drill into an electronic control panel to locate conduit connections. You are probably not entering the panel where the manufacturer would like you to since most manufactur-

ers recommend or provide prepunched conduit connections. You may also be negating the NEMA rating of the enclosure. Drilling can cause metal filings to land on the electronics and create a short circuit when powered is applied. If you must drill the panel, take the following precautions:

- First, call the panel manufacturer before drilling into the panel to be sure you are entering the panel at the right place.
- Take measures to avoid ESD (electrostatic discharge) to the electronics as you prep the inside of the Electronic control panel. This can be done by employing an antistatic wrist band and mat connected to ground.
- Cover the electronics with plastic and secure it with masking or electrical tape.
- Place masking tape or duct tape on the inside of the panel where you are going to drill. The tape will catch most of the filings.
- Clean all of the remaining filings from the panel before removing the protective plastic.

When routing conduit to the top of an electronic control panel, condensation must be taken into consideration. Water can condense in the conduit and run into the panel causing catastrophic failure. Route the conduit to the sides or bottom of the panel and use a conduit drain. If the conduit must be routed to the top of the panel, use a sealable conduit fitting which is poured with a sealer after the wires have been pulled, terminated, and the control functions have been checked. A conduit entering the top of the enclosure must have a NEMA-4 hub type fitting between the conduit and the enclosure so that if water gets on top of the enclosure it cannot run in between the conduit and the enclosure. This is extremely important in outdoor applications.

**NOTE: It is simply NEVER a good practice to enter through the top of an electronic control panel or starter panel that does not already have knockouts provided. If knockouts are not provided for this purpose it is obvious this is not recommended and could VOID WARRANTY.**

**Never add relays, starters, timers, transformers, etc. inside an electronic control panel without first contacting the manufacturer.** Contact arcing and EMI emitted from these devices can interfere with the electronics. Relays and timers are routinely added to electronic control panels by the manufacturer, but the manufacturer knows the acceptable device types and proper placement in the panel that will keep interference to a minimum. If you need to add these devices, contact the manufacturer for the proper device types and placement.

**Never run refrigerant tubing inside an electronic control panel.** If the refrigerant is ammonia, a leak will totally destroy the electronics.

**If the electronic control panel has a starter built into the same panel, be sure to run the higher voltage wires where indicated by the manufacturer.** EMI from the wires can interfere with the electronics if run too close to the circuitry.

**Never daisy-chain or parallel-connect power or ground wires to electronic control panels.** Each electronic control panel must have its own control power supply and ground wires back to the power source (Plant Transformer). Multiple electronic control panels on the same power wires create current surges in the supply wires, which may cause controller malfunctions. Daisy-chaining ground wires, taking them to ground at each device, allows ground loop currents to flow between electronic control panels which also causes malfunctions. See Figure 46.




Figure 46

## COMMUNICATIONS

The use of communications such as serial and ethernet in industrial environments are commonplace. The proper installation of these networks is as important to the proper operation of the communications as all of the preceding practices are to the equipment.

Serial communications cable needs to be of the proper gauge based on the total cable distance of the run. Daisy-chaining is the only acceptable style of running the communications cable. While Star Networks may use less cable, they more often than not cause problems and interruptions in communications, due to varying impedances over the varying lengths of cable. Ground or drain wires of the communications cable are to be tied together at each daisy-chain connection and only taken to ground in the central control system panel.

It is important to carefully consider the type of cable to be used. Just because a cable has the proper number of conductors and is shielded does not mean it is an acceptable cable. Johnson Controls-Frick recommends the use of Belden #9829 for RS-422 communications and Belden # 9841 for RS-485 up to 2000 feet (600 Meters) total cable length. Refer to Frick drawing 649D4743 for more detail

**Comm Port Protection:** Surge suppression for the comm ports may not be the best method, since suppression is required to divert excess voltage/current to ground. Therefore, the success of these devices is dependent on a good ground (covered earlier in this section). This excess energy can be quite high and without a proper ground, it will access the port and damage it.

Isolation or Optical Isolation is the preferred comm port protection method. With optical isolation, there is no continuity between the communications cable and the comm port. There is no dependence on the quality of the ground. Be sure to know what the voltage isolation value of the optical isolator is before selecting it. These may range from 500 to 4000 Volts.

Frick® Optical Isolation Kits are offered under part number 639C0133G01. One kit is required per comm port.

## UPS POWER AND QUANTUM™LX PANELS

Johnson Controls, Inc. does not advise nor support the use of uninterrupted power supply systems for use with the Quantum™LX panel. With a UPS system providing shutdown protection for a Quantum panel, the panel may not see the loss of the 3-phase voltage on the motor because the UPS may prevent the motor starter contactor from dropping out. With the starter contactor still energized, the compressor auxiliary will continue to feed an "okay" signal to the Quantum™LX panel. This may allow the motor to be subjected to the fault condition on the 3-phase bus.

A couple of fault scenarios are: 1. The 3-phase bus has power "on" and "off" in a continuous cycle manner which may cause the motor to overheat due to repeated excessive in-rush current experiences. 2. The motor cycling may damage the coupling or cause other mechanical damage due to the repeated high torque from rapid sequential motor "bumps." 3. Prolonged low voltage may cause the motor to stall and possibly overheat before the motor contactor is manually turned off.

Under normal conditions, the loss of 3-phase power will shut down the Quantum™LX panel and it will reboot upon proper power return. If the panel was in "Auto," it will come back and return to running as programmed. If the unit was in "Remote," the external controller will re-initialize the panel and proceed to run as required. If the panel was in "Manual" mode, the compressor will have to be restarted manually after the 3-phase bus fault/interruption has been cleared / restored.

If the local power distribution system is unstable or prone to problems there are other recommendations to satisfy these problems. If power spikes or low or high line voltages are the problem, then a constant voltage (CV) transformer with a noise suppression feature is recommended. Johnson Controls, Inc. can provide these types of transformers for this purpose. Contact Johnson Controls for proper sizing (VA Rating) based on the requirement of the job. If a phase loss occurs, then you will typically get a high motor amp shutdown. If the problem continues, an analysis of the facility's power supply quality may be necessary.

**NOTE: It is very important to read the installation instructions thoroughly before beginning the project. Make sure you have drawings and instructions for the equipment being installed. If not, call the manufacturer to receive the proper instructions and drawings. Every manufacturer of electronic equipment should have a knowledgeable staff, willing to answer your questions or provide additional information. Following correct wiring procedures will ensure proper installation and consequently, proper operation of your electronic equipment.**





## RWF II COMPRESSOR PRESTART CHECKLIST

The following items **MUST** be checked and completed by the installer prior to the arrival of the Frick Field Service Supervisor. Details on the checklist can be found in this manual. Certain items on this checklist will be reverified by the Frick Field Service Supervisor prior to the actual start-up.

### Mechanical Checks

- Package installed according to Frick publication S70-210 IB, Screw Compressor Foundations.
- Confirm that motor disconnect is open
- Isolate suction pressure transducer
- Pressure test and leak check unit
- Evacuate unit
- Remove compressor drive coupling guard
- Remove coupling center and **DO NOT reinstall** (motor rotation must be checked without center)
- Check for correct position of all hand, stop, and check valves **PRIOR** to charging unit with **OIL** or **REFRIGERANT**
- Charge unit with correct type and quantity of oil
- Lubricate electric drive motor bearings **PRIOR** to checking motor rotation
- Check oil pump alignment (if applicable)
- Check for correct economizer piping (if applicable)
- Check separate source of liquid refrigerant supply (if applicable, liquid injection oil cooling)
- Check water supply for water-cooled oil cooler (if applicable, water cooled oil cooling)
- Check thermosyphon receiver refrigerant level (if applicable, thermosyphon oil cooling)
- Check for **PROPER PIPE SUPPORTS** and correct foundation
- Check to ensure **ALL** piping **INCLUDING RELIEF VALVES** is completed

### Electrical Checks

- Package installed according to Frick publication 090-400 SB, Proper Installation of Electrical Equipment In An Industrial Environment.
- Confirm that main disconnect to motor starter and micro is open
- Confirm that electrical contractor has seen this sheet, **ALL PERTINENT WIRING** information, and drawings
- Confirm proper power supply to the starter package
- Confirm proper motor protection (breaker sizing)
- Confirm that all wiring used is stranded copper and is 14 AWG or larger (sized properly)
- Confirm all 120 volt control wiring is run in a separate conduit from all high voltage wiring
- Confirm all 120 volt control wiring is run in a separate conduit from oil pump and compressor motor wiring
- Confirm no high voltage wiring enters the micro panel at any point
- Check current transformer for correct sizing and installation
- Check all point-to-point wiring between the micro and motor starter
- Confirm all interconnections between micro, motor starter, and the system are made and are correct
- Ensure all electrical panels are free from installation debris, METAL PARTICLES, and moisture

### After the above items have been checked and verified:

- Close the main disconnect from the main power supply to the motor starter
- Close the motor starter disconnect to energize the micro
- Manually energize oil pump and check oil pump motor rotation
- Manually energize compressor drive motor and check motor rotation
- Leave micro energized to ensure oil heaters are on and oil temperature is correct for start-up

**Summary: The Frick Field Service Supervisor should arrive to find the above items completed. He should find an uncoupled compressor drive unit (to verify motor rotation and alignment) and energized oil heaters with the oil at the proper standby temperatures. Full compliance with the above items will contribute to a quick, efficient and smooth start-up.**

### The Start-up Supervisor will:

1. Verify position of all valves
2. Verify all wiring connections
3. Verify compressor motor rotation
4. Verify oil pump motor rotation
5. Verify the % of FLA on the micro display
6. Verify and finalize alignment (if applicable)
7. Calibrate slide valve and slide stop
8. Calibrate temperature and pressure readings
9. Correct any problem in the package
10. Instruct operation personnel

**NOTE: Customer connections are to be made per the electrical diagram for the motor starter listed under the installation section and per the wiring diagram listed under the maintenance section of the IOM.**

**Please complete and sign this form & fax to 717-762-8624 as confirmation of completion.**

Frick Sales Order Number: \_\_\_\_\_  
 Compressor Model Number: \_\_\_\_\_  
 Unit Serial Number: \_\_\_\_\_  
 End User Name: \_\_\_\_\_  
 Address of Facility: \_\_\_\_\_  
 City, State, Zip: \_\_\_\_\_

Print Name: \_\_\_\_\_  
 Company: \_\_\_\_\_  
 Job Site Contact: \_\_\_\_\_  
 Contact Phone Number: \_\_\_\_\_  
 Signed: \_\_\_\_\_

## Start-up Report

Frick Order No: \_\_\_\_\_

Sold To: \_\_\_\_\_ Contact Name: \_\_\_\_\_ Date: \_\_\_\_\_  
 End User: \_\_\_\_\_ Contact Name: \_\_\_\_\_ Phone: \_\_\_\_\_  
 End User Address: \_\_\_\_\_ Fax No: \_\_\_\_\_  
 City, State, Zip: \_\_\_\_\_ Start-up Representative \_\_\_\_\_

### Unit General Information

Unit Model # \_\_\_\_\_ Customer Package Identification # \_\_\_\_\_  
 Compressor Serial # \_\_\_\_\_ Separator National Board # \_\_\_\_\_  
 Unit Serial # \_\_\_\_\_ Oil Cooler National Board # \_\_\_\_\_  
 Evaporator National Board # \_\_\_\_\_ Serial # \_\_\_\_\_ Condenser National Board # \_\_\_\_\_ Serial # \_\_\_\_\_  
 Oil Pot National Board # \_\_\_\_\_ H.P. Receiver National Board # \_\_\_\_\_  
 Economizer National Board # \_\_\_\_\_ Suction Accumulator National Board # \_\_\_\_\_  
 Refrigerant \_\_\_\_\_ Oil Filters \_\_\_\_\_ Lube Oil Type \_\_\_\_\_ Design Operating Conditions  
 Oil Cooling \_\_\_\_\_ ° Suct. / \_\_\_\_\_ ° Disch.

### Micro Information

Micro Type \_\_\_\_\_ Program Software Ver # \_\_\_\_\_ and Date \_\_\_\_\_ UL Serial # \_\_\_\_\_  
 Digital I/O Board #1 Serial # \_\_\_\_\_ Software Ver # \_\_\_\_\_ and Date \_\_\_\_\_  
 Digital I/O Board #2 Serial # \_\_\_\_\_ Software Ver # \_\_\_\_\_ and Date \_\_\_\_\_  
 Analog Board #1 Serial # \_\_\_\_\_ Software Ver # \_\_\_\_\_ and Date \_\_\_\_\_  
 Analog Board #2 Serial # \_\_\_\_\_ Software Ver # \_\_\_\_\_ and Date \_\_\_\_\_

### Compressor Motor Starter / Drive Information

Manufacturer \_\_\_\_\_ Part # \_\_\_\_\_ Model # \_\_\_\_\_  
 Starter Type \_\_\_\_\_ Serial # \_\_\_\_\_  
 Input Voltage \_\_\_\_\_ Voltage Range \_\_\_\_\_ Phase \_\_\_\_\_ Hz \_\_\_\_\_ Current \_\_\_\_\_  
 Output Voltage \_\_\_\_\_ Phase \_\_\_\_\_ Hz \_\_\_\_\_ Max FLA \_\_\_\_\_ Max LRA \_\_\_\_\_ Min Load FLA \_\_\_\_\_ Job FLA \_\_\_\_\_  
 Logic Board Serial # \_\_\_\_\_ U33 Prog. Ver. \_\_\_\_\_ Date \_\_\_\_\_ P/N \_\_\_\_\_  
 U34 Prog. Ver. \_\_\_\_\_ Date \_\_\_\_\_ P/N \_\_\_\_\_  
 U45 Prog. Ver. \_\_\_\_\_ Date \_\_\_\_\_ P/N \_\_\_\_\_  
 Harmonic Filter Serial # \_\_\_\_\_ Prog. Ver. \_\_\_\_\_ Date \_\_\_\_\_ P/N \_\_\_\_\_  
 Frick Interface Serial # \_\_\_\_\_ Prog. Ver. \_\_\_\_\_ Date \_\_\_\_\_ P/N \_\_\_\_\_  
 CT Location Checked  CT Phase \_\_\_\_\_ CT Ratio \_\_\_\_\_ Transition Time \_\_\_\_\_ DBS Ver.# \_\_\_\_\_

### Oil Pump Information

Pump Mfg. \_\_\_\_\_ Model # \_\_\_\_\_ Serial # \_\_\_\_\_ Motor Mfg. \_\_\_\_\_ H.P. \_\_\_\_\_  
 Motor RPM \_\_\_\_\_ Service Factor \_\_\_\_\_ Volt \_\_\_\_\_ HZ \_\_\_\_\_ FLA \_\_\_\_\_ Design \_\_\_\_\_ Code \_\_\_\_\_ Starter Size \_\_\_\_\_

### Cooling Fan Information

Motor HP \_\_\_\_\_ RPM \_\_\_\_\_ Service Factor \_\_\_\_\_ Volt \_\_\_\_\_ Hz \_\_\_\_\_ FLA \_\_\_\_\_ Cooling Fans \_\_\_\_\_

### Special Options

\_\_\_\_\_  \_\_\_\_\_  \_\_\_\_\_  \_\_\_\_\_

### Prestart Checks

- |   |   |   |
|---|---|---|
| <input type="checkbox"/> Installation, Foundation   | <input type="checkbox"/> Compressor PHD Setup               | <input type="checkbox"/> Coolant Installed            |
| <input type="checkbox"/> Position of all valves   | <input type="checkbox"/> Motor PHD Setup                    | <input type="checkbox"/> 4-20 Coolant Loop Pump Setup |
| <input type="checkbox"/> Proper oil charge  | <input type="checkbox"/> Motor Winding RTD's Setup          | <input type="checkbox"/> Coolant Loop Temp Setup      |
| <input type="checkbox"/> All wiring connections   | <input type="checkbox"/> Motor Bearing RTD's Setup          | <input type="checkbox"/> Cooling Fan Motor I/O Setup  |
| <input type="checkbox"/> Starter Cleanliness  | <input type="checkbox"/> Motor Temperature Thermistor Setup | <input type="checkbox"/> Cooling Fan Rotation Checked |
| <input type="checkbox"/> All micro settings   | <input type="checkbox"/> 4-20 Motor Drive Signal Calibrated | <input type="checkbox"/> Oil pump motor rotation      |
| <input type="checkbox"/> 4-20 CT Channel 16 Setup   | <input type="checkbox"/> Cold alignment                     | <input type="checkbox"/> Motor rotation               |
| <input type="checkbox"/> 4-20 Output Calibration - Liquid Makeup Valve, Coolant Temp Valve, Economizer Makeup Valve |   |   |

### Configuration

Capacity	Channel	Direction	Package
Mode 1 _____	_____	_____	Compressor _____
Mode 2 _____	_____	_____	Pump _____
Mode 3 _____	_____	_____	Dual Pump _____
Mode 4 _____	_____	_____	Drive _____
VFD Hi & Low PI Control	_____	_____	Refrigerant _____ K-Factor _____
<b>Miscellaneous</b>			Filter _____
Sequencing _____			PowerPac _____
Condenser _____			
Screen Saver _____			

Page 2 Unit Serial # \_\_\_\_\_ Frick Order No: \_\_\_\_\_

Mode _____ Capacity Control Setpoints				Mode _____			
Setpoint _____		Regulation Safeties		Setpoint _____		Regulation Safeties	
High	Low	Load Inhibit		High	Low	Load Inhibit	
Prop. Band _____	_____	Force Unload _____		Prop. Band _____	_____	Force Unload _____	
Dead Band _____	_____	Warning _____		Dead Band _____	_____	Warning _____	
Cycle Time _____ Sec	_____ Sec	Warning Delay _____ Sec		Cycle Time _____ Sec	_____ Sec	Warning Delay _____ Sec	
VFD Prop Band _____	_____	Shutdown _____		VFD Prop Band _____	_____	Shutdown _____	
VFD Integ. Time _____ Sec	_____ Sec	Shutdown Delay _____ Sec		VFD Integ. Time _____ Sec	_____ Sec	Shutdown Delay _____ Sec	
Channel _____				Channel _____			
<b>Auto Cycle</b>		<b>Low Suction</b>		<b>Auto Cycle</b>		<b>Low Suction</b>	
Start _____		Load Inhibit _____		Start _____		Load Inhibit _____	
Start Delay _____ Min		Force Unload _____		Start Delay _____ Min		Force Unload _____	
Stop _____		Warning _____		Stop _____		Warning _____	
Stop Delay _____ Min		Warning Delay _____ Sec		Stop Delay _____ Min		Warning Delay _____ Sec	
		Shutdown _____				Shutdown _____	
		Shutdown Delay _____ Sec				Shutdown Delay _____ Sec	

Compressor Safeties			
<b>High Discharge Temperature</b>			
Load Inhibit _____			
Force Unload _____			
Warning _____			
Warning Delay _____ Sec			
Shutdown _____			
Shutdown Delay _____ Sec			
<b>High Discharge Pressure</b>		<b>Dual Mode</b> _____	
Regulation Modes 1 & 3 _____	Modes 2 & 4 _____		
Load Inhibit _____ PSIG	_____ PSIG		
Force Unload _____ PSIG	_____ PSIG		
Warning _____ PSIG	_____ PSIG		
Warning Delay _____ Sec	_____ Sec		
Shutdown _____ PSIG	_____ PSIG		
Shutdown Delay _____ Sec	_____ Sec		
Maximum Discharge Pressure _____ PSIG			
Highest Cap. To Permit Start _____ %			
Start Period Before Cap. Increase _____			
Stopping Period For Cap. Unload _____			
Compressor Auto Mode Min. Cap. _____ %			
Capacity Unload Assist. _____ Rate _____ %			
Separator Velocity Ref. _____			
Compression Ratio _____			
Liquid Slug Warning _____			
Liquid Slug Shutdown _____			
		<b>High Suction Pressure</b>	
		Load Inhibit _____ PSIG	
		Force Unload _____ PSIG	
		Warning _____ PSIG	
		Warning Delay _____ Sec	
		Shutdown _____ PSIG	
		Shutdown Delay _____ Sec	
		<b>Economizer</b> _____	
		On When Above _____ %	
		Off When Below _____ %	
		Override Discharge Pressure _____	
		Port Value _____	
		Pressure Input _____	
		Fixed Pressure Setpoint _____	
		Balance Piston	
		On _____ %	
		Off _____ %	
		Ignore Delay _____ Min	
		Fail Delay _____ Min	
		Oil Log _____ Delay _____ Sec.	
		Main Oil Injection On When Discharge Temperature Is Above _____ °F for _____ Sec	

Package Safeties			
<b>Low Compressor Oil Temperature</b>			
Warning _____ Delay _____ Sec			
Shutdown _____ Delay _____ Sec			
<b>High Compressor Oil Temperature</b>			
Warning _____ Delay _____ Sec			
Shutdown _____ Delay _____ Sec			
<b>Low Compressor Oil Pressure</b>			
Warning _____ PSI Delay _____ Sec			
Shutdown _____ PSI Delay _____ Sec			
<b>High Filter Pressure</b>			
Warning _____ PSI Delay _____ Min			
Shutdown _____ PSI Delay _____ Min			
<b>Main Oil Injection</b>			
Shutdown _____ PSI Delay _____ Sec			
<b>Oil Heater Off Above</b> _____ Sec			
<b>High Level Shutdown Delay</b> _____ Sec			
<b>Low Oil Level Delay</b> _____ Sec			
<b>Oil Pump Lube Time Before Starting</b> _____ Sec			
<b>Dual Pump Transition Time</b> _____ Sec			
<b>Pull Down</b> _____			
Capacity Position _____ %			
Amount of Time _____ Sec			
<b>Pump Down</b> _____			
On When Suction Above _____ PSIG Delay _____ Min			
<b>DX Circuit</b>			
<b>#1 Action</b> _____			
Off When Below _____ %			
On When Above _____ %			
<b>#2 Action</b> _____			
Off When Below _____ %			
On When Above _____ %			
<b>Liquid Injection</b> _____			
On When Above _____ Delay _____ Sec			
Dual Port Transition _____			
<b>Hot Gas Bypass</b> _____ %			
<b>Power Assist</b> _____ Sec			

Page 3

Unit Serial # \_\_\_\_\_ Frick Order No: \_\_\_\_\_

**Compressor Motor Setpoints and Information**

<b>Motor Name Plate</b>	<b>VFD</b>	Manufacturer _____
Motor Amps _____	Maximum Drive Output ____ %	Frame Size _____
Volts _____	Minimum Drive Output ____ %	H.P. _____
Service Factor _____	<b>Remote Control</b>	RPM _____
Horsepower _____	Rate Of Increase _____ % Delay ____ Sec	Serial # _____
CT Factor _____	Rate Of Decrease _____ % Delay ____ Sec	Service Factor _____
<b>Recycle Delay</b> _____ Min	<b>Capacity Control</b>	Voltage _____
<b>High Motor Amps</b>	When Slide Valve Reaches _____ %	Hz _____
Load Inhibit _____	Drive Speed Reaches _____ %	Design _____
Force Unload _____	<b>Variable Speed Min. Slide Valve Position</b> _____ %	Code _____
Warning _____ Delay ____ Sec	<b>Skip Frequency Bands</b>	Bearing Type _____
Shutdown _____ Delay ____ Sec	<b>Bottom</b> _____	Motor Coupling _____
	<b>Top</b> _____	
	_____	
	_____	
<b>Low Motor Amps</b>		
Shut Down _____ Delay ____ Sec		
Confirmed Running Motor Amps _____		
Starting Motor Amps Ignore Period _____ Sec		

**Vyper Coolant Setpoints**

Vyper Standby Time \_\_\_\_\_ Vyper Coolant Low Temp. Alarm \_\_\_\_\_ Delay \_\_\_\_\_ Shutdown \_\_\_\_\_ Delay \_\_\_\_\_  
 High Temp. Alarm \_\_\_\_\_ Delay \_\_\_\_\_ Shutdown \_\_\_\_\_ Delay \_\_\_\_\_

**PHD Monitoring Setpoints** **Condenser Control**

<b>Compressor Bearing</b>		<b>Condenser Control Setpoint</b>
<b>Suction End</b> _____ Delay _____	<b>Discharge End</b> _____ Delay _____	<b>Digital Controls</b> _____ <b>Step Order</b> _____
High Warning _____ gF _____ Sec	High Warning _____ gF _____ Sec	Module A _____
High Shutdown _____ gF _____ Sec	High Shutdown _____ gF _____ Sec	Module B _____
		Module C _____
<b>Motor Bearing</b> _____		Module D _____
		Step Up Dead Band _____ PSI
<b>Shaft Side</b> _____ Delay _____	<b>Opposite Shaft Side</b> _____ Delay _____	Step Up Delay _____ Sec
High Warning _____ F _____ Sec	High Warning _____ F _____ Sec	Step Down Dead Band _____ PSI
High Shutdown _____ F _____ Sec	High Shutdown _____ F _____ Sec	Step Down Delay _____ Sec
		High Pressure Override _____ PSI
<b>Motor Stator</b> _____		High Pressure Override Delay _____ Sec
<b>Stator 1</b> _____ Delay _____	<b>Stator 2</b> _____ Delay _____	<b>Analog Controls</b> Analog Output A _____
High Warning _____ F _____ Sec	High Warning _____ F _____ Sec	Analog Output B _____
High Shutdown _____ F _____ Sec	High Shutdown _____ F _____ Sec	Proportional Band _____ PSI
		Integration Time _____ Sec
<b>Stator 3</b> _____ Delay _____		High Limit _____ PSI
High Warning _____ F _____ Sec		Low Limit _____ Sec
High Shutdown _____ F _____ Sec		

**Miscellaneous**

Remote Capacity Deadband \_\_\_\_\_ %  
 High Compressor Oil Pressure \_\_\_\_\_  
 Shutdown \_\_\_\_\_ PSI Delay \_\_\_\_ Sec  
 Max Slide Valve Timer \_\_\_\_\_ 1/10 Sec  
 Max Discharge Pressure \_\_\_\_\_ PSI  
 Max Discharge and Oil Temp \_\_\_\_\_ °F



Page 4 Unit Serial # \_\_\_\_\_ Frick Order No: \_\_\_\_\_

**P&ID Setpoints**

Name	_____	_____	_____	_____
Control	_____	_____	_____	_____
Action	_____	_____	_____	_____
Control Point	_____	_____	_____	_____
Device Source	_____	_____	_____	_____
Device Channel	_____	_____	_____	_____
Setpoint	_____	_____	_____	_____
Dead Band	_____	_____	_____	_____
Prop. Band	_____	_____	_____	_____
Integral Gain	_____	_____	_____	_____

**Communications**

<b>Compressor ID</b> _____			
<b>Comm 1</b>	<b>Comm 2</b>	<b>Comm 3</b>	
Baud Rate _____	Baud Rate _____	Baud Rate _____	
Data Bits _____	Data Bits _____	Data Bits _____	
Stop Bits _____	Stop Bits _____	Stop Bits _____	
Parity _____	Parity _____	Parity _____	
RS 485 Connection _____	RS 485 Connection _____	RS 485 Connection _____	
Protocol _____	Protocol _____	Protocol _____	Use Map File _____

**Ethernet**

<b>IP Data</b>	<b>Naming Data</b>	<b>Protocols</b>
Address Type _____	Host Name _____	ModBus TCP _____
IP Address _____	Work Group _____	Ethernet I/P _____
Gateway Address _____	Comments _____	Profinet _____
Subnet Mask _____		
Web Server Port _____		

Compressor Operating Log Sheet				Starter Operating Log Sheet			
Date				Average Current			
Time				Current Phase A			
Hour Meter Reading				Current Phase B			
Equip. Room Temp.				Current Phase C			
Suction Pressure				Full Load Amps			
Suction Temperature				Output Frequency			
Suction Superheat				Output Voltage			
Discharge Pressure				DC Bus Voltage			
Discharge Temperature				Input Power kW			
Corresponding Temperature				Actual Speed			
Oil Pressure				Speed Command			
Oil Temperature				Ambient Temp F.			
Oil Filter Pressure Drop				Convert Heatsink Temp. F.			
Separator Temperature				Baseplate Temp. F.			
Slide Valve Position				VSD Operating Mode			
Volume Ratio (VI)				Harmonic Filter Present			
Motor Amps / FLA %				Harmonic Filter Mode			
Capacity Control Setpoint				Water Pump Energized			
Oil Level				Precharge Relay Energized			
Oil Added				Trigger SCR's Energized			
Seal Leakage (Drops/Min.)				DC Inverter Link Current			
Evaporator. EWT F.				Motor Winding Temp. F.			
Evaporator LWT F.				Humidistat % RH			
Condenser EWT F.				Vyper Coolant Temp. F.			
Condenser LWT F.				Total kWh			


## VIBRATION DATA SHEET

Date: \_\_\_\_\_  
End User: \_\_\_\_\_  
Address: \_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_

Sales Order Number: \_\_\_\_\_  
Installing Contractor: \_\_\_\_\_  
Service Technician: \_\_\_\_\_

Equipment ID (As in Microlog): \_\_\_\_\_  
Compressor Model Number: \_\_\_\_\_  
Compressor Serial Number: \_\_\_\_\_  
Unit Serial Number: \_\_\_\_\_  
National Board Number: \_\_\_\_\_  
Running Hours: \_\_\_\_\_  
Manufacturer and Size of Coupling: \_\_\_\_\_  
Motor Manufacturer: RAM \_\_\_\_\_  
Motor Serial Number: \_\_\_\_\_  
RPM: \_\_\_\_\_ Frame Size: \_\_\_\_\_ H.P. \_\_\_\_\_  
Refrigerant: \_\_\_\_\_  
Ambient Room Temperature: \_\_\_\_\_ °F  
Operating Conditions:

SUCTION		DISCHARGE		OIL		SEPARATOR		Slide Valve Position	%
Press	#	Press	#	Press	#	Temp	°F	V.I. Ratio	
Temp	°F	Temp	°F	Temp	°F			F.L.A.	%



# Index

## Symbols

3-phase ground, 54  
3-phase supply, 54

## A

Abnormal Operation Analysis and Correction, 33  
across-the-line, 12  
atmospheric pressure, 25,26  
axial loads, 14  
axial load bearings, 14

## B

back-feeding, 22  
back flushing, 10  
back-pressure regulator, 11  
back-pressure regulator valve, 10,11  
balance piston, 14,22  
Balance Piston Pressure Regulator, 30  
balancing load, 11  
bleed valve, 25  
booster application, 12,15  
booster compressor, 22  
booster systems, 22  
BP, 16  
BP coupling data table, 6  
BPR valve, 11  
brownouts, 13

## C

cable trays, 54  
CH Coupling Data Table, 7  
check valve, 11,22  
chemical cleaning process, 9  
circuit breaker, 12  
circuit breaker disconnect, 12  
clamping bolts, 7  
closed-loop fluids, 9  
closed-loop system, 9  
coalescer filter element, 15,26  
coalescer filter retainer, 26  
codes, 54  
Cold-Start System, 15  
cold-start valve, 15,34  
Comm Port Protection, 56  
Communications, 56  
Compressor  
  compressor, 11  
  discharge, 15  
  drive shaft, 14  
  hydraulic system, 16  
  lubrication, 15  
  motor, 11,12  
  oil temperature, 16  
  suction, 16  
  Vi, 16  
Compressor Operating Log Sheet, 62  
Compressor Port Locations, 41  
condenser, 15  
condenser inlet, 8

condensing pressure, 8  
condensing temperature, 8  
Conduit, 54  
cone/button, 8  
constant speed starters, 54  
control power regulator, 13  
control power transformer, 12  
control transformer, 12  
coolers, 5  
cooling tower water, 9  
cooling water, 9  
coupling, 11  
Coupling Data Table, 6  
coupling hubs, 6  
CPT, 12  
crane, 5  
CT, 12  
CT ratio, 13  
Current Transformer, 12  
cutout parameters, 15  
cycle time, 16

## D

Daisy-chaining, 56  
"D" Flange adapter, 14  
dead band, 16  
demand oil pump strainer, 25  
Demand Pump  
  Assembly, 28  
  ball bearing, 27  
  single row ball bearing, 28  
  bearing retainer washer, 27,28  
  bearing spacer, 27,28  
  bearing spacer collar, 29  
  carbon-graphite bushings, 27,28,29  
  casing, 27  
  demand pump, 14,15  
  Disassembly, 27  
  End Clearance, 29  
  idler, 27  
  idler pin, 27,28  
  lip seal, 27,29  
  Mechanical Seal, 28  
  O-ring gasket, 28  
  Preventative Maintenance  
    end clearance, 30  
    end clearance adjustment, 30  
    grease, 30  
    lubrication, 30  
    packing adjustment, 30  
  pump head, 28  
  refrigeration oil, 28  
  seal face, 28  
  seal seat, 28  
  seal spring, 28  
  shaft snap ring, 28  
  snap ring, 27,28  
  tapered installation sleeve, 28  
  thrust-bearing assembly, 27,29  
  Thrust Bearing Adjustment, 29  
  Troubleshooting

bent shaft, 30  
cavitating, 30  
cavitation, 29  
Discharge Port, 29  
Discharge pressure, 30  
discharge valve, 30  
Fluttering, 29,30  
Gate valve, 29  
Grease leaks from vent port, 40  
High viscosity, 29  
Insufficient oil pressure, 40  
jumping, 29  
Main filter PSID too high, 40  
misalignment, 29,30  
Noise and Vibration, 40  
Oil pressure drops as head pressure increases, 40  
Oil pressure fluctuates, 40  
Oil pressure rapidly drops, 40  
Pressure Gauge, 29  
Relief valve, 29  
Relief valve poppet, 30  
Starving, 30  
Strainer, 30  
suction port, 29  
Suction valve, 30  
vacuum gauge, 29  
Vibrating, 30  
Viking Pump, 27  
demand pump, 14,15  
disc-type check valves, 11  
discharge check valve, 15,22  
discharge pressure, 14  
disconnect switches, 24  
disc drive spacer, 6  
disc packs, 6  
double-acting hydraulic cylinders, 16  
Double-Acting Mode, 16  
double-acting solenoid valve, 17  
drain valve, 25  
drive coupling, 22  
drive hubs, 6  
dry nitrogen, 7,24  
dual-port liquid injection, 16  
dual-setpoint, 11  
dual dip tube method, 9  
dual oil filters, 14  
DX economizer, 10  
DX vessel, 11

## E

Economizer  
  back-pressure regulator valve, 10,11  
  balancing load, 11  
  BPR valve, 11  
  check valve, 11  
  DX economizer, 10  
  DX vessel, 11  
  economizer port, 10,11  
  economizer vessel, 11  
  electric shutoff option, 11

flashing liquid, 10  
 flash economizer system, 10  
 flash gas, 11  
 flash tank, 10  
 flash vapor, 11  
 heat exchanger, 10  
 isolation valve, 11  
 liquid feed solenoid, 11  
 liquid solenoid, 10  
 microprocessor, 10  
 outlet pressure regulator, 11  
 overpressurizing, 11  
 Packaged Refrigerant Recirculation Unit, 11  
 partial load, 11  
 piston-type check valves, 11  
 port pressure, 10  
 strainer, 11  
 subcooled liquid, 10  
 subcooling, 10  
 suction bypass, 11  
 suction pressure, 11  
 economizer port, 10,11  
 economizer vessel, 11  
 elastomeric gear, 6,7  
 electric shutoff option, 11  
 entrapped refrigerant, 26  
 evaporator, 9  
 external controller, 12  
 external oil cooler, 7  
 External Oil Cooling, 23  
 external strainer, 14  
 EZ-Cool™LIOC  
 analog board #1, 18  
 analog output #1, 18  
 Control Input, 18  
 Control Setpoint, 18  
 Dead Band, 18  
 Delta, 18  
 Derivative Gain, 18  
 discharge temperature, 19  
 Integral Gain, 18  
 Liquid Slugging, 19  
 P11A terminal strip, 18  
 PID #1, 18  
 PID Output value, 18  
 Proportional Band, 18,19  
 Proportional Gain, 18  
 Quantum™LX Control Panel, 18

**F**

filter assembly, 25  
 filter canister, 25  
 filter cartridge, 25  
 filter elements, 7  
 fixed bulkhead, 16  
 flashing liquid, 10  
 flash economizer system, 10  
 flash gas, 11  
 flash tank, 10  
 flash vessel, 10,11  
 float level control, 9  
 forklift, 5

Foundation, 5,14  
 Foundation  
 Anchor bolts, 5  
 epoxy grout, 5  
 grout, 5  
 housekeeping pads, 5  
 I-beams, 5  
 reinforced concrete, 5  
 foundation, 5  
 Freeze-up protection, 22

**G**

gas bypassing, 14  
 gas compression, 5  
 gas flow, 15  
 gas outlet connection, 15  
 gauges, 7  
 General Maintenance, 24

**H**

hard water conditions, 9  
 heat exchanger, 9,10  
 helical rotors, 14  
 high-frequency vibrations, 5  
 high pressure discharge gas, 22  
 high stage applications, 15  
 Holding-charge, 7  
 Hot oil, 8  
 hydraulic cylinder, 16  
 Hydraulic System  
 compressor suction, 16  
 Compressor Vi, 16  
 cycle time, 16  
 dead band, 16  
 double-acting hydraulic cylinders, 16  
 Double-Acting Mode, 16  
 fixed bulkhead, 16  
 hydraulic cylinder, 16  
 microprocessor, 16  
 movable slide stop, 16  
 MSS, 16  
 MSV, 16  
 MSV solenoid, 16  
 Needle Valve, 16  
 proportional band, 16  
 slide valve, 16  
 solenoid valve, 16  
 Vi, 16  
 volume ratio, 16

**I**

identification data plate, 4  
 infinitely variable volume ratio, 14  
 inlet service valve, 25  
 isolation valve, 11

**J**

jack, 5

**K**

keyway setscrews, 6

**L**

leak test, 25  
 level-control method, 9  
 LICO, 17  
 liquid feed solenoid, 11  
 liquid injection, 14,16  
 Alarms, 20  
 analog input signal, 20  
 Common Digital Alarm, 20  
 Danfoss Liquid Injection Valve, 19  
 High, 20  
 ICAD (Industrial Control Actuator with Display), 19  
 ICM (Motorized Industrial Control Valve), 19  
 Low, 20  
 Med, 20  
 MMI (Man Machine Interface), 19  
 Mod, 20  
 Opening Degree (OD), 20  
 parameters, 19  
 Parameter list, 21  
 Analog Input signal, 21  
 Analog Output signal, 21  
 Automatic calibration, 21  
 Digital Input function, 21  
 Fail-safe, 21  
 ICM configuration, 21  
 Main Switch, 21  
 Mode, 21  
 Modulating Mode, 21  
 Old Alarms, 21  
 Password, 21  
 digital Input signal, 20  
 Display, 20  
 Enter push button, 20  
 ICAD (Industrial Control Actuator with Display), 19  
 ICM valve, 20  
 MMI (Man Machine Interface), 19  
 Mod, 20  
 Motorized Industrial Control Valve, 19  
 Opening Degree, 20  
 parameters, 19  
 Parameter list, 21  
 Analog Output signal, 21  
 Automatic calibration, 21  
 Digital Input function, 21  
 Fail-safe, 21  
 ICM configuration, 21  
 Main Switch, 21  
 Mode, 21  
 Modulating Mode, 21  
 Old Alarms, 21  
 Password, 21  
 solenoid valve, 20  
 liquid injection oil cooling, 9  
 liquid injection strainer, 25  
 liquid injection system, 9  
 liquid injection tube, 9  
 liquid injection valves, 24  
 liquid level, 8,9  
 liquid refrigerant, 17

liquid solenoid, 10,25  
liquid supply service valve, 25  
locknut, 6  
low differential oil pressure, 15  
low pressure transducer, 25  
low voltage, 11  
lubrication system, 14

## M

magnetic field, 54  
Maintenance  
Abnormal Operation Analysis and Correction, 33  
abnormal system conditions, 33  
abnormal vibration, 30  
Capacity Linear Transmitter, 36  
compressor unload cylinder, 36  
condensed refrigerant, 34  
DIN connector plug, 36  
filter elements, 31  
Grease Compatibility, 32  
leaks, 30  
linear transmitter, 36  
lubrication, 32  
Lubrication Schedule, 32  
Maintenance Schedule, 31  
Main Operating Screen, 33  
moisture, 31  
Motor Bearings, 32  
NLGI Grease Compatibility Chart, 32  
noise, 30  
oil-base grease, 32  
oil analysis, 31  
oil level control, 37  
Oil Level Transmitter, 37  
Oil quality, 31  
Operating Log, 32  
Potentiometer, 36  
Pressure Transducers  
discharge pressure, 35  
discharge pressure transducer, 35  
oil pressure transducer, 35  
Pressure Transducer, 35  
Replacement, 35  
Testing, 35  
transducer isolation valve, 35  
voltage reading, 35  
Proper Installation of Electronic Equipment, 52  
P & I Diagram, 49  
Recommended Maintenance Program, 30  
refrigeration oil, 31  
sensor well, 36  
Servicing the Cold-Start Valve, 34  
bonnet, 34  
Bonnet Cap Screw Torque Values, 34  
valve body, 34  
valve housing, 34  
stop valve, 34  
Temperature Transmitter, 37

Troubleshooting. *See Index*, Troubleshooting  
shooting  
Troubleshooting Guide, 33  
Vibration Analysis, 30  
Vibration Data Sheet, 63  
vibration readings, 30  
volume ratio control, 36  
Volumizer® unit, 36  
main oil injection port, 15  
manual solenoid, 26  
manway bolts, 26  
manway cover, 26  
microprocessor, 10,11,16,17  
microprocessor control system, 12  
mist, 15  
motor, 11  
Motor And Bare Compressor Replacement, 40  
motor contactor, 11  
motor rotation, 6  
motor starters, 24  
motor starter coils, 12  
motor starter contactor, 11  
mounting bolts, 5  
movable slide stop, 16  
movable slide valve, 14,16  
MSS, 16  
MSV, 16  
MSV solenoid, 16

## N

neoprene drive spacer, 6  
nitrogen charge, 7

## O

dual oil filters, 25  
main oil filter, 25  
oil, 5  
oil-charging valve, 26  
Oil-entrained refrigerant, 26  
Oil Charge, 7  
oil charge reservoir, 15  
oil cooler, 9,14  
oil filters, 24  
oil filter cartridges, 26  
oil foaming, 7,25,26,31  
oil heaters, 7,12  
oil leakage, 7,25,31  
oil level cutout, 7,25,26,31  
Oil Level Transmitter Replacement, 37  
Troubleshooting, 36  
Din Plug, 37  
oil manifold, 16,22  
oil pressure loss, 7,31  
oil pump, 14,15  
Oil Pump Coupling, 7  
oil pump starter, 12  
oil sampling valve, 32  
oil seal, 14  
oil separator, 11,14,15  
oil strainer elements, 26

Oil temperature, 8  
operating level, 7  
Operating Log Sheet, 57  
operating volume ratio, 17  
Optical Isolation, 56  
ORIFICE, 23  
outlet pressure regulator, 11  
overpressurizing, 11

## P

Packaged Refrigerant Recirculation unit, 11  
package vibration, 5  
partial load, 11  
pH, 9  
pipe hangers, 5  
piston, 15  
piston-type check valves, 11  
plate and shell oil cooler, 8  
plate and shell type thermosyphon oil cooler, 8  
Point-To-Point Wiring Diagram, 13  
port pressure, 10  
power feed, 54  
power fluctuations, 13  
premature bearing failure, 24  
PRESSURE-REGULATING VALVE, 22  
pressure differential, 15  
proportional band, 16  
no pump, 14  
pump-out connection, 22  
purge valve, 25  
P & I DIAGRAM, 49  
PVC conduit, 54

## Q

Quantum™LX, 3,11,15,24,56

## R

reboot, 56  
receiver, 8,9  
refrigerant charge, 5  
refrigerant isolation valves, 9  
refrigerant vapor, 26  
refrigeration oil, 25  
regulating control transformer, 12  
roller bearings, 14  
Rotary Screw Compressor, 5  
rotor contact, 14

## S

safety valve, 9  
Sales Order Numbers, 3  
SC2, 16  
scaling, 9  
self-lubricating, 14  
separator, 5,7,26  
serial number, 4  
service valves, 26  
setpoint, 11,16  
severe water conditions, 9  
SGC Compressor, 14

"D" Flange adapter, 14  
 angular-contact ball bearings, 14  
 axial loads, 14  
 axial load bearings, 14  
 balance pistons, 14  
 compressor drive shaft, 14  
 discharge pressure, 14  
 external strainer, 14  
 helical rotors, 14  
 infinitely variable volume ratio, 14  
 movable slide valve, 14  
 roller bearings, 14  
 rotor contact, 14  
 self-lubricating, 14  
 Shaft rotation, 14  
 Single-Acting Mode, 16  
 slide valve, 14  
 Suction flange, 14  
 suction port, 14  
 Volumizer®, 14  
 SGC compressor, 16  
 Shaft rotation, 14  
 shunting device, 12  
 Shutdown, 40  
 shutdowns, 24  
 shutdown cycles, 7  
 sight glass, 7,15,26  
 single-box control, 11  
 single-port liquid injection, 17  
 slide stop, 14  
 slide stop piston, 16  
 slide valve, 11,14,16  
 slide valve position, 23  
 slugging, 24  
 Sola® constant voltage (CV) transformer, 12  
 solenoid, 11,26  
 solenoid valve, 9,16,17,22  
 solid-state, 12  
 spacer, 6  
 spring isolators, 5  
 Star Networks, 56  
 Starter Operating Log Sheet, 62  
 Start-up  
   CoolWare™, 23  
   discharge temperature, 23  
   hand expansion valve, 23  
   initial start-up, 23  
   manway bolts, 23  
   prestart checklist, 23  
   start-up, 7  
   theoretical discharge temperature, 23  
   water control valve, 23  
 starter coil, 12  
 starter package, 12  
 Starter Wiring Diagram, 12  
 stop valve, 26  
 strainer, 9,11,26  
 strainer basket, 26  
 strainer cover, 25,26  
 strainer elements, 26  
 strainer inlet service valve, 25  
 subcooled liquid, 10

subcooling, 10  
 suction, 15  
 suction accumulators, 24  
 suction bypass, 11  
 suction check valve, 8,22  
 suction check valve bypass, 15  
 suction check valve bypass line, 11  
 Suction Check Valve  
   Power Assist Kit, 22  
 Suction flange, 14  
 suction isolation valve, 8  
 suction port, 14  
 suction pressure, 11  
 suction strainer, 14,24  
 suction trap, 25  
 superheat, 24  
 superheating, 14  
 Surge suppression, 56  
 system head pressure, 14

**T**

TCV, 17  
 temperature control valve, 17  
 Temperature Sensor  
   Replacement, 37  
   DIN connector plug, 37  
   thermal well, 37  
   transmitter unit, 37  
   Troubleshooting, 37  
   digital board #1, 37  
 temperature sensor, 17  
 thermosyphon, 8,14  
 Thermosyphon Oil Cooling  
   condenser inlet, 8  
   condensing pressure, 8  
   condensing temperature, 8  
   operating level, 7  
   plate and shell oil cooler, 8  
   receiver, 8,9  
   thermostatically controlled mixing valve, 8  
   thermosyphon oil cooling, 8,9  
   two-pass oil coolers, 8  
   vapor, 8  
 thermosyphon oil cooling, 8,9  
 threaded metallic, 54  
 threaded PVC-coated metallic, 54  
 throttling valve, 15  
 thrust balance piston, 22  
 torque analysis, 12  
 Troubleshooting, 38  
   Excessive Noise and Vibration, 38  
   Gradual Oil Loss, 38  
   Rapid Oil Loss, 38  
   Shaft Seal Leakage, 38  
   Slide Stop  
     will not function either direction, 39  
     will not move, 38  
   Slide Valve  
     will load but not unload, 39  
     will not load or unload, 39  
     will not move, 38  
     will unload but not load, 39

Troubleshooting Guide, 33  
 Troubleshooting The Demand Pump System, 40  
 Troubleshooting The Hydraulic System, 39  
 Troubleshooting The Oil Separation System, 38  
 Troubleshooting The Rwf Ii Compressor, 38  
 tunnel, 6  
 turbine drive, 5  
 two-pass oil coolers, 8

**U**

uninterrupted power supply, 56  
 Unit Data Plate, 3  
 unitized flex disc, 6  
 unloader spring, 16  
 unshielded, 54  
 UPS, 11,56

**V**

A4ALE Pressure Regulating Valve, 22  
 valve HV-1, 22  
 valve HV-2, 22  
 vapor, 8  
 vapor line, 11  
 variable frequency drives, 54  
 VFD Applications, 53  
 VFD output, 53  
 Vi, 16  
 Vibration Data Sheet, 63  
 voltage isolation, 56  
 volume ratio, 16  
 volume ratio control, 14  
 Volume Ratio Control Transmitter - Slide Stop, 36  
   Replacement, 36  
   linear transmitter, 36  
   Troubleshooting, 36  
   slide stop linear transmitter, 36  
   slide valve transmitter, 36

**W**

water-cooled, 14  
 water-cooled oil cooler, 9  
 Water-Cooled Oil Cooling, 9  
 water treatment, 9  
 water vapor, 24  
 wye-delta, 12

