




Installation – Electrical Information

Water-Cooled CenTraVac™ With CH530



Required Installation Information:

CVHE-SVN01A-EN – General Information

CVHE-SVN02B-EN – Piping Information

CVHE-SVN03C-EN – Electrical Information

Warnings and Cautions

Warnings and Cautions

Notice that warnings and cautions appear at appropriate intervals throughout this manual. Warnings are provided to alert installing contractors to potential hazards that could result in personal injury or

death, while cautions are designed to alert personnel to conditions that could result in equipment damage.

Your personal safety and the proper operation of this machine depend upon the strict observance of these precautions.

NOTICE: Warnings and Cautions appear at appropriate sections throughout this manual. Read these carefully.

⚠ WARNING – Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.

⚠ CAUTION – Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury. It may also be used to alert against unsafe practices.

CAUTION – Indicates a situation that may result in equipment or property-damage-only accidents.

Contents

Warnings and Cautions	2
General	4
Power Supply	8
PFCC	9
Unit Mounted Starter	10
Remote Starter	11
Motor Lugs	13
Field Control Panel Signal Wiring	15
Wiring Diagrams	21
Legend	68



Electrical Information

General

Note: Unit-mounted starters are available as an option on most CVHE, CVHF, and CVHG units with wye delta, and solid-state starters, with nominal voltages of up to 600 volts and unit mounted medium voltage across-the-line starters..

While this option eliminates most field-installed wiring requirements, the electrical contractor must still complete the electrical connection for: (1) Power supply wiring to the starter, (2) Other unit control options present, and (3) Any field-supplied control devices.

General Requirements

⚠ WARNING!

Hazardous Voltage!

Use extreme caution when measurements, adjustments, or other service-related work is performed with power on. Failure to disconnect power before servicing could result in death or serious injury.

⚠ WARNING

Rotating Parts!

During installation, testing, servicing and troubleshooting of this product it may be necessary to measure the speed of rotating components. Have a qualified or licensed service individual who has been properly trained in handling exposed rotating components perform these tasks. Failure to follow all safety precautions when exposed to rotating components could result in death or serious injury.

As you review this manual, along with the wiring instructions presented in this section, keep in mind that:

Typical field connection requirements for remote-mounted starters are shown at the end of the manual, and summarized in Table 1.

All field-installed wiring must conform to National Electric Code (NEC) guidelines, as well as to any applicable state and local codes. Be sure to satisfy proper equipment grounding requirements per NEC.

All field-installed wiring must be checked for proper terminations, and for possible shorts or grounds.

Note: The typical customer connection diagrams shown in this manual are representative of standard CVHE, CVHF and CVHG units, and are provided only for general reference. Always refer to the actual wiring diagrams that shipped with the chiller for specific as built electrical schematic and connection information.

Do not modify or cut enclosure to provide electrical access. Removable panels have been provided for this purpose. Modify these panels only; away from enclosure. Refer to installation information shipped with the starter or submittal drawings.

CAUTION

TO AVOID DAMAGE TO STARTER COMPONENTS, remove debris inside the starter panel. Failure to do so may cause an electrical short that seriously damages the starter components.

Electrical Information

Trane Supplied Remote Starter

Table 1. CVHE, CVHF, and CVHG standard remote starter field wiring requirements

Power Supply wiring (to Starter Panel)	Starter Panel Terminals		
3-Phase Line Voltage: Terminal Block (2TB3 or 2X3)	2X3-L1, L2, L3, and GROUND	All wiring to be in accordance with National Electrical Code and any local codes.	
3-Phase Line Voltage: Circuit Breaker	2Q1-L1,L2,L3, and GROUND		
Remote Starter to Chiller Motor Junction Box	T1 through T6		
Starter to UCP 120VAC control wiring	Starter Panel Terminals	Unit Control Panel Terminations	
120VAC Power Supply (from starter to UCP)	2X1-1-1, 2X1-2 2X1-20(Ground)	1X1-1, 1X1-12 1X1-18 (Ground)	#8 gauge minimum 40 amps circuit
High Pressure Cutout to Starter	2X1-4,	1X1-4	14 ga.
1Q1 Circuit Breaker to Starter	2X1-6	1X1-3	14 ga.
Oil Pump Interlock	2X1-7, 2X1-8	1A7-J2-4, 1A7-J2-2	14 ga.
Low Voltage Circuits (less than 30VAC)	Starter Panel Terminals	Unit Control Panel Terminations	
Standard Circuits			
Inter Processor Communications (IPC) Remote Mounted	2A1- J3-3 to 4, or 2X1-12 to 13 if present (do not ground shield at starter)	1A1-J5-3 to 4 Shield ground at 1X1- 22(GND) only.	2 wire w/ ground Comm link.

Standard Field Power wiring:

Note: All wiring to be in accordance with National Electrical Code and any local codes.

Reference Field connection diagram 2309-4935 in this manual



Electrical Information

Customer Supplied Remote Starter

Table 2. CVHE, CVHF, and CVHG standard customer supplied remote field wiring requirements

Power Supply wiring (to Starter Panel)	Starter Panel Terminals		
Starter by others	See "Starter by others" schematic		All wiring to be in accordance with National Electrical Code and any local codes.
Power wiring:			
3-Phase Power Supply Starter and Motor Junction Box Interconnection (Remote starter only)			
Starter provided by others:			
Starter to UCP 120VAC control wiring	Starter Panel Terminals	Unit Control Panel Terminations	
120VAC Power Supply	See "Starter by others" schematic 5X1-1, 5X1-2 5X1-20 (Ground)	1X1-1, 1X1-12 1X1-18	#8 gauge minimum 40 amps circuit
Power from UCP 1Q1	5X1-3	1X1-3, 1A23-J6-3	14 ga.
Interlock Relay signal	5X1-4	1A23-J10-1	14 ga.
Start contactor signal	5X1-5	1A23-J8-1	14 ga.
Oil Pump Interlock	5X1-7, 5X1-8	1A7-J2-4, 1A7-J2-2	14 ga.
Run Contactor signal	5X1-10	1A23-J6-12	14 ga.
Transition Complete	5X1-14	1A23-J12-2	14 ga.
Low Voltage Circuits (less than 30VAC)	Starter Panel Terminals	Unit Control Panel Terminations	
Standard Circuits			
Current Transformers* (see table next page)	5CT4- wht, blk 5CT5- wht, blk 5CT6- wht, blk	1A23-J7-1,2 1A23-J7-3,4, 1A23-J7-5,6,	Note: Phasing must be maintained
Potential Transformers	5T17-236,237 5T18-238,239 5T19-240,241	1A23 -J5-1,2, 1A23 -J5-3,4, 1A23 -J5-5,6	Note: Phasing must be maintained

Starter Supplied by Others -Standard Field Power wiring:

Note: All wiring to be in accordance with National Electrical Code and any local codes.

Reference Field Connection Customer Supplied Starter diagram 2309-4936 in this manual

Reference "Starter by Others" Specification available from your local Trane sales office.

Electrical Information

Customer Supplied Remote Starter

Table 3. Current transformer and potential transformer wire sizing tables for customer supplied starter to chiller unit control panel starter module 1A23

The maximum recommended wire length for secondary CT leads in a dual CT system are:

Wire AWG (mm ²)	Maximum Wire Length Secondary CT Leads	
	Feet	Meters
8 (10)	1362.8	415.5
10 (6)	856.9	261.2
12 (4)	538.9	164.3
14 (2.5)	338.9	103.3
16 (1.5)	213.1	65.0
17 (1)	169.1	51.5
18 (0.75)	134.1	40.9
20 (0.5)	84.3	25.7

Note:

1. Wire lengths are for copper conductors only.
2. Wire lengths are total "one way" distance that the CT can be from the Starter module.

The maximum recommended total wire length for PT's in a single PT system:

Wire Gauge	Max lead length (ft)	Max lead length (m)
8	5339	1627
10	3357	1023
12	2112	643
14	1328	404
16	835	254
17	662	201
18	525	160
20	330	100
21	262	79
22	207	63

The maximum recommended total wire length (to and from) for PT leads in a dual PT system are:

Wire Gauge	Max Wire Length Primary (ft)	Max Wire Length Primary (m)	Max Wire Length Secondary (ft)	Max Wire Length Secondary (m)
8	3061	933	711	217
10	1924	586	447	136
12	1211	369	281	85
14	761	232	177	53
16	478	145	111	33
17	379	115	88	26
18	301	91	70	21
20	189	57	44	13
21	150	45	34	10
22	119	36	27	8

Note: These wire lengths are for copper conductors only

Note: The above lengths are maximum round trip wire lengths. The maximum distance the PT can be located from the Starter module is 1/2 of the listed value.

Electrical Information

Power Supply

Power Supply Wiring

To assure that power supply wiring to the starter panel is properly installed and connected, review and follow the guidelines outlined below.

3-Phase Power Source

1. Verify that the starter nameplate ratings are compatible with the power supply characteristics and with the electrical data on the unit nameplate.
2. If the starter enclosure must be cut to provide electrical access, exercise care to prevent debris from falling inside the enclosure. If the starter cabinet has a removable panel, be sure to remove the panel from the unit before drilling holes.

CAUTION

TO AVOID DAMAGE TO STARTER COMPONENTS, remove debris inside the starter panel. Failure to do so may cause an electrical short that seriously damages the starter components.

3. Use copper conductors to connect the 3-phase power supply to the remote or unit-mounted starter panel.

CAUTION

USE ONLY COPPER CONDUCTORS FOR TERMINAL CONNECTIONS.

Failure to do so may cause corrosion or overheating, and starter damage.

4. Size the power supply wiring in accordance with the Minimum Circuit Ampacity (MCA) shown on the unit nameplate.
(MCA = (RLA x 1.25) + Control Power Load)
5. Make sure that the incoming power wiring is properly phased; each power supply conduit run to the starter must carry the correct number of conductors to ensure equal phase representation. See Figure 1.

6. As you install the power supply conduit, make sure that this position does not interfere with the serviceability of any of the unit components, nor with structural members and equipment.


Also, assure that the conduit is long enough to simplify any servicing that may be necessary in the future (e.g., starter removal).

Note: Use flexible conduit to enhance serviceability and minimize vibration transmission.

Circuit Breakers and Fusible Disconnects

Size the circuit breaker or fuse disconnect in compliance with NEC or local guidelines.

Figure 1. Proper phasing for starter power supply wiring and conduit loading



Electrical Information

PFCC

Optional PFCCs

Power factor correction capacitors (PFCCs) are designed to provide power factor correction for the compressor motor. They are available as an option.

Note: Remember that the PFCC nameplate voltage rating must be greater than or equal to the compressor voltage rating stamped on the unit nameplate. See Table 2 to determine what PFCC is appropriate for each compressor voltage application.


CAUTION

PFCCS MUST BE WIRED INTO THE STARTER CORRECTLY! Failure to do so may cause misapplication of these capacitors and result in a loss of motor overload protection and subsequently cause motor damage.

Table 3. PFCC design voltage sizing per compressor voltage application

PFCC Design Voltage	Compressor Motor Rating (See Unit Nameplate)
240/60 Hz	208V/60 Hz
480V/60 Hz	380V/60 Hz 440V/60 Hz 460V/60 Hz 480V/60 Hz
600V/60 Hz	575V/60 Hz 600V/60 Hz
2400V/60 Hz	2300V/60 Hz 2400V/60 Hz
PFCC Rating	Compressor Motor Rating (See Unit Nameplate)
480V/50 Hz	346V/50 Hz 380V/50 Hz 400V/50 Hz 415V/50 Hz
4160V/60 Hz	3300V/60 Hz 4160V/60 Hz

Figure 2. PFCC leads routed through overload current transformer



Note: See the attached wiring diagram for more detail.

Electrical Information

Unit Mounted Starter


Interconnecting Wiring

Typical equipment room conduit layouts with and without unit-mounted starters are shown in Figures 3 and 4, respectively.

IMPORTANT

Keep in mind that the interconnecting wiring between the starter panel, compressor and UCP control panel is factory-installed with unit-mounted starters but must be field-installed when a remote-mounted starter is used.

Figure 3. Typical equipment room layout with unit-mounted, Wye-Delta




Note:
See Starter submittal drawing for location of incoming wiring to the starter.

Electrical Information

Remote Starter

Figure 4. Typical equipment room layout with remote-mounted Wye-Delta starter



Notes:

1. Refer to the unit field connection diagram for approximate UCP knockout locations.
2. 115-volt conduit must enter the higher than 30 Vdc Class I portion of the unit control panel.
3. IPC circuit conduit must enter the Low Voltage Class II portion of the UCP.
4. See starter submittal drawing for location of incoming wiring to the starter.



Electrical Information

Remote Starter

Starter to Motor (Remote-Mounted Starters Only)

Ground Wire Terminal Lugs

Ground wire lugs are provided in the motor terminal box and in the starter panel.

Terminal Clamps

Terminal clamps are supplied with the motor terminals to accommodate either bus bars or standard motor terminal wire lugs. Terminal clamps provide additional surface area to minimize the possibility of improper electrical connections.

Wire Terminal Lugs

Wire terminal lugs must be field-supplied.

1. Use field-provided crimp-type wire terminal lugs properly sized for the application.

Note: Wire size ranges for the starter line and load-side lugs are listed on the starter submittal drawings supplied by the starter manufacturer or Trane. Carefully review the submitted wire lug sizes for compatibility with the conductor sizes specified by the electrical engineer or contractor.

2. A terminal clamp with a 3/8" bolt is provided on each motor terminal stud; use the factor-supplied Belleville washers on the wire lug connections.

Figure 5 illustrates the juncture between a motor terminal stud and terminal clamp.

3. Tighten each bolt to 24 foot-pounds.
4. Install but do not connect the power leads between the starter and compressor motor. (These connections will be completed under supervision of a qualified Trane service engineer after the prestart inspection).

CAUTION

ENSURE THE POWER SUPPLY WIRING AND OUTPUT TO MOTOR WIRING ARE CONNECTED TO THE PROPER TERMINALS. Failure to do so will cause catastrophic failure of the starter and, or motor

Bus Bars

Install the bus bars between the motor terminals when a low-voltage "across-the-line", "primary reactor/resistor," "auto transformer" or customer-supplied solid-state, or customer-supplied AFD.

Be sure to bus motor terminal T1 to T6, T2 to T4, and T3 to T5.

Note: Bus bars are not needed in high-voltage applications since only 3 terminals are used in the motor and starter.

Starter to UCP (Remote-Mounted Starters Only)

Electrical connections required between the remote-mounted starter and the unit control panel are shown in an example of a point-to-point starter-to-UCP connection diagram as shown at the end of the manual.

Note: Install control voltage conduit into control voltage section of chiller control panel and starter panel. Do not route with low voltage (30 volts) conduit wires.

When sizing and installing the electrical conductors for these circuits, follow the guidelines listed.

Unless otherwise specified use 14 ga. wire for 120 V control circuits.

Electrical Information

Remote Starter

CAUTION

Starter Component Damage.

Remove debris inside the starter panel. Failure to do so may cause an electrical short that seriously damages the starter components.

1. If the starter enclosure must be cut to provide electrical access, exercise care to prevent debris from falling inside the enclosure. Do not cut AFD enclosure.
2. Use only shielded twisted pair for the interprocessor communication (IPC) circuit between the starter and the UCP on remote mounted starters. Recommended wire is Beldon Type 8760, 18 AWG for runs up to 1000 feet.
Note: The polarity of the IPC wire pair is critical for proper operation.
3. Separate low-voltage (less than 30V) wiring from the 115V wiring by running each in its own conduit.
4. As you route the IPC circuit out of the starter enclosure, make sure that it is at least 6" from all wires carrying a higher voltage.

5. For UCP IPC shielded twisted pair wiring, the shield should be grounded on one end only at UCP at 1X1-G. The other end should be unterminated and taped back on the cable sheath to prevent any contact between shield and ground.

6. Oil Pump Interlock - All starters must provide an interlock (N.O.) contact with the chiller oil pump connected to the UCP at Terminals 1A7-2-4 and 1A7-J2-2 (14 ga.)

The purpose of this interlock is to power the oil pump on the chiller in the event that a starter failure, such as welded contacts, keeps the chiller motor running after the controller interrupts the run signal.

CAUTION


Electrical Noise.

Maintain at least 6 inches between low-voltage (<30V) and high voltage circuits. Failure to do so could result in electrical noise that may distort the signals carried by the low-voltage wiring, including the IPC.


Electrical Information

Motor Lugs

Figure 5. Terminal stud, clamp and lug assembly



Front View



MID VOLTAGE
RXL RATR RPIR CXL CATR CPIR

Electrical Information

Field Control Panel Signal Wiring

Table 4

Standard Control Circuits: UCP Control Wiring (120 VAC)	Unit Control Terminations	Included in Factory Package	Input or Output Type	All wiring to be in accordance with National Electrical Code and any local codes. Contacts
Chilled Water Flow Proving Input	1X1-5 to 1A6-J3-2	Std.	Binary Input	Normally Open, closure with flow
Condenser Water Flow Proving Input	1X1-6 to 1A6-J2-2	Std.	Binary Input	Normally Open, closure with flow
Chilled Water Pump Relay Output	1A5-J2- 4 to 6	Std.	Binary Output	Normally Open
Condenser Water Pump Relay Output	1A5-J2-1 to 3	Std.	Binary Output	Normally Open
Optional Control Circuits (120 VAC)				
Alarm Relay MAR (Non-Latching) Output	1A8-J2-1 to 3	OPST	Binary Output	Normally Open
Limit Warning Relay Output	1A8-J2-4 to 6	OPST	Binary Output	Normally Open
Alarm Relay MMR (Latching) Output	1A8-J2-7 to 9	OPST	Binary Output	Normally Open
Compressor Running Relay Output	1A8-J2-10 to 12	OPST	Binary Output	Normally Open
Maximum Capacity Relay Output	1A9-J2-1 to 3	OPST	Binary Output	Normally Open
Head Relief Request Relay Output	1A9-J2-4 to 6	OPST	Binary Output	Normally Open
Purge Alarm Relay Output	1A9-J2-7 to 9	OPST	Binary Output	Normally Open
Ice Making Relay Output	1A5-J2-10 to 12	EXOP	Binary Output	Normally Open
Free Cooling Relay Output	1A11-J2-4 to 6	FRCL	Binary Output	Normally Open
Standard Low Voltage Circuits Low Voltage Circuits (less than 30VAC)				
External Auto Stop Input	1A13-J2-1 to 2	Std.	Binary Input	Closure required for normal operation
Emergency Stop Input	1A13-J2-3 to 4	Std.	Binary Input	Closure required for normal operation
Optional Low Voltage Circuits				
External Base Loading Enable Input	1A18-J2-1 to 2	EXOP	Binary Input	Normally Open
External Hot Water Control Enable Input	1A18-J2-3 to 4	EXOP	Binary Input	Normally Open
External Ice Machine Control Enable Input	1A19-J2-1 to 2	EXOP	Binary Input	Normally Open
External Free Cooling Input Enable Input	1A20-J2-1 to 2	FRCL	Binary Input	Normally Open
RLA Compressor Output	1A15-J2-1 to 3	GBAS or CDRP	Analog Output	2-10 vdc
External Condenser Pressure Output	1A15-J2-4 to 6	GBAS or CDRP	Analog Output	2-10 vdc
External Current Limit Setpoint Input	1A16-J2-2 to 3	GBAS	Analog Input	2-10 vdc, or 4-20 mA
External Chilled Water Setpoint Input	1A16-J2-5 to 6	GBAS	Analog Input	2-10 vdc, or 4-20 mA
External Base Load Setpoint Signal Input	1A17-J2-2 to 3	EXOP	Analog Input	2-10 vdc, or 4-20 mA
Generic Refrigerant Monitor input	1A17-J2-5 to 6	EXOP	Analog Input	2-10 vdc, or 4-20 mA
Outdoor Air Temperature sensor	IPC bus Connection and sensor	CWR	Communication and sensor.	
Tracer Comm Interface	1A14-J2-1(+) to 2(-) 1A14-J2-3(+) to 4(-)	TRMM or LCI-C	Communication to Tracer	

Electrical Information

UCP Electrical Specifications

Following is a requirements list for the UCP in the control panel:

Note that the control panel is designed to receive input from the secondary of a power transformer in the starter panel.

1. **Nominal Voltage:** 115/110 VAC, 60/50 Hz with operating range of 98 to 127 VAC, inclusive.
2. **Maximum VA:** 4K VA (40-amp fuse) for units with the refrigerant pump.
3. Power input wiring must be at least 6" (152 mm) from low-voltage, less than 30V wiring.
4. All signal inputs are low-voltage less than 30V.
5. UCP Storage Range: -40°F to 158°F (-40°C to 70°C) i.e., not applicable for chiller.

Water Pump Interlock Circuits and Flow Switch Input

Chilled Water Pump. Wire the evaporator water pump contactor (5K1) to a separate 120 volt single phase power supply with 14 AWG, 600 volt copper wire, then connect this circuit to 1A5-J2-6. Then use 1A5-J2-4 120 VAC output to allow the UCP to control the evaporator water pump, or wire the 5K1 contactor to operate remotely and independently of the UCP.

Chilled Water Proof of Flow

Wire the auxiliary contacts of the evaporator water pump contactor (5K1) in series with the flow switch (5S1) installed in the evaporator supply pipe. Use 14 AWG, 600-volt copper wire.

Connect this circuit to UCP terminals 1X1-5 to 1A6-J3-2.

When installed properly, the chilled water interlock circuit will only allow compressor operation if the evaporator pump is running and providing at least the minimum water flow required.

Condenser Water Pump. Wire the condenser water pump contactor (5K2) to a separate 120-volt, single-phase power supply with 14 AWG, 600-volt copper wire; then connect this circuit to UCP terminals 1A5-J2-3. Then use 1A5-J2-1 120 VAC output to allow UCP to control the condenser pump.

Condenser Water Proof of Flow

Next, use 14 AWG, 600-volt copper wire to connect the auxiliary contacts of the condenser water pump contactor (5K2) in series with the flow switch (5S2) installed in the condenser supply pipe.

Connect this circuit to UCP terminals 1X1-6 to 1A6-J2-2.

When installed properly, the condenser water lock circuit will only allow the compressor to operate if the condenser pump is running and providing at least the minimum water flow required.

Electrical Information

Temperature Sensor Circuits

All temperature sensors are factory-installed except the optional outdoor air temperature sensor. This sensor is required for the outdoor air temperature type of chilled water reset. Follow the guidelines below to locate and mount the outdoor air temperature sensor. Mount the sensor probe where needed, however, mount the sensor module in the UCP.

CWR - Outdoor Option

The outdoor temperature sensor similar to the unit mounted temperature sensors in that it consists of the sensor probe and the module. A four-wire IPC bus is connected to the module for 24 vdc power and the communications link.

We recommend mounting the sensor module within the UCP and the sensor two wire leads be extended and routed to the outdoor temperature sensor probe sensing location. This assures the four wire IPC bus protection and provides access to the module for configuration at start-up.

The sensor probe lead wire between the sensor probe and the module can be separated by cutting the two wire probe lead leaving equal lengths of wire on each device; the sensor probe and the sensor module. Note this sensor and module are matched and must remain together or inaccuracy may occur. These wires can then be spliced to with two 14-18 AWG 600V wires of sufficient length to reach the desired outdoor location, maximum length 1000 feet (305 meters). The module four-wire bus must be connected to the UCP four-wire bus using the Trane approved connectors provided.

The sensor will be configured (given its identity and become functional) at start-up when the serviceman performs the start-up configuration.

It will not be operational until that time.

Note: If shielded cable is used to extend the sensor leads, be sure to tape off the shield wire at the junction box and ground it at the UCP. If the added length is run in conduit, do not run them in the same conduit with other circuits carrying 30 or more volts.

Note:

MAINTAIN AT LEAST 6 INCHES BETWEEN LOW-VOLTAGE (<30V) AND HIGH VOLTAGE CIRCUITS. Failure to do so could result in electrical noise that may distort the signals carried by the low-voltage wiring, including the IPC.

Optional Relay Circuits

Optional Control and Output Circuits
Install various optional wiring as required by the owner's specifications.

TRMM or LC1-C

Optional Tracer Communication Interface

This control options allows the UCP to exchange information such as chiller status and operating set points with a Tracer system.

Figure 7 illustrates how such a communication/control network might appear.

Note: The circuit must be run in separate conduit to prevent electrical noise interference.

Additional information about the Tracer Comm option is published in the installation manual and operator's guide that ships with the Tracer.

Unit Start-Up

All phases of initial unit start-up must be conducted under the supervision of a qualified local service engineer.

This includes pressure testing, evacuation, electrical checks, refrigerant charging, actual start-up and operator instruction.

Advance notification is required to assure that initial start-up is scheduled as close to the requested date as possible.

Starter Module Configuration

The starter module configuration settings will be checked (and configured for Remote Starters) during start-up commissioning. To configure starter module, and perform other starter checks, it is recommended that the line voltage three phase power be turned off and secured (locked out), and then a separate source control power (115 vac) be utilized to power up the control circuit. To do this, remove control coil circuit fuse, typically 2F4, and then connect separate source power cord to starter terminal block 2X1-1 (H), 2X1-2 (N), and Ground. Use the "as-built starter schematic" to assure correct fuse and terminals. Verify correct fuse is removed, control circuit connections are correct, then apply the 115 vac separate source power to service the controls.

Forms Information

Samples of start-up and operating forms along with other helpful forms are found in the Operation Maintenance manual which can be obtained from the nearest Trane office.


It is recommended that the serviceman contact the local Trane office to obtain the most recent printing date of the form. The forms in the operation and maintenance manual are only current at the time of printing of the manual.

After obtaining the most recent form, complete all the information and forward it to your local Trane office.

Electrical Information

Field Control Panel Signal Wiring

Figure 6



Note: UCP control wiring (120 VAC) must not be routed with low voltage circuits (less than 30 VAC). Conduit access holes are furnished in the top of the unit control panel. Use the left holes for low voltage wiring, and use center and right hand holes for control (120 VAC) wiring.

***Note:** The wire is retained in the clamp by the force of the spring which pushes the wire against the connecting bar. Use care to ensure full insertion of screwdriver into terminal block wire release mechanism. Proper tool engagement is required to release the tension for wire insertion.

Separate low voltage field wiring from 120 VAC control wiring

Control Panel Internally mounted devices

For visual identification Internal Control Panel mounted devices are identified by their respective schematic designation number. Control panel items are marked on the inner back panel in the control panel. Figure 7 illustrated below, identifies these devices. The Control Panel Devices table corresponds to the same device designators (see right hand column). Optional controls are present when a specific optional controls package is specified, as listed in the second column. Optional controls packages


are; OPST Operating Status, GBAS Generic Building Systems, EXOP Extended operation, CDRP Condenser Pressure, TRMM Tracer communications, WPSR Water Flow Pressure sensing, FRCL Free Cooling, HGBP Hot Gas Bypass , and EPRO Enhanced Protection

Figure 20 illustrates the Control Panel Components Layout.

Modules 1A1, 1A3, 1A4, 1A5, 1A6, 1A7, and 1A13 are standard and present in all configurations. Other Modules vary depending on machine optional devices.

Electrical Information

Figure 8. Illustrates communication/control network to chiller units with CH530



Wiring Drawings

Schematic Wiring Drawings

The following pages consist of typical wiring drawings for an CVHE, CVHF or CVHG chiller. However, please refer to the submittals and drawings that actually shipped with the unit.

Refer to the chiller operation and maintenance manual for an example of a typical sequence of operation for a Unit Mounted Wye-Delta Starter.

In the starter drawings, shown in this manual, all starter variables are the same in the Sequence of Operation except the Maximum Acceleration Time.

Table 5 provides a listing of included schematics, connection diagrams and field wiring drawings to follow.


Table 5 also shows variables of the Maximum Acceleration Time for all starter drawings in this manual.

Table 5 . Wiring addendum


Type of Drawing	Drawing Number	Maximum Acceleration Time (seconds)	Page #
Field Wiring Layout Drawings			
Legend (Unit Mounted Wye-Delta Starter)	2309-4922-D	–	68-69
Unit Mounted Wye-Delta Starter	2309-4902-D	27	22-23
Unit Mounted Solid-State Starter	2309-4904-D	15	26-27
Unit Mounted Across-the-Line	2309-4906-D	6	30-31
Unit Mounted Adaptive Frequency Drive	2309-4912-E	30	38-39
Remote Wye-Delta Starter	2309-4903-D	27	24-25
Remote Mounted Solid-State Starter	2309-4905-D	15	28-29
Remote Across-the-Line Starter	2309-4909-E	6	32-33
Remote Primary Reactor Starter	2309-4910-E	11	34-35
Remote Auto Transformer Starter	2309-4911-E	11	36-37
Customer Supplied Wye-Delta Starter	2309-4913-F	27	40-41
Customer Supplied Primary Reactor and Auto Transformer Starter	2309-4914-F	11	42-43
Customer Supplied Across-the-Line Starter	2309-4915-F	6	44-45
Customer Supplied Solid-State Starter	2309-4916-F	20	46-47
Purge Schematic	2309-4917-D	–	48-49
Unit Controls Schematic	2309-4919-E	–	50-51
System Controls Schematic	2309-4920-E	–	52-53
Options Schematic	2309-4921-D	–	54-55
Connection Diagrams			
Standard Connection Diagram Panel with Options	2309-4923-E	–	56-57
Field Connection Trane Starter	2309-4935-E	–	58-59
Customer Supplied Starter	2309-4936-E	–	60-61
Unit Wiring – Standard	2309-4937-E	–	62-63
Unit Wiring – Optional	2309-4938-F	–	64-65
Purge Control Panel (Unit Mounted)	2309-4939-D	–	66-67

Note: These are typical drawings only. Refer to specific as-built schematics for actual unit drawings which represent the unit wiring as shipped.

19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55




WARNING
 READ AND UNDERSTAND ALL INSTRUCTIONS BEFORE USING THIS EQUIPMENT. FAILURE TO FOLLOW THESE INSTRUCTIONS MAY RESULT IN DEATH OR SERIOUS INJURY.
AVERTISSEMENT
 LIREZ ATTENTION ET Lisez toutes les instructions avant d'utiliser cet équipement. Le non-respect de ces instructions peut entraîner la mort ou de graves blessures.
CAUTION
 READ AND UNDERSTAND ALL INSTRUCTIONS BEFORE USING THIS EQUIPMENT. FAILURE TO FOLLOW THESE INSTRUCTIONS MAY RESULT IN DEATH OR SERIOUS INJURY.
 LIREZ ATTENTION ET Lisez toutes les instructions avant d'utiliser cet équipement. Le non-respect de ces instructions peut entraîner la mort ou de graves blessures.



ALTERNATE WIRING FOR CALIFORNIA CODE

THIS DRAWING IS NOT TO BE COPIED OR REPRODUCED WITHOUT THE WRITTEN CONSENT OF THE WRITERS COMPANY.




WARNING
 HAZARDOUS VOLTAGE
 DEATH OR SERIOUS INJURY MAY OCCUR IF ELECTRICAL CONNECTIONS ARE MADE INCORRECTLY.
 FAILURE TO FOLLOW THESE INSTRUCTIONS MAY CAUSE DAMAGE TO THE EQUIPMENT.

AVERTISSEMENT
 DANGER
 MORTALITE OU BLESSEMENT GRAVE PEUT SURVENIR SI DES BRANCHEMENTS ELECTRIQUES SONT FAITES INCORRECTEMENT.
 LE NON RESPECT DE CES INSTRUCTIONS PEUT CAUSER DES DOMMAGES A L'EQUIPEMENT.

CAUTION
 THE EQUIPMENT IS DESIGNED FOR USE ONLY IN THE UNITED STATES OF AMERICA.
 FAILURE TO DO SO MAY CAUSE DAMAGE TO THE EQUIPMENT.

ALTERNATE WIRING FOR CALIFORNIA CODE



THIS DRAWING IS THE PROPERTY OF THE WRITER COMPANY. IT IS TO BE COPIED AND USED WITHOUT THE WRITER COMPANY'S PERMISSION.

⚠ WARNING

Hazardous Voltage!

Starter and motor components may be energized even if the motor is not running. Disconnect all electric power, including remote disconnects before servicing. Follow proper lockout/tagout procedures to ensure the power cannot be inadvertently energized. Failure to disconnect power before servicing could result in death or serious injury.

CAUTION!


Equipment Damage!


Motor components may be energized even if the motor is not running. Do NOT apply a deep vacuum to the unit if the unit is energized. Disconnect all electric power before evacuating the chiller. Failure to do so may cause damage to the equipment. Applying a deep vacuum to an IT Solid State Starter equipped unit, while power is applied to the unit, can cause an electrical arc-over inside the motor housing. This can cause motor winding or motor terminal damage or failure.

HERMETIC CENTRIFUGAL LIQUID CHILLER

CENTRAVAC[®]
CH530 SCHEMATIC WIRING CVHF, CVHG, CDHF AND CDHG
REMOTE MOUNTED SOLID STATE STARTER

2309-4905 D





WARNING
 READ CAREFULLY ALL ELECTRICAL CONNECTIONS
 BEFORE WORKING ON THIS EQUIPMENT
 FAILURE TO DO SO MAY CAUSE
 DAMAGE TO THE EQUIPMENT.


AVERTISSEMENT
 LIRE ATTENTIVEMENT TOUTES LES
 CONNEXIONS ÉLECTRIQUES
 AVANT DE TRAVAILLER SUR CE
 MATÉRIEL
 LE NON RESPECT DE CES
 RECOMMANDATIONS PEUT CAUSER
 DES DOMMAGES À L'ÉQUIPEMENT.


CAUTION
 READ CAREFULLY ALL ELECTRICAL CONNECTIONS
 BEFORE WORKING ON THIS EQUIPMENT
 FAILURE TO DO SO MAY CAUSE
 DAMAGE TO THE EQUIPMENT.

HERMETIC CENTRIFUGAL LIQUID CHILLER

CENTRAVAC[®]
 CH530 SCHEMATIC WIRING CVHE, CVHF, CVHG, CDHF AND CDHG
 UNIT MOUNTED ACROSS THE LINE STARTER

2309-4906 D






SEE LINE 141

WARNING
 NEVER TOUCH THE EQUIPMENT WITH YOUR HANDS OR FEET WHILE THE EQUIPMENT IS OPERATING. ALWAYS USE THE PROPER LOCKOUT/TAGOUT PROCEDURES TO PREVENT THE EQUIPMENT FROM STARTING UP UNEXPECTEDLY. ALWAYS WEAR THE PROPER PPE (PERSONAL PROTECTIVE EQUIPMENT) AS SPECIFIED IN THE SAFETY MANUAL.
AVERTISSEMENT
 NE JAMAIS TOUCHER L'ÉQUIPEMENT AVEC VOS MAINS NI VOS PIEDS ALORS QUE L'ÉQUIPEMENT EST EN MARCHE. TOUJOURS UTILISER LES PROCÉDURES DE VERROUILLAGE/ÉTIQUETAGE APPROPRIÉES POUR PRÉVENIR LE DÉMARRAGE INATTENDU DE L'ÉQUIPEMENT. TOUJOURS PORTER L'ÉQUIPEMENT DE PROTECTION INDIVIDUELLE (EPI) PRÉCONISÉ DANS LE MANUEL DE SÉCURITÉ.

CAUTION
 THE EQUIPMENT IS DESIGNED TO OPERATE AT A SPECIFIC VOLTAGE. DO NOT OPERATE THE EQUIPMENT AT A VOLTAGE OTHER THAN THAT SPECIFIED IN THE SAFETY MANUAL. FAILURE TO DO SO MAY CAUSE DAMAGE TO THE EQUIPMENT.






278/279 TRANSFORMER PHASING TRANSFORMERTAP	
PHASE	CHINESE
L1	H1, X1, X5
L2	H2, X2
L3	H3, X3, X4

HERMETIC CENTRIFUGAL LIQUID CHILLER

CENTRAVAC[®]
 CH530 SCHEMATIC WIRING CVHE, CVHF, CVHG, CDHF AND CDHG
 REMOTE MOUNTED ACROSS THE LINE STARTER

2309-4909 E






WARNING
 ELECTRICAL POWER
 CONNECTIONS
 MUST BE MADE BY A
 QUALIFIED PERSON.
 FAILURE TO FOLLOW
 THESE INSTRUCTIONS
 MAY RESULT IN
 PERSONAL INJURY OR
 DEATH.

AVERTISSEMENT
 LES TRAVAUX D'INSTALLATION
 DE LA PUISSANCE
 ÉLECTRIQUE DOIVENT ÊTRE
 RÉALISÉS PAR UN
 PERSONNEL QUALIFIÉ.
 LE NON-RESPECT DE
 CES RÈGLES PEUT CAUSER
 DES BLESSURES
 PERSONNELLES OU
 LA MORT.

CAUTION
 THE EQUIPMENT IS ONLY
 DESIGNED
 TO BE USED WITH
 THE SPECIFIED
 SUPPLIES.
 FAILURE TO DO SO MAY CAUSE
 DAMAGE TO THE EQUIPMENT.





279 TRANSFORMER PHASING
 TRANSFORMER TAP

PHASE	278	279
L1	H1, X1, X5	H1, X1, X5
L2	H2, X2	H1, X1, X5
L3		H2, X2, X4

HERMETIC CENTRIFUGAL LIQUID CHILLER
 CENTRAVAC[®]
 CH530 SCHEMATIC WIRING CVHF, CVHG, CDHF AND CDHG
 REMOTE MOUNTED PRIMARY REACTOR STARTER

2309-4910 E






2K1-2K8, B2
INTERLOCK RELAY

2K1-1, 5, 9, 7, 8
START CONTACTOR

2K2, 3, 7, 11, 22
RUN CONTACTOR

SEE LINE H1



278/279 TRANSFORMER PHASING
TRANSFORMER TAP

PHASE	0	278	279
L1		H1, X1, X5	
L2		H2, X2	H1, X1, X5
L3			H2, X2, X4

IPC BUS

22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55

WARNING
 ELECTRICAL POWER
 CONNECTIONS
 POWER
 FAILURE OR
 DEATH.
AVERTISSEMENT
 ALERTE
 ELECTRICITE
 LIEN
 DE
 MORT
 MORTALITE
 MORTALITE


CAUTION
 THE EQUIPMENT IS NOT DESIGNED
 FOR USE IN A HAZARDOUS
 ENVIRONMENT.
 FAILURE TO DO SO MAY CAUSE
 DAMAGE TO THE EQUIPMENT.


THIS DRAWING IS PROPERTY OF THE
 MANUFACTURER AND IS NOT TO BE
 REPRODUCED OR COPIED IN ANY
 MANNER WITHOUT THE WRITTEN
 CONSENT OF THE MANUFACTURER.

HERMETIC CENTRIFUGAL LIQUID CHILLER

CENTRAVAC[®]
 CH530 SCHEMATIC WIRING CVHE, CVHF, CVHG, CDHF AND CDHG
 REMOTE MOUNTED AUTO-TRANSFORMER STARTER

2309-491 1E





2K1-5
2K1-4
OPTIONAL

2K1-2B1,6Z
INTERLOCK RELAY


2K5,5,6,2B
START CONTACT

2K3,3,0,2Z
RUN CONTACT

2K5,3,7,2
SHORTING CONTACT

SEE LINE 141

WARNING
H DANGER OF HIGH VOLTAGE R RISK OF ELECTRICAL SHOCK E ELECTRIC SHOCK CAN CAUSE DEATH S SERIOUS INJURY OR DEATH V VOLTAGE
AVERTISSEMENT
H DANGER DE HAUTE TENSION R RISQUE D'ÉLECTROCUTION E ÉLECTROCUTION PEUT CAUSER LA MORT S SERIEUX BLESSURE OU MORT V VOLTAJE
CAUTION
U UNEXPECTED MOVEMENT OF EQUIPMENT T TRIP POINTS F FAILURE TO DO SO MAY CAUSE DAMAGE TO THE EQUIPMENT.




IPC BUS



HERMETIC CENTRIFUGAL LIQUID CHILLER

CENTRAVAC®

CH530 SCHEMATIC WIRING CVHE, CVHF AND CVHG UNIT MOUNTED ADAPTIVE FREQUENCY DRIVE

2309-4912 E






<p>WARNING</p> <p>HAZARD DISCONNECT ALL ELECTRIC POWER BEFORE WORKING ON THIS EQUIPMENT FAILURE TO FOLLOW THESE INSTRUCTIONS MAY CAUSE DEATH OR SERIOUS INJURY.</p>	<p>AVERTISSEMENT</p> <p>HAZARD DISCONNECTER TOUS LES COURANTS ELECTRIQUES AVANT DE TRAVAILLER SUR CE MATERIEL NE PAS SUIVRE CES INSTRUCTIONS PEUT CAUSER LA MORT OU DE GRAVES BLESSES.</p>
<p>CAUTION</p> <p>USE COP WIRE STRIPPING TOOL UNIT TERMINALS ARE NOT ARMED CONDUCTORS. FAILURE TO DO SO MAY CAUSE DAMAGE TO THE EQUIPMENT.</p>	<p>AVERTISSEMENT</p> <p>UTILISER UN OUTIL D'ENLEVEMENT DE LA BOULE D'ISOLATION LES TERMINAUX DE L'UNIT NE SONT PAS ARMES. L'EGALITE DE LA BOULE D'ISOLATION NE PAS SUIVRE CES INSTRUCTIONS PEUT CAUSER LA MORT OU DE GRAVES BLESSES.</p>


THIS DRAWING IS FOR INFORMATION ONLY. IT IS NOT TO BE COPIED OR REPRODUCED WITHOUT THE WRITTEN CONSENT OF THE AUTHOR.

HERMETIC CENTRIFUGAL LIQUID CHILLER


CENTRIVAC®
 CH530 SCHEMATIC WIRING CVHF, CVHG, CDHF AND CDHG
 CUSTOMER SUPPLIED WYE-DELTA STARTER

2309-4913 F





SEE LINE 141



WIRE AND TERMINAL NOS ARE REFERENCE ONLY

WARNING
 ELECTRICAL SHOCK
 DEATH OR SERIOUS INJURY
 POSSIBLE IF POWER
 IS NOT DISCONNECTED
 BEFORE WORKING ON
 THIS EQUIPMENT.
 ALWAYS USE PROPER
 SAFETY PROCEDURES.
 ALWAYS WEAR
 APPROPRIATE PPE.
 ALWAYS LOCK OUT
 AND TAG OUT
 BEFORE WORKING ON
 THIS EQUIPMENT.
 ALWAYS USE
 PROPER SAFETY
 PROCEDURES.
 ALWAYS WEAR
 APPROPRIATE PPE.

AVERTISSEMENT
 CHOC ÉLECTRIQUE
 DÉCÈS OU BLESSURES
 GRAVES POSSIBLES
 SI LE POUVOIR
 ÉLECTRIQUE N'EST
 PAS DÉCONNECTÉ
 AVANT DE TRAVAILLER
 SUR CE MATÉRIEL.
 TOUJOURS UTILISER
 LES PROCÉDURES
 DE SÉCURITÉ
 APPROPRIÉES.
 TOUJOURS PORTER
 LE MATÉRIEL
 DE PROTECTION
 ADÉQUAT.


CAUTION
 THE APPROXIMATE WEIGHT
 OF THIS EQUIPMENT IS
 150 LBS (68 KG).
 LIFTING SHOULD BE
 DONE USING PROPER
 LIFTING TECHNIQUES.
 ALWAYS WEAR
 APPROPRIATE PPE.
 ALWAYS LOCK OUT
 AND TAG OUT
 BEFORE WORKING ON
 THIS EQUIPMENT.
 ALWAYS USE
 PROPER SAFETY
 PROCEDURES.
 ALWAYS WEAR
 APPROPRIATE PPE.


THIS DRAWING IS PROPERTY OF THE COMPANY AND IS NOT TO BE COPIED OR ITS CONTENTS REPRODUCED IN ANY MANNER WITHOUT THE WRITTEN CONSENT OF THE COMPANY.

HERMETIC CENTRIFUGAL LIQUID CHILLER

CENTRIVAC[®]
 CH530 SCHEMATIC WIRING CVHF, CVHG, CDHF AND CDHG
 CUSTOMER SUPPLIED PRIMARY REACTOR OR AUTO-TRANSFORMER STARTER

2309-4914 F





WARNING


READ INSTRUCTIONS CAREFULLY BEFORE OPERATING THIS EQUIPMENT. FAILURE TO FOLLOW THESE INSTRUCTIONS MAY CAUSE PERSONAL INJURY OR PROPERTY DAMAGE.

AVERTISSEMENT

AVERTISSEMENT: LIRE ATTENTIVEMENT LES INSTRUCTIONS D'UTILISATION AVANT D'OPÉRER CE MATÉRIEL. LE NON-RESPECT DE CES INSTRUCTIONS PEUT CAUSER DES BLESSURES PERSONNELLES OU DES DOMMAGES À L'ÉQUIPEMENT.

CAUTION

DO NOT TOUCH MOVING PARTS OF THE EQUIPMENT. ONLY QUALIFIED PERSONNEL SHOULD SERVICER THIS EQUIPMENT. FAILURE TO FOLLOW THESE INSTRUCTIONS MAY CAUSE PERSONAL INJURY OR PROPERTY DAMAGE TO THE EQUIPMENT.




WIRE AND TERMINAL NOS ARE REFERENCE ONLY

THIS DRAWING IS THE PROPERTY OF THE WRITER. IT IS TO BE USED ONLY FOR THE PROJECT AND NOT BE COPIED OR ITS CONTENTS REPRODUCED IN ANY MANNER WITHOUT THE WRITER'S CONSENT.

HERMETIC CENTRIFUGAL LIQUID CHILLER

CENTRAVAC[®]
 CH530 SCHEMATIC WIRING CVHE, CVHF, CVHG, CDHF AND CDHG
 CUSTOMER SUPPLIED ACROSS THE LINE STARTER

2309-4915 F




CUSTOMER SUPPLIED ACROSS THE LINE STARTER

1 = CONTROL PANEL
 2 = STARTER PANEL
 3 = PURGE
 4 = UNIT MOUNTED DEVICE
 5 = PROVIDED BY OTHERS
 DASHED LINES INDICATE WIRING BY OTHERS

TRANSFORMER NOT REQUIRED
 IF PRIMARY 600 VAC
 AND SECONDARY 115 VAC
 REQ. IF OVER 4800 V.

SEE LINE 141



SEE LINE 141

WARNING


HAZARDOUS VOLTAGE
 EMERGENCY: ALL LIFTING POWER
 CONNECTIONS
 BEFORE ATTEMPTING TO POWER
 UP OR REPAIR THE EQUIPMENT
 FAILURE TO FOLLOW THESE INSTRUCTIONS
 CAN RESULT IN DEATH OR SERIOUS
 INJURY.

AVERTISSEMENT

HAZARDEUSE TENSION
 URGENCE: TOUS LES BRANCHEMENTS
 DE LA PUISSANCE
 AVANT D'ESSAYER DE METTRE EN
 MARCHÉ L'ÉQUIPEMENT
 ÉLECTRIQUE
 LE NON-RESPECT DE CES
 INSTRUCTIONS
 PEUT CAUSER LA MORT
 OU DES BLESSURES GRAVES.

CAUTION

DO NOT TOUCH THE EQUIPMENT
 WHILE IT IS RUNNING
 FAILURE TO DO SO MAY CAUSE
 DAMAGE TO THE EQUIPMENT.




WIRE AND TERMINAL NOS ARE REFERENCE ONLY


THIS DRAWING IS PROPERTY OF THE WRITER-CONSEIL INC. IT IS TO BE USED WITHOUT PERMISSION OF THE WRITER-CONSEIL INC.

HERMETIC CENTRIFUGAL LIQUID CHILLER

CENTRAVAC[®]
 CH530 SCHEMATIC WIRING CVHF, CVHF, CVHG, CDHF AND CDHG
 CUSTOMER SUPPLIED SOLID STATE STARTER

2309-4916 F





WARNING

NEVER DISCONNECT OR RECONNECT POWER CABLES WHILE THE EQUIPMENT IS OPERATING. FAILURE TO DO SO MAY CAUSE DAMAGE TO THE EQUIPMENT.

AVERTISSEMENT

NEVER DÉCONNECTER NI RECONNECTER LES CÂBLES D'ALIMENTATION ALORS QUE L'ÉQUIPEMENT EST EN MARCHE. UNE ÉCHEC À LE FAIRE PEUT ENDOMMAGER L'ÉQUIPEMENT.

CAUTION

THIS DRAWING IS THE PROPERTY OF THE COMPANY. IT IS NOT TO BE REPRODUCED OR TRANSMITTED IN ANY FORM OR BY ANY MEANS, ELECTRONIC OR MECHANICAL, INCLUDING PHOTOCOPYING, RECORDING, OR BY ANY INFORMATION STORAGE AND RETRIEVAL SYSTEM, WITHOUT THE WRITTEN CONSENT OF THE COMPANY.



WIRES AND TERMINAL NOS ARE REFERENCE ONLY


THIS DRAWING IS THE PROPERTY OF THE COMPANY. IT IS NOT TO BE REPRODUCED OR TRANSMITTED IN ANY FORM OR BY ANY MEANS, ELECTRONIC OR MECHANICAL, INCLUDING PHOTOCOPYING, RECORDING, OR BY ANY INFORMATION STORAGE AND RETRIEVAL SYSTEM, WITHOUT THE WRITTEN CONSENT OF THE COMPANY.

HERMETIC CENTRIFUGAL LIQUID CHILLER

CENTRAVAC[®]
CH530 SCHEMATIC WIRING CVHF, CVHG, CDHF AND CDHG
PRODUCTION PURGE

2309-4917D


- 61 —
- 62 —
- 63 —
- 64 —
- 65 —
- 66 —
- 67 —
- 68 —
- 69 —
- 70 —
- 71 —
- 72 —
- 73 —
- 74 —
- 75 —
- 76 —
- 77 —
- 78 —
- 79 —
- 80 —
- 81 —
- 82 —
- 83 —
- 84 —
- 85 —



HERMETIC CENTRIFUGAL LIQUID CHILLER


CENTRAVAC®
CH530 SCHEMATIC WIRING CVHE, CVHF AND CVHG
UNIT CONTROLS SCHEMATIC

2309-4919E



121
122
123
124
125
126
127
128
129
130
131
132
133
134
135
136
137
138
139

140
141
142
143
144
145
146
147
148
149
150
151
152
153
154
155
156
157
158
159
160
161
162
163
164
165
166
167
168
169
170
171
172
173
174
175



WARNING
Hazardous voltage may be present on this equipment. Before servicing, disconnect the power and lock out the main power supply. Failure to do so may cause damage to the equipment.

AVERTISSEMENT
Un potentiel de tension dangereuse peut être présent sur cet équipement. Avant toute intervention, déconnectez l'alimentation et bloquez l'alimentation principale. Toute négligence peut entraîner des dommages à l'équipement.

CAUTION
Use COPR to connect the unit to the power supply. Failure to do so may cause damage to the equipment.

NOTE:
1. EXTERNAL AUTO STOP (EMERGENCY STOP) IS NOT USED WITH WZP NOT USED.


THIS DRAWING IS UNLESS OTHERWISE SPECIFIED TO BE COPIED AND USED WITHOUT THE WRITTEN CONSENT OF THE COMPANY.


HERMETIC CENTRIFUGAL LIQUID CHILLER

CENTRAVAC®

CH530 SCHEMATIC WIRING CVHE, CVHF AND CVHG SYSTEM CONTROLS SCHEMATIC

2309-4920E





WARNING
 HAZARDOUS VOLTAGE
 DISCONNECT ALL POWER SOURCES
 INCLUDING MAIN SUPPLY CIRCUITS
 BEFORE ATTEMPTING TO SERVICE
 FAILURE TO DISCONNECT ALL POWER
 SOURCES CAN CAUSE DEATH OR
 SERIOUS INJURY.


AVERTISSEMENT
 DANGER
 TENSION ÉLECTRIQUE DANGÉREUSE
 DÉBRANCHER TOUS LES ALIMENTATIONS
 ÉLECTRIQUES Y COMPRIS LES CIRCUITS
 D'ALIMENTATION PRINCIPALE AVANT
 D'ESSAYER DE RÉPARER L'ÉQUIPEMENT
 NE PAS RÉPARER L'ÉQUIPEMENT
 SANS DÉBRANCHER TOUS LES ALIMENTATIONS
 ÉLECTRIQUES PEUT CAUSER LA MORT
 OU DE GRAVES BLESSURES.


CAUTION
 USE CORRECT WIRING TECHNIQUE
 UNIT TERMINALS ARE NOT TO BE
 CONNECTED TO OTHER TERMINALS
 FAILURE TO DO SO MAY CAUSE
 DAMAGE TO THE EQUIPMENT.

THIS DRAWING IS UNLESS OTHERWISE SPECIFIED TO BE CORDED
 BY THE CUSTOMER. THE WRITER COMPANY IS NOT RESPONSIBLE FOR
 THE WRITER COMPANY'S LIABILITY.

HERMETIC CENTRIFUGAL LIQUID CHILLER
 CENTRAVAC®
 CH530 SCHEMATIC WIRING CVHE, CVHF AND CVHG
 OPTIONS SCHEMATIC

2309-4921 D





WARNING
 DISCONNECT ALL TRACER EQUIPMENT FROM ALL AC POWER SOURCES BEFORE ATTEMPTING TO MAKE ANY CONNECTIONS TO THIS EQUIPMENT. FAILURE TO DO SO MAY CAUSE DAMAGE TO THE EQUIPMENT.


AVERTISSEMENT
 DÉBRANCHER TOUS LES ÉQUIPEMENTS DE TRACER DE TOUS LES ALIMENTATIONS EN COURANT ALTERNATIF AVANT D'ESSAYER DE FAIRE DES CONNEXIONS À CE MATÉRIEL. L'ÉCHEC À LE FAIRE PEUT ENDOMMAGER L'ÉQUIPEMENT.


CAUTION
 ONLY CERTIFIED TECHNICIANS ONLY IT IS DESIGNED FOR ALIQUOT USE ONLY. FAILURE TO DO SO MAY CAUSE DAMAGE TO THE EQUIPMENT.

CONNECTION DIAGRAM
 FIELD CONNECTION - TRANE STARTER
 CH 530
 CVHE,CVHF,CVHG

2309-4935E


UNIT CONTROL PANEL





EVAPORATOR WATER FLOW INTERLOCK (REQUIRED)

CONDENSER WATER FLOW INTERLOCK (REQUIRED)



SIMPLEX FIELD WIRING CIRCUIT SELECTION INFORMATION

WIRE # OR DEVICE	CIRCUIT SELECTION INFORMATION
Supply and Motor leads	See name plate; minimum circuit ampacity
1A, 2A, GRN/ YEL	4000VA @ 115 VAC
3B, 4B, 13A*, 15A*, 16A*, 18A*	Contact Rating - 2.88A Inductive, 1/3 HP, 0.25KW @ 115VAC
9A, 10A	Pump Motor - 1 phase 3/4 HP, 11.7 Full Load Amps @ 115VAC
5H1, 2, 4, 6, 7, 8, 10, 11	Contact Rating - 2.88A Inductive, 1/3 HP, 0.25KW @ 115VAC
5K1, 2	Contact Rating - 2.88A Inductive, 1/3 HP, 0.25KW @ 115VAC
5A7, WB4	Twisted Shielded pair, 30 Volts, max length 1500 feet, Beldon type 8760 recommended
5S3, 4, 5, 6, 7, 8	24 VDC 12mA resistive load
5A1, 2, 3, 4, 5, 6	2-10 VDC or 4-20mA Input/Output
236*, 237*, 238*, 239*, 240*, 241*	See Trane Specification S6516-0513
5CT4*, 5CT5*, 5CT6*; white/ black	See Trane Specification S6516-0513

*indicates customer supplied starter wiring

NOTES:

- DASHED LINES INDICATE FIELD WIRING BY OTHERS. CHECK SALES ORDER TO DETERMINE WHICH OPTIONS ARE SPECIFIED.
- DO NOT ROUTE LOW VOLTAGE (30V MAX) WITH CONTROL VOLTAGE (115V) AND DO NOT POWER UNIT UNTIL CHECK-OUT AND START-UP PROCEDURES HAVE BEEN COMPLETED.
- EVAPORATOR AND CONDENSER FLOW SWITCHES ARE REQUIRED. THEY CONTAIN DPDT CONTACTS. THE SEPERATE FLOW SWITCHES ARE RUN IN SERIES WITH SEPERATE AUX CONTACTS FOR THE CONDENSER PUMP AND SEPERATE AUX CONTACTS FOR THE EVAPORATOR PUMP. THEY MUST BE INSTALLED AND WIRED TO THE APPROPRIATE TRANE PANEL BY THE INSTALLING CONTRACTOR. PURCHASE OF SWITCHES FROM THE TRANE CO. IS OPTIONAL.
- SEE INSET "A" FOR CONNECTIONS OF MEDIUM VOLTAGE STARTERS, REMOTE ACROSS THE LINE, REMOTE AUTO TRANSFORMER AND REMOTE PRIMARY REACTOR.

⚠ WARNING

HAZARDOUS VOLTAGE!
DISCONNECT ALL ELECTRIC POWER INCLUDING REMOTE DISCONNECTS BEFORE SERVICING.
FAILURE TO DISCONNECT POWER BEFORE SERVICING CAN CAUSE SEVERE PERSONAL INJURY OR DEATH.

⚠ AVERTISSEMENT


VOLTAGE HASARDEUX!
DECONNECTEZ TOUTES LES SOURCES ELECTRIQUES INCLUANT LES DISJONCTEURS SITUES A DISTANCE AVANT D'EFFECTUER L'ENTRETIEN.
FAUTE DE DECONNECTER LA SOURCE ELECTRIQUE AVANT D'EFFECTUER L'ENTRETIEN PEUT ENTRAINER DES BLESSURES CORPORELLES SEVERES OU LA MORT.

⚠ CAUTION

USE COPPER CONDUCTORS ONLY!
UNIT TERMINALS ARE NOT DESIGNED TO ACCEPT OTHER TYPES OF CONDUCTORS.
FAILURE TO DO SO MAY CAUSE DAMAGE TO THE EQUIPMENT.




**CONNECTION DIAGRAM
FIELD CONNECTION
CUSTOMER SUPPLIED STARTER
CH 530
CVHE,CVHF,CVHG**


2309-4936E



CONNECTION DIAGRAM
UNIT WIRING STANDARD
CH 530
CVHE,CVHF,CVHG




UNIT CONTROL PANEL





MOTOR WINDING TEMPERATURE JUNCTION BOX

- NOTES:
1. WATER TEMP. SENSORS MAY BE CONNECTED TO 4-WIRE COMMUNICATION LINK CABLE WB2 FOR RIGHT HAND END OR WB3 FOR LEFT HAND END DEPENDING ON WATER BOX PASS ARRANGEMENT.
 2. WIRES 1A, 2A, 3B, 4B, 9A, 10A ARE INSTALLED WHEN YOU HAVE USTR OR USID STARTERS.





WARNING
HAZARDOUS VOLTAGE!
DISCONNECT ALL ELECTRIC POWER INCLUDING REMOTE DISCONNECTS BEFORE SERVICING.
FAILURE TO DISCONNECT POWER BEFORE SERVICING CAN CAUSE SEVERE PERSONAL INJURY OR DEATH.

AVERTISSEMENT
VOLTAGE HASARDEUX!
DECONNECTEZ TOUTES LES SOURCES ELECTRIQUES INCLUANT LES DISJONCTEURS SITUES A DISTANCE AVANT D'EFFECTUER L'ENTRETIEN.
FAUTE DE DECONNECTER LA SOURCE ELECTRIQUE AVANT D'EFFECTUER L'ENTRETIEN PEUT ENTRAINDER DES BLESSURES CORPORELLES SEVERES OU LA MORT.

CAUTION
USE COPPER CONDUCTORS ONLY!
UNIT TERMINALS ARE NOT DESIGNED TO ACCEPT OTHER TYPES OF CONDUCTORS.
FAILURE TO DO SO MAY CAUSE DAMAGE TO THE EQUIPMENT.

NOTES:

1. WATER TEMP. SENSORS MUST BE CONNECTED TO 4 WBS CONDUIT RACKS (RACKS) WBS-2 FOR RIGHT HAND END OR WBS-3 FOR LEFT HAND END (DEPENDING ON WAVE OR SURF PANE ARRANGEMENT).
2. WIRING SHOWN IS FOR UNLIMITED CONTROL. IF SHORTS EXISTER, PLEASE SEE LINE. B09-4935 OR IF CUSTOMER SUPPLIED BY WAVE SEE DWG. 2599-4934.








<p>WARNING</p> <p>HAZARDOUS VOLTAGES IS PRESENT IN ALL ELECTRICAL PARTS AND TO BE KEPT AWAY FROM ELECTRICAL PARTS BEFORE SERVICING.</p> <p>NO ANY TOUCHING POWER SOURCE & ELECTRICAL PARTS BEFORE PERSONAL SAFETY IS SECURED.</p> <p>AVERTISSEMENT</p> <p>HAZARDEUSES TENSIONS PRESENTENT DANS TOUS LES PARTIES ELECTRIQUES. NE TOUCHER AUCUNE PARTIE ELECTRIQUE - EXTRACTION AVANT D'ETRE SECURISES PAR LA SOURCE ELECTRIQUE. ASSURER VOTRE SECURITE PERSONNELLE EN TOUJOURS PORTER UN EQUIPEMENT DE SECURITE APPROPRIE (GILET, CASQUE, CHAUSSETTES, GANTS) EN TOUS MOMENTS.</p> <p>CAUTION</p> <p>USE CORRECT WIRING TECHNIQUE WIRING TERMINALS ARE NOT DESIGNED TO ACCEPT WIRE OF DIFFERENT CONDUCTIVITY. FAILURE TO USE SO MAY CAUSE DAMAGE TO THE EQUIPMENT.</p>

CONNECTION DIAGRAM PURGE CONTROL PANEL

CH 530
CVHE, CVHF, CVHG
PRODUCTION

2309-4939 D





2309-4922 D

CH530 SCHEMATIC WIRING CVHE, CVHF, CVHG, CDHF AND CDHG
LEGEND

DEVICE	DESCRIPTION
1A1	24VDC POWER SUPPLY NO 1
1A2	24VDC POWER SUPPLY NO 2
1A4	CONDENSER HIGH PRESSURE CUTOFF SWITCH INPUT
1A5 (1)/(2)	EVAPORATOR AND CONDENSER WATER PUMP, OIL TANK HEATER AND ICE BUILDING INDICATOR RELAYS
1A5 (3)	OIL TANK HEATER CONTROL RELAY
1A6	EVAPORATOR AND CONDENSER WATER FLOW SWITCH/INTERLOCK INPUTS
1A7	OIL REFRIGERANT PUMP MOTOR CONTROL RELAY
1A8 (1)	NON LATCHING AND LATCHING ALARM LINE MODE AND RUNNING INDICATOR RELAYS
1A8 (2)	OPERATING STATUS PROGRAMMABLE RELAYS
1A9 (1)	HEAD ROLLER MOTOR MAXIMUM CAPACITY AND PURGE ALARM INDICATOR RELAYS
1A9 (2)/(3)	OPERATING STATUS PROGRAMMABLE RELAYS
1A11	FREE COOLING INHIBIT OUTPUTS
1A12	HOT GAS BYPASS VALVE CONTROL RELAY
1A13	EXTERNAL AND INTERNAL EMERGENCY STOP INPUTS
1A14	COMM4 OR COMM2 MODULE
1A15	% RLA COMPRESSOR PRESSURE CONDENSER REFRIGERANT PRESSURE OUTPUTS
1A16	EXTERNAL CURRENT LIMIT AND CHILLED WATER SETPOINT INPUTS
1A17	EXTERNAL BASE HEATING SETPOINT AND REFRIGERANT MONITOR INPUTS
1A18	EXTERNAL BASE LOADING AND EXTERNAL HOT WATER CONTROL ENABLE/DISABLE INPUTS
1A19	EXTERNAL ICE BUILDING COMMAND INPUT
1A20	EXTERNAL FREE COOLING COMMAND AND FREE COOLING VALVES CLOSED INPUTS
1A21	EVAPORATOR AND CONDENSER WATER DIFFERENTIAL PRESSURE INPUTS
1A22	DYNAMVIEW
1A23	STARTER MODULE
1A24	STARTER FAULT INPUT
1A25	CIRCUIT 1 AND 2 EXTERNAL LOCKOUT INPUTS
1A26	MOTOR WINDING TEMPERATURE 1, 2 AND 3 INPUTS
1E1	CONTROL POWER FILTER
1Q1	STARTER CONTROL CIRCUIT BREAKER
1Q2	PURGE CONTROL CIRCUIT BREAKER
1Q3	UNIT CONTROL CIRCUIT BREAKER
1Q4	OUTLET MOTOR WINDING CIRCUIT BREAKER
1Q5	OUTLET MOTOR WINDING CIRCUIT BREAKER
1T1	CONTROL POWER TRANSFORMER
1T1	CONTROL PANEL TERMINAL BLOCK
2A1	STARTER MODULE
2A2	ADAPTIVE FREQUENCY DRIVE
2A3	STARTER POWER SUPPLY
2A4	SOLID STATE STARTER
2A4-K1	STARTER FAULT CONTROL RELAY
2A4-K2	STARTER FAULT CONTROL RELAY
2A5	STARTER FAULT INPUT
2A5 (4)	INPUT INDICATOR
2A6	FILTER CAPACITORS
2A7 (4)	LINE SYNC PULS
2A7 (5)	ENGINE GENERATOR START/STOP CONTROL RELAY
2A8	ENGINE GENERATOR UP-TO-SPEED/FREQUENCY AND STARTER DRIVE FAULT INPUTS
2A9	ENGINE GENERATOR SPEED SIGNAL OUTPUT
2A12	ADAPTIVE FREQUENCY DRIVE AC LINE I/O
2A32	ADAPTIVE FREQUENCY DRIVE COMMUNICATION CARD

DEVICE	DESCRIPTION
3L2	PURGE PUMPOUT VALVE
3L3	PURGE REGENERATION VALVE
3M6	PURGE CONDENSING UNIT MOTOR
3M7	PURGE CONDENSING UNIT FAN MOTOR
3R1	PURGE COMPRESSOR REFRIGERANT SUCTION TEMPERATURE SENSOR
3R2	PURGE CARBON TANK TEMPERATURE SENSOR
3R3	PURGE CONDENSER SATURATED REFRIGERANT TEMPERATURE SENSOR
3S1	CONDENSER HIGH PRESSURE CUTOFF SWITCH
3S9	PURGE LIQUID LEVEL SWITCH
3T1	PURGE AUTO TRANSFORMER
3T2	PURGE CONTROL POWER TRANSFORMER
3X1	PURGE PANEL TERMINAL BLOCK
4B1	EVAPORATOR WATER DIFFERENTIAL PRESSURE TRANSDUCER
4B2	CONDENSER WATER DIFFERENTIAL PRESSURE TRANSDUCER
4C1	OUTLET MOTOR WINDING CIRCUIT BREAKER
4E1	OIL TANK HEATER
4K8	OUTLET MOTOR WINDING CIRCUIT BREAKER
4M1	CONDENSING UNIT MOTOR
4M2	INLET GUIDE VANE FIRST STAGE ACTUATOR
4M3	OIL/REFRIGERANT PUMP MOTOR
4M4	INLET GUIDE VANE SECOND STAGE ACTUATOR
4M5	HOT GAS BYPASS VALVE
4M6	COOLANT CIRCULATING PUMP MOTOR
4M12	FREE COOLING LIQUID LINE VALVE
4M13	FREE COOLING GAS LINE VALVE
4M12,3,4	MOTOR WINDING TEMPERATURE 1, 2 AND 3
4R1	INBOARD BEARING TEMPERATURE SENSOR
4R2	OUTBOARD BEARING TEMPERATURE SENSOR
4R3	OIL PUMP DISCHARGE PRESSURE TRANSDUCER
4R4	OIL TANK PRESSURE TRANSDUCER
4R5	OIL TANK TEMPERATURE SENSOR
4R6	EVAPORATOR INLET WATER TEMPERATURE SENSOR
4R7	EVAPORATOR LEAVING WATER TEMPERATURE SENSOR
4R8	CONDENSER ENTERING WATER TEMPERATURE SENSOR
4R9	CONDENSER LEAVING WATER TEMPERATURE SENSOR
4R10	EVAPORATOR SATURATED REFRIGERANT TEMPERATURE SENSOR
4R11	CONDENSER SATURATED REFRIGERANT TEMPERATURE SENSOR
4R13	OUTDOOR AIR TEMPERATURE SENSOR
4R14	SECOND CONDENSER ENTERING WATER TEMPERATURE SENSOR
4R15	SECOND CONDENSER LEAVING WATER TEMPERATURE SENSOR
4R16	CONDENSER DISCHARGE REFRIGERANT TEMPERATURE SENSOR
4R22	CONDENSER REFRIGERANT PRESSURE TRANSDUCER
4S2	COOLANT CIRCULATING PUMP PRESSURE SWITCH
5A10	SOLID STATE STARTER
5A10-K1	STARTER FAULT CONTROL RELAY
5A10-K2	STARTER FAULT CONTROL RELAY
5CT4,5,6	STARTER DRIVE CURRENT TRANSFORMERS
5F1,2,3	CONTROL POWER PRIMARY FUSING
5F4	CONTROL POWER SECONDARY FUSE
5H1	CHILLER LATCHING ALARM INDICATOR

2A33	ADAPTIVE FREQUENCY DRIVE GATE-KILL
2C1	POWER FACTOR CORRECTION CAPACITORS
2F1,2,3	CONTROL POWER TRANSFORMER FUSING
2F1,2 (4)	PRIMARY TRANSFORMER FUSING
2F3 (4)	CONTROL POWER SECONDARY FUSE
2F4	CONTROL POWER SECONDARY FUSE
2F4,5,6 (4)	PRIMARY FILTER CAPACITOR FUSING
2F7,8,9	PRIMARY LINE SYNC FUSING
2F10,11,12	PRIMARY PRECHARGE RESISTOR FUSING
2F13	CONTROL POWER SECONDARY FUSE
2K1	START CONTACTOR
2K2	RUN CONTACTOR
2K3 (4)	SHORTING CONTACTOR
2K4	TRANSITION CONTACTOR
2K4 (4)	PRECHARGE CONTACTOR
2K7	CONDENSER HIGH PRESSURE CUTOFF CONTROL RELAY
2K9	GROUND FAULT RELAY
2K10	POWER FACTOR CORRECTION CAPACITOR ISOLATION CONTACTOR
2K11	INTERLOCKING RELAY
2M1,2,3 (4)	OIL PUMP INTERPOSING RELAY
2Q1	FAN MOTORS
2Q2	MAIN CIRCUIT BREAKER
2Q2K1	CONTROL POWER SECONDARY CIRCUIT BREAKER
2R1,2,3	TEST RUN CONTROL RELAY
2R4,5,6	TRANSITION RESISTORS
2S1	PRECHARGE RESISTORS
2T1,2,3	CONTROL POWER DISCONNECT SWITCH
2T5	LINE CURRENT TRANSFORMERS
2T8,9	CONTROL POWER TRANSFORMER
2T15	LINE POTENTIAL TRANSFORMERS
2T17,18,19	GROUND FAULT TORQUES
2V	LINE POTENTIAL TRANSFORMERS
2X1,2	METAL OXIDE VARISTOR
2X3	STARTER PANEL TERMINAL BLOCKS
2Z1	LINE POTENTIAL TERMINAL BLOCK
3A1	R/C SNUBBER
3A2	PURGE PUMP/OUT AND EXHAUST VALVE CONTROL
3A3	PURGE CONDENSING UNIT CONTROL RELAY
3A4	PURGE PUMP/OUT, CARBON TANK HEATER, REGENERATION VALVE AND ALARM RELAYS
3A5	PURGE LIQUID LEVEL SWITCH INPUT
3A6	PURGE POWER SUPPLY
3A10	PURGE CHILLER RUNNING INPUT
3C5	PURGE DYNAMVIEW
3C6	PURGE CONDENSING UNIT CAPACITOR
3E1	PURGE PUMP/OUT COMPRESSOR CAPACITOR
3F1	PURGE CARBON TANK HEATER
3F2	PURGE AUTO-TRANSFORMER FUSE
3L1	PURGE CONTROL POWER TRANSFORMER FUSE
	PURGE EXHAUST VALVE

NOTE:

- (1) = AS USED ON CV/HE, CV/HF AND CV/HG UNITS.
- (2) = AS USED ON LH CIRCUIT OF CDHF AND CDHG UNITS.
- (3) = AS USED ON RH CIRCUIT OF CDHF AND CDHG UNITS.
- (4) = AS USED WITH ADAPTIVE FREQUENCY DRIVE STARTERS.
- (5) = AS USED WITH ENGINE-GENERATOR SET.

5H2	CHILLER NON-LATCHING ALARM INDICATOR
5H4	PURGE ALARM INDICATOR
5H4 (2)	CIRCUIT 2 PURGE ALARM INDICATOR
5H6	CHILLER RUNNING INDICATOR
5H7	CHILLER LIMIT MODE INDICATOR
5H8	ICE BUILDING INDICATOR
5H9	FREI COOLING INDICATOR
5H10	CHILLER HEAD RELIEF REQUEST INDICATOR
5H11	CHILLER MAXIMUM CAPACITY INDICATOR
5H12	CIRCUIT 1 PURGE ALARM INDICATOR
5H13	CIRCUIT 1 RUNNING INDICATOR
5H14	CIRCUIT 2 RUNNING INDICATOR
5H15	CHILLER ALARM INDICATOR
5H16	CIRCUIT 3 ALARM INDICATOR
5H17	PURGE ALARM INDICATOR
5H18	PURGE ALARM INDICATOR
5K1	EVAPORATOR WATER PUMP CONTROL RELAY
5K2	CONDENSER WATER PUMP CONTROL RELAY
5K11	INT FLOODING RELAY
5K12	STAIR CONTACTOR
5K91	RUN CONTACTOR
5K13	PURGE CHILLER RUNNING RELAY
5Q1	MAIN CIRCUIT BREAKER
5S1	EVAPORATOR WATER FLOW SWITCH/INTERLOCK
5S2	CONDENSER WATER FLOW SWITCH/INTERLOCK
5S3	EXTERNAL AUTO-STOP SWITCH
5S4	EMERGENCY STOP SWITCH
5S5	EXTERNAL BASE LOADING ENABLE/DISABLE SWITCH
5S6	EXTERNAL HOT WATER CONTROL ENABLE/DISABLE SWITCH
5S7	EXTERNAL HOT WATER CONTROL COMMAND SWITCH
5S8	EXTERNAL ICE BUILDING COMMAND SWITCH
5S9	EXTERNAL FREE COOLING SWITCH
5S10	CIRCUIT 1 EXTERNAL LOCKOUT SWITCH
5T1,2,3	CIRCUIT 2 EXTERNAL LOCKOUT SWITCH
5T5	LINE CURRENT TRANSFORMERS
5T6	CONTROL POWER TRANSFORMER
5T9	12-PULSE AUTO-TRANSFORMER
5T11,18,19	LINE POTENTIAL TRANSFORMER
5X1	LINE POTENTIAL TRANSFORMERS
5X3	TERMINAL BLOCK
5X3	LINE POTENTIAL TERMINAL BLOCK
6K1	ENGINE GENERATOR START-STOP CONTROL
6K2	ENGINE GENERATOR DRIVE FAULT CONTROL
6K3	ENGINE GENERATOR UP-TO-SPEED/FREQUENCY CONTROL
6O1	ENGINE GENERATOR CIRCUIT BREAKER
6X1,2,6	ENGINE GENERATOR TERMINAL BLOCKS
7K2	RUN CONTACTOR
7K3	SHORTING CONTACTOR
7R1,2,3	TRANSITION RESISTORS
ISW	ISOLATION SWITCH

DEVICE LOCATION PREFIX CODE

- 1 = MAIN CONTROL PANEL
- 2 = STARTER PANEL OR ADAPTIVE FREQUENCY DRIVE
- 3 = PURGE
- 4 = UNIT MOUNTED DEVICE
- 5 = PROVIDED BY OTHERS
- 6 = ENGINE DRIVEN GENERATOR
- 7 = REDUCED VOLTAGE PANEL



Trane
A business of American Standard Companies
www.trane.com

For more information contact your local district office or e-mail us at comfort@trane.com

Literature Order Number	CVHE-SVN03C-EN
File Number	SL-RF-CVHE-CTV-SVN03C-EN-303
Supersedes	CVHE-SVN03B-EN-902
Stocking Location	Inland

*Trane has a policy of continuous product and product data improvement and reserves the right to change design and specifications without notice.
Only qualified technicians should perform the installation and servicing of equipment referred to in this publication.*