




TRANE™

**Operation
Maintenance**

CVHE-M-2C

Library	Service Literature
Product Section	Refrigeration
Product	Gen. Liq. Chillers--Water-Cooled
Model	CVHE, Cooling-Only and Heat-Rec.
Literature Type	Operation/Maintenance
Sequence	2C
Date	June 1985
File No.	SV-RF-CTV-CVHE-M-2C-685
Supersedes	CVHE-M-2B (7/84)

**CENTRIFUGAL
LIQUID CHILLER:
COOLING-ONLY AND
HEAT-RECOVERY
DIRECT-DRIVE
CENTRAVAC**



Models CVHE 013 thru CVHE 125

Drwg. No. X39640204-02

Since The Trane Company has a policy of continuous product improvement, it reserves the right to change specifications and design without notice. The installation and servicing of the equipment referred to in this booklet should be done by qualified, experienced technicians.

TABLE OF CONTENTS -----

<u>Subject</u>	<u>Page</u>	<u>Subject</u>	<u>Page</u>
MODEL NUMBER DESCRIPTION	3	PERIODIC MAINTENANCE	35
INTRODUCTION	3	Daily Maintenance & Checks	35
MECHANICAL OPERATION	3	Weekly Maintenance	36
Cooling-Only Cycle	6	Every Three Months	36
Heat-Recovery Cycle	7	Every Six Months	37
Compressor Lubrication System	8	Off-Season Maintenance	37
Oil Cooler	9	Annual Maintenance	38
Motor Cooling System	10	Other Maintenance	
Purge System:		Recommendations	39
A thru D-Design Units	10	MAINTENANCE PROCEDURES	41
E and Later-Design Units	12	Purge Unit Maintenance:	
SYSTEM CONTROL	15	Drive Belt	41
Control Panel	15	Purge Unit Oil Change	42
Electrical Sequence of Operation:		Purge Drum Cleanup	43
Electronic Capacity Control	17	Drum Water Elimination	46
Control Options--		Lubrication	46
Pneumatic Capacity Control	22	Refrigerant Charge	46
Sequence Panel	24	Cleaning the Condenser	47
Free-Cooling	26	Cleaning the Auxiliaries	48
Hot Gas Bypass	28	Compressor Oil	48
Demand-Limit Interface	29	Draining the Oil Sump	48
Chilled Water Reset Interface	30	Filling the Oil Sump	49
Chilled Water Reset	31	Control Settings and Adjustments	49
UNIT START-UP/SHUTDOWN PROCEDURES	32	TRUBLE ANALYSIS	50
Daily Unit Start-Up	32	OPERATING LOG	55
Daily Unit Shutdown	33		
Seasonal Unit Start-Up	33		
Seasonal Unit Shutdown	34		

Notice

The Trane Company urges that all HVAC servicers working on Trane equipment, or any manufacturer's products, make every effort to eliminate, if possible, or vigorously reduce the emission of CFC, HCFC and HFC refrigerants to the atmosphere resulting from installation, operation, routine maintenance, or major service on this equipment. Always act in a responsible manner to conserve refrigerants for continued use even when acceptable alternatives are available.

Conservation and emission-reduction can be accomplished by following recommended Trane service and safety procedures published in Trane General Service Bulletin CTV-SB-81. The information and procedures provided in CTV-SB-81 supersedes those published in this manual. Copies of this bulletin may be obtained by contacting your local Trane commercial product representative.

The Trane Company
La Crosse, Wisconsin 54601-7599
Printed in U.S.A.

©American Standard Inc. 1985

MODEL NUMBER DESCRIPTION -----

All standard Trane products are identified by a multiple-character model number that precisely identifies a particular type of unit. An explanation of the alphanumeric identification code used with CenTraVac units is provided on the next two pages. Its use will enable the owner/operator, installing contractor(s), and service engineer(s) to define the operation, components and options for a particular unit.

Be sure to refer to the model number stamped on the unit nameplate when ordering replacement parts or requesting service. (NOTE: Trane-built unit-mounted starters are identified by a separate number found on the starter.)

INTRODUCTION -----

This manual describes the operation and maintenance of Model CVHE Cooling-Only and Heat-Recovery CenTraVac liquid chillers. Its use will enable the owner/operator to understand the chiller systems, and to successfully operate and maintain the machine. Trouble analysis information is provided at the end of this manual to allow the operator to analyze and resolve a number of system malfunctions, if any should occur. (If mechanical problems do occur, however, Trane recommends that trained service personnel be contacted to ensure proper diagnosis and repair of the unit.)

MECHANICAL OPERATION -----

Each CVHE unit is comprised of five basic components: the evaporator, three-stage compressor, water-cooled condenser, two-stage economizer, and related interconnecting piping. A heat-recovery or auxiliary condenser can be factory-added to the basic unit assembly to provide a heat-recovery cycle. Refer to Figure 1 for an illustration of a typical unit.





FIGURE 1 - Typical CVHE Chiller (General Unit Assembly Shown)

CVHE MODEL NUMBER TREE AND DESCRIPTION



DIGITS 1, 2: CENTRAVAC

DIGIT 3: DIRECT-DRIVE

DIGIT 4: DEVELOPMENT SEQUENCE

DIGITS 5, 6, 7: COMPRESSOR DESIGNATORS

013	023	036	056	089
014	025	040	063	090
016	028	045	071	100
018	032	050	080	112
020				125
				SSS

DIGIT 8: NOMINAL VOLTAGE

A = 200/60/3	H = 575/60/3
B = 208/60/3	J = 600/60/3
C = 230/60/3	K = 2300/60/3
D = 380/60/3	L = 2400/60/3
E = 440/60/3	M = 4000/60/3
F = 460/60/3	N = 4160/60/3
G = 480/60/3	S = Special

DIGIT 9: UNIT TYPE

- A = Hermetic Standard
- B = Hermetic Heat-Recovery
- C = Hermetic Aux. Condenser
- D = Hermetic Free-Cooling
- S = Special

DIGIT 10: DESIGN SEQUENCE

DIGIT 11: ECONOMIZER & HGBP

- 2 = Std. Economizer; Flanged Elbow
- 4 = Std. Economizer w/HGBP; Flanged Elbow
- S = Special

DIGIT 12: COMPRESSOR MOTOR KW

A = 96	G = 172	P = 361	X = 742
B = 105	H = 184	R = 403	Y = 853
C = 118	J = 204	T = 453	Z = 954
D = 131	K = 230	U = 513	S = Special
E = 142	L = 256	V = 586	
F = 155	N = 323	W = 653	

DIGIT 13: COMPRESSOR MOTOR VENDOR

DIGITS 14, 15, 16: IMPELLER CUTBACK DIA.

235 = 23.50	260 = 26.00
240 = 24.00	265 = 26.50
245 = 24.50	270 = 27.00
250 = 25.00	275 = 27.50
255 = 25.50	SSS = Special

DIGIT 17: EVAP. BUNDLE SIZE

DIGIT 18: EVAP. LENGTH

- C = Short
- D = Long
- S = Special

DIGIT 19: EVAP. TUBE SPEC.

- A = .028 Cu
- B = .035 Cu
- M = .035 Cu/Ni; 90/10
- E = .028 Cu (IE)
- S = Special

DIGIT 20: EVAP. WATER PASS ARRGMT.

DESIGNATOR	NUMBER OF PASSES	TYPE	CONNECTION ARRANGEMENT*			
			INLET		OUTLET	
			RIGHT OR LEFT HAND	END FRONT OR REAR	RIGHT OR LEFT HAND	END FRONT OR REAR
A	1	M	-	-	-	-
B	1	M	LH	F	RH	R
C	1	M	RH	F	LH	F
D	1	M	LH	F	RH	F
D	1	M	RH	F	LH	F
J	2	M	LH	F	LH	R
K	2	M	LH	F	LH	F
L	2	M	RH	F	RH	R
M	2	M	RH	F	RH	F
N	3	M	LH	F	RH	R
N	3	M	RH	F	LH	F
P	3	M	LH	F	LH	R
P	3	M	RH	F	RH	F
V	1	M	-	-	-	-
Z	2	M	RH	F	RH	F
Z	2	M	LH	F	LH	F
Z	3	M	-	-	-	-

*Type M = Mono Type M = Non-Mono Type
*Connection arrangement determined when facing control panel side of unit

DIGIT 21: EVAP. WORKING PRESSURE (WATER SIDE)

- A = Flanged 150 Psig
- B = Flanged 300 Psig
- C = Victaulic 150 Psig
- D = Victaulic 300 Psig
- E = Flanged 150 Psig (ASME)
- F = Victaulic 150 Psig (ASME)
- S = Special

DIGIT 22: COND. CONSTRUCTION (REFRIG. SIDE)

- 1 = Standard
- 2 = ASME
- S = Special

DIGIT 23: COND. BUNDLE SIZE (COOLING)

DIGIT 24: COND. LENGTH (COOLING)

- C = Short
- D = Long
- S = Special

DIGIT 25: COND. TUBE SPEC. (COOLING)

- A = .028 Cu
- B = .035 Cu
- C = .042 Cu
- M = .035 Cu/Ni; 90/10
- N = .042 Cu/Ni; 90/10
- X = .035 Cu/Ni; 70/30
- Y = .042 Cu/Ni; 70/30
- R = .049 Cu
- T = .049 Cu/Ni; 90/10
- E = .049 Cu/Ni; 70/30
- E = .028 Cu (IE)
- S = Special

DIGIT 26: COND. WATER PASS ARRGMT. (COOLING)

DESIGNATOR	NUMBER OF PASSES	TYPE	CONNECTION ARRANGEMENT*			
			INLET		OUTLET	
			RIGHT OR LEFT HAND	END FRONT OR REAR	RIGHT OR LEFT HAND	END FRONT OR REAR
A	1	M	-	-	-	-
B	1	M	LH	F	RH	R
C	1	M	RH	F	LH	F
D	1	M	LH	F	RH	F
D	1	M	RH	F	LH	F
F	2	M	LH	F	LH	R
F	2	M	RH	F	RH	R
D	2	M	LH	F	RH	F
H	2	M	RH	F	RH	R
J	2	M	LH	F	LH	R
L	2	M	LH	F	LH	F
L	2	M	RH	F	RH	R
M	2	M	RH	F	RH	F
V	1	M	-	-	-	-
Z	2	M	RH	F	RH	F
Z	2	M	LH	F	LH	F

*Type M = Mono Type M = Non-Mono Type
*Connection arrangement determined when facing control panel side of unit

DIGIT 27: COND. WORKING PRESSURE (COOLING WATER SIDE)

- A = Flanged 150 Psig
- B = Flanged 300 Psig
- C = Victaulic 150 Psig
- D = Victaulic 300 Psig
- E = Flanged 150 Psig (ASME)
- F = Victaulic 150 Psig (ASME)
- S = Special

DIGIT 28: COND. BUNDLE SIZE (HEATING)

DIGIT 29: COND. LENGTH (HEATING)

- 0 = None
- C = Short
- D = Long
- S = Special

DIGIT 30: COND. TUBE SPEC. (HEATING)

- 0 = None
- A = .028 Cu
- B = .035 Cu
- C = .042 Cu
- M = .035 Cu/Ni; 90/10
- N = .042 Cu/Ni; 90/10
- X = .035 Cu/Ni; 70/30
- Y = .042 Cu/Ni; 70/30
- R = .049 Cu
- T = .049 Cu/Ni; 90/10
- Z = .049 Cu/Ni; 70/30
- E = .028 Cu (IE)
- S = Special

DIGIT 31: COND. WATER PASS ARRGMT. (HEATING)

DESIGNATOR	NUMBER OF PASSES	TYPE	CONNECTION ARRANGEMENT					
			INLET			OUTLET		
			RIGHT OR LEFT HAND	END FRONT OR REAR	RIGHT OR LEFT HAND	END FRONT OR REAR	RIGHT OR LEFT HAND	END FRONT OR REAR
A	1	M	---	F	---	F	---	
B	1	M	---	R	---	R	---	
C	1	M	LH	F	RH	R	---	
C	1	M	RH	R	LH	F	---	
D	1	M	LH	R	RH	F	---	
D	1	M	RH	F	LH	R	---	
E	2	M	LH	F	LH	F	---	
F	2	M	LH	R	LH	R	---	
G	2	M	RH	F	RH	F	---	
H	2	M	RH	R	RH	R	---	
J	2	M	LH	F	LH	R	---	
K	2	M	LH	R	LH	F	---	
L	2	M	RH	F	RH	R	---	
M	2	M	RH	R	RH	F	---	
Y	1	MM	---	E	---	E	---	
Z	2	MM	RH	E	RH	E	---	
1	2	MM	LH	E	LH	E	---	
0								

0 = No Heat Recovery Condenser
 Type: M = Normal Type MM = Non-Magnetic Type
 *Connection arrangement determined when facing control panel side of unit

DIGIT 32: COND. WORKING PRESSURE (HEATING)

- 0 = None
- A = Flanged 150 Psig
- B = Flanged 300 Psig
- C = Victaulic 150 Psig
- D = Victaulic 300 Psig
- E = Flanged 150 Psig (ASME)
- F = Victaulic 150 Psig (ASME)
- S = Special

DIGIT 33: COND. SIZE (AUX. TUBE & BUNDLE)

- 0 = None
- A = .028 Cu; Small Bundle
- B = .028 Cu; Large Bundle
- C = .035 Cu; Small Bundle
- D = .035 Cu; Large Bundle
- E = .042 Cu; Small Bundle
- F = .042 Cu; Large Bundle
- J = .035 Cu/Ni; 90/10; Small Bundle
- K = .035 Cu/Ni; 90/10; Large Bundle
- L = .042 Cu/Ni; 90/10; Small Bundle
- M = .042 Cu/Ni; 90/10; Large Bundle
- S = Special

DIGIT 34: COND. PASS ARRGMT. (AUXILIARY)

DESIGNATOR	NUMBER OF PASSES	TYPE	CONNECTION ARRANGEMENT					
			INLET			OUTLET		
			RIGHT OR LEFT HAND	END FRONT OR REAR	RIGHT OR LEFT HAND	END FRONT OR REAR	RIGHT OR LEFT HAND	END FRONT OR REAR
A	1	M	---	F	---	F	---	
B	1	M	---	R	---	R	---	
C	1	M	LH	F	RH	R	---	
C	1	M	RH	R	LH	F	---	
D	1	M	LH	R	RH	F	---	
D	1	M	RH	F	LH	R	---	
E	2	M	LH	F	LH	F	---	
F	2	M	LH	R	LH	R	---	
G	2	M	RH	F	RH	F	---	
H	2	M	RH	R	RH	R	---	
J	2	M	LH	F	LH	R	---	
K	2	M	LH	R	LH	F	---	
L	2	M	RH	F	RH	R	---	
M	2	M	RH	R	RH	F	---	
Y	1	MM	---	E	---	E	---	
Z	2	MM	RH	E	RH	E	---	
1	2	MM	LH	E	LH	E	---	
0								

0 = No Auxiliary Condenser
 Type: M = Normal Type MM = Non-Magnetic Type
 *Connection arrangement determined when facing control panel side of unit

DIGIT 35: COND. WORKING PRESSURE (AUX. WATER SIDE)

- 0 = None
- A = Flanged 150 Psig
- B = Flanged 300 Psig
- C = Victaulic 150 Psig
- D = Victaulic 300 Psig
- E = Flanged 150 Psig (ASME)
- F = Victaulic 150 Psig (ASME)
- S = Special

DIGIT 36: ORIFICE*

- 1 = 4 Sizes Under
- 2 = 3 Sizes Under
- 3 = 2 Sizes Under
- 4 = 1 Size Under
- 5 = Nom. Size Orifice
- 6 = 1 Size Over
- 7 = 2 Sizes Over
- S = Special

*The CenTraVac computer selection program includes the proper orifice designator.

DIGIT 37: INSULATION & SHIPPING

DESIGNATOR	INSULATION	PACKAGING			ISOLATION	
		STD	STD EXPORT	FULL SHIPMENT EXPORT	NEOPRENE	SPRING
1	X	X			X	
2		X	X		X	
3	X		X		X	
4			X		X	
5	X			X	X	
6				X	X	
A	X	X				X
B		X				X
C	X		X			X
D			X			X
E	X			X		X
F			X			X
S	SPECIAL					

DIGIT 38: CONTROL PANEL

DESIGNATOR	ELECTRIC CONTROL	PNEUMATIC CONTROL	OPTION*			
			NUMBER OF ELAPSED TIME COUNTER	ELAPSED TIME METER	UL APPROVAL	CSA APPROVAL
A	X				X	
B	X					X
C	X				X	
D		X			X	
E	X					X
F	X	X			X	
G	X		X	X	X	
H	X		X	X	X	
J	X		X	X	X	
K	X		X	X	X	
L	X	X	X	X	X	
M	X	X	X	X	X	
0						

*X indicates the option(s) provided

DIGIT 39: STARTER

- 0 = w/o Starter
- 1 = w/Unit-Mounted Starter
- S = Special

DIGIT 40: OPTION

DESIGNATOR	STARTER OPTIONS*				
	AMMETER	VOLTMETER	CKT. BRKR.	HI INTERRUPT CAPACITY CKT. BREAKER	GROUND FAULT PROTECTION
A					
B	X				
C		X			
D	X	X			
E			X		
F	X		X		
G		X	X		
H	X	X	X		
J				X	
K	X			X	
L		X		X	
M	X	X		X	
N			X		X
P	X		X		X
R		X	X		X
T	X	X	X		X
U				X	X
V	X			X	X
W		X		X	X
Y	X	X		X	X
0					

*X indicates the starter option(s) included.




FIGURE 2 - CVHE Pressure/Enthalpy Curve

Following are discussions of the unit's cooling-only and heat-recovery modes of operation. A pressure/enthalpy diagram (shown in Figure 2) is provided to further illustrate unit operation.

COOLING-ONLY CYCLE

When the CVHE is functioning in the cooling mode, liquid refrigerant is distributed along the length of the evaporator and sprayed through small holes in a distributor (which runs the entire length of the shell) to uniformly coat each evaporator tube. Here, the liquid refrigerant absorbs enough heat from the system water circulating through the evaporator tubes to vaporize. The gaseous refrigerant is then drawn through the eliminators (which remove droplets of liquid refrigerant from the gas) and first-stage variable inlet guide vanes, and into the first-stage impeller. (The inlet guide vanes are designed to modulate the flow of gaseous refrigerant to meet system capacity requirements; they also prerotate the gas, allowing it to enter the impeller at an optimal angle that maximizes efficiency at all load conditions.)

Compressed gas from the first-stage impeller flows through the fixed, second-stage inlet vanes and into the second-stage impeller. Here, the refrigerant gas is again compressed, and then discharged through the third-stage variable guide vanes and into the third-stage impeller. Once the gas is compressed a third time, it is discharged into the condenser.

Baffles within the condenser shell distribute the compressed refrigerant gas evenly across the condenser tube bundle. Cooling tower water--circulated through the condenser tubes--absorbs heat from the refrigerant, causing it to condense. The liquid refrigerant then passes through an orifice plate and into the two-stage economizer.

The economizer reduces the energy requirements of the refrigeration cycle by eliminating the need to pass all of the gaseous refrigerant through the three stages of compression. See Figure 3. Notice that some of the liquid refrigerant will "flash" to a gas because of the pressure drop created by the orifice plates, thus further cooling the liquid refrigerant. This flash gas is then drawn directly from the first (Chamber A) and second (Chamber B) stages of




FIGURE 3 - Two-Stage Economizer

the economizer into the third- and second-stage impellers of the compressor, respectively. The remaining liquid refrigerant flows through another orifice plate (labelled "C" in Figure 3) to the evaporator.

NOTE: Some CVHE units are equipped with single-stage economizers. This type of economizer serves the same function as the two-stage economizer, but the flash gas is discharged only to the third stage of the compressor.

HEAT-RECOVERY CYCLE

The purpose of the heat-recovery cycle is to salvage the heat that is normally rejected to the atmosphere through the cooling tower, and put it to beneficial use. For example, a high-rise office building may experience simultaneous heating and cooling requirements during the winter months. With the addition of a heat-recovery cycle, the heat removed from the building cooling load can be transferred to that area of the building which requires heat. (Remember that a cooling load must exist to act as a heat source if the heat-recovery cycle is to be used.)

To provide a heat-recovery cycle, a heat-recovery condenser is added to the unit; see Figure 1. Though physically identical to the standard condenser, the heat-recovery condenser is piped into a heating circuit rather than to the cooling tower.

During the heat-recovery cycle, the unit operates just as it does in the cooling-only mode except that the cooling load heat is rejected to the heating water circuit rather than to the cooling tower water circuit. When hot water is required, the heating water circuit pumps energize. The water circulated through the heat-recovery (or auxiliary) condenser tube bundle by the pumps absorbs the cooling load heat from the compressed refrigerant gas discharged by the compressor. The heated water is then used to satisfy building comfort heating requirements.

NOTE: Unlike the heat-recovery condenser (which is designed to satisfy comfort heating requirements), the auxiliary condenser serves a preheat function only, and is used in those applications where hot water is needed for use in kitchens, lavatories, etc. While the operation of the auxiliary condenser is physically identical to that of the heat-recovery condenser, it is comparatively smaller in size, and its heating capacity is not controlled. (Because of its small size, The Trane Company does not recommend operating the auxiliary condenser alone.)

COMPRESSOR LUBRICATION SYSTEM

A schematic diagram of the compressor lubrication system is illustrated in Figure 4; this system supplies oil to the compressor motor bearings.

Oil is pumped from the oil tank (by a pump and motor located within the tank) through an oil pressure-regulating valve designed to maintain a net oil pressure of 18 to 20 psig. It is then filtered and sent to the compressor motor bearings. From here, the oil drains back to the oil tank through return lines. Notice that each oil return line is equipped with a sight glass; this enables the operator to check for oil flow when the oil pump is energized.

To ensure proper lubrication and prevent refrigerant from condensing in the oil tank, a 1000-watt heater is secured to the oil tank exterior. Operating in response to the oil temperature control (S10), this heater energizes as necessary to maintain an oil tank temperature of 150 to 160 F. When the chiller is operating, the temperature of the oil tank is typically 125 to 150 F.

Notice that the oil tank is vented between the compressor inlet vanes and the first-stage impeller suction cover; refer to Figure 4. On earlier models of CVHE chillers (i.e., "A" and "B"-design), this vent connection is located at the compressor suction elbow. During normal system operation, motor barrel pressure is greater than that of the oil tank. Therefore, any gaseous refrigerant that enters the motor bearing cavities is drawn toward the oil tank where it is removed by the vent line.

On chillers of "C" and subsequent design, any oil that collects in the suction cover area is pulled back to the oil tank by an ejector pump. This pump uses high-pressure condenser gas to draw the oil from the suction cover area back to the ejector; from the ejector, the oil is discharged into the oil tank. (In lieu of an ejector, a drain line between the first-stage suction cover and oil tank is used on "A" and "B"-design units to allow oil trapped in the suction cover to gravitate back to the oil tank when the machine is shut down.)

CAUTION: The oil tank vent must remain completely open on those units equipped with ejectors; closure of the vent line may hamper the return of oil to the oil tank and result in damage to the chiller.

NOTE: On those CVHE chillers with the vent connection located at the suction elbow, the vent valve should be four turns open.




FIGURE 4 - Compressor Lubrication and Motor-Cooling Systems

OIL COOLER (CVHE 036 THRU 125 ONLY)

Oil coolers are installed as a standard feature on CVHE 036 through 125 chillers. See Figure 5 for an illustration of the oil cooler assembly.

Oil--at approximately 150 to 160 F and 18 to 20 psig--is pumped from the oil tank, through the oil pressure-regulating valve, and into the oil cooler. The oil cooler is designed to maintain a leaving oil temperature of 130 to 140 F; temperature control is accomplished with a water-regulating valve that responds to a sensor in the bearing oil supply line. When the sensor detects an increase in oil temperature, the valve opens to allow more cooling water through the oil cooler. Conversely, the valve will limit water flow through the cooler when the sensor detects a drop in oil temperature.




FIGURE 5 - Oil Cooler Assembly
(Chiller Sizes 036 thru 125 Only)

The water-regulating valve is field-adjustable; simply tighten the adjusting screw to decrease water flow, and loosen it to increase water flow.

Notice that a drain hole is provided in the leaving water nipple of the oil cooler; see Figure 5. When open, this drain relieves all of the water in the circuit between the cooling coil and the normally-closed water-regulating valve. Drain the water from the oil cooler as necessary (i.e., by removing the small screw tapped into the outlet pipe) to perform maintenance procedures, and to prevent cooler freeze-up during winter shutdown.

MOTOR COOLING SYSTEM

The CVHE compressor motor is cooled with liquid refrigerant; a schematic illustration of this pressurized system is provided in Figure 4.

Liquid refrigerant flows from the condenser sump to the bottom of the compressor motor where it enters the motor chamber through a control orifice. As the liquid refrigerant touches the warmer motor components, a portion of it flashes to a gas and cools the motor. The flash gas and excess liquid refrigerant then drain to the second-stage of the economizer. Because of the positive pressure differential between the condenser and the economizer, proper refrigerant flow through the motor is maintained at all load conditions.

PURGE SYSTEM

CVHE Units thru "D" Design

NOTE: To determine the design sequence of your unit, check the tenth digit of the model number stamped on the unit nameplate.

Because some sections of the chiller's refrigeration system operate at less-than-atmospheric pressure, the possibility exists that air and moisture may leak into the system. If allowed to accumulate, these noncondensibles




FIGURE 6 - Purge System Schematic (CVHE Units thru "D"-Design)

become trapped in the condenser; this increases condensing pressure and compressor power requirements, and reduces the chiller's efficiency and cooling capacity.

The purge system--shown schematically in Figure 6--is designed to remove noncondensable gases and water from the refrigeration system. A mixture of refrigerant vapor, noncondensable gases and water is drawn from the condenser and compressed by the purge compressor. The compressed gas is then discharged into an oil separator tank where the gas is heated (refer to Figure 7); this process effectively separates any purge compressor oil entrained in the gas. The oil collects at the bottom of the separator tank and is returned to the purge compressor crankcase through a float valve and return line.

Heated vapor leaves the separator tank and passes into the purge drum; here, the condensible portion of the mixture condenses on the surfaces of a chilled water coil, while the noncondensibles rise to the top of the drum. (Refer to Figure 8 for an illustration of the CVHE's auxiliary chilled water piping connections.) When the pressure within the purge drum exceeds the setting of the purge drum relief valve (see Figure 9), the valve opens and exhausts the noncondensibles to the atmosphere. Any accumulated water floating on the surface of the refrigerant can be removed by opening the manual blow-off valve found on the water connection end of the purge drum.

NOTE: Check the purge drum for water accumulation on a weekly basis, and notice the amount of water removed. Any visible accumulation of water




FIGURE 7 - Oil Separator Tank (CVHE Units thru "D"-Design)




FIGURE 8 - CVHE Auxiliary Chilled Water Piping Connections

indicates that there is an air or water leak in the unit; if this condition occurs, be sure to contact a qualified service organization to correct this problem as soon as possible.

The remaining liquid refrigerant passes through a float valve within the purge drum and re-enters the refrigerant system through a valve at the evaporator.

CVHE Units of "E" or Subsequent Design

NOTE: Be sure to check the tenth digit of the model number stamped on the unit nameplate of your unit to determine the design sequence.




FIGURE 9 - Purge Drum

Like the purge system used on CVHE units of "A" through "D" design (described in the previous section), the purge system used on "E" design units removes noncondensable gases and water from the refrigeration system. Refer to the schematic of the "E"-design purge system shown in Figure 10. Notice that this system uses an oilless purge compressor specifically designed for CenTraVac application, thus eliminating the need for an oil separator tank. In addition, a check valve and solenoid valve (as well as an isolation valve at the condenser) are used to isolate the purge compressor from the rest of the system when it is off; this prevents refrigerant leakage.

CAUTION: Before performing a standing vacuum test, be sure to close the manually-operated isolation valve at the condenser; this prevents air from entering the system.

A mixture of refrigerant vapor, noncondensable gases and water is drawn from the condenser and compressed by the purge compressor. The compressed gas is then discharged directly into the purge drum; here, the condensible portion of the mixture condenses on the surfaces of the chilled water coil, while the noncondensibles rise to the top of the drum. (Refer to Figure 8 for an illustration of the CVHE's auxiliary chilled water piping.) When the pressure within the purge drum exceeds the setting of the purge drum relief valve (see Figure 9), the valve opens and exhausts the noncondensibles to the atmosphere. Any accumulated water floating on the surface of the refrigerant can be removed by opening the manual blow-off valve found on the water connection end of the purge drum.

NOTE: Check the purge drum for water accumulation on a weekly basis, and notice the amount of water removed. Any visible accumulation of water indicates that there is an air or water leak in the unit; if this condition occurs, be sure to contact a qualified service organization to correct this problem as soon as possible.

The remaining liquid refrigerant passes through a float valve within the purge drum and re-enters the refrigerant system through a valve at the evaporator.

Purge Unit Operation

The oilless ITT purge unit is controlled by the purge switch on the control panel as follows:

OFF - Purge will not operate.

MANUAL - Purge will run continuously. This position is for service use only. The purge should not be left in this position during normal operation.

NOTE: When the unit is operating in the cooling mode, close the manual shutoff valves on the cooling condenser. Reverse this procedure when the unit is operating in the heat-recovery mode. Purge only from the active condenser.

AUTO - In this position, the purge timer will run the compressor for five minutes out of every hour of machine operation. This is the normal switch position for machine purging.

Recommended operation of the new purge unit is in the "auto" mode or manually once per week for one hour.

When the purge unit is operated in the "auto" mode, the purge compressor starts and stops under control of the timer. The timer should be set to operate for five minutes every hour. The timer can be adjusted to run the purge for less than five minutes per hour, if desired, to slow wear on the purge compressor rings.

NOTE: If five minutes per hour is not sufficient to keep the unit purged of air, the "on" time can be increased by adjusting the timer. However, operation in excess of five minutes per hour indicates an unacceptable leak rate that must be repaired to avoid machine damage and excessive wear on the purge compressor rings.

NOTE: Rotation of the time adjustment knob on the purge timer will not cycle the purge on and off. If the compressor is on, turning the knob will cycle the purge off. Further revolutions of the knob will not turn the compressor back on.




FIGURE 10 - Purge System Schematic (CVHE Units of "E" and Subsequent Design)

SYSTEM CONTROL -----

CONTROL PANEL

Safety and operating controls are housed in the CenTraVac unit control panel. Panel functions are divided into four categories, as indicated by the physical layout of the panel; see Figure 11.

1. Pressure gauges--located on the left-hand side of the panel--indicate condenser, evaporator, lubricating oil, and purge drum pressures.
2. Seven system sequence status lights (located to the immediate right of the pressure gauges) perform an important diagnostic function by monitoring the progress of the chiller start-up sequence. As each of the seven control circuit interlocks is verified, its control panel pilot light illuminates. If, for some reason, the start-up sequence is aborted, the operator can determine the point of the breach by checking these pilot lights.
3. Five safety indicators are provided in the center of the control panel, directly below the unit AUTO/OFF and purge MAN/OFF/AUTO switches; see Figure 11. These circuit interrupters are used to open the control circuit since they will hold their position in the event of a power interruption. This means that a power failure does NOT require manual resetting of all safeties.

NOTE: Additional alarm contacts on each of the safety indicators are brought to a terminal strip for external field-installed connection.

4. The electronic capacity control system, located on the right-hand side of the control panel, operates an electric vane motor to load and unload the chiller. This system consists of three elements: a current limiter, a chilled water temperature control, and the function control switch (and indicator lights).




FIGURE 11 - CVHE Unit Control Panel

The current limit control (labelled % CURRENT) can be set to control at any value below 100 percent of the motor rated load current. Motor current is sensed by three current transformers, and processed into a proportional DC voltage signal by the CenTraVac motor overload (A1). This same DC voltage signal is monitored by the current limiter. When the set percentage of rated load current is reached, the current limiter prohibits the inlet vanes from opening further; if the setting is exceeded, the inlet vanes are modulated toward the closed position.

The chilled water temperature control module uses a solid-state temperature sensor to monitor leaving chilled water temperature. If this temperature varies from setpoint (which is set using the knob labelled CONTROL POINT, and is based on design conditions), an electronic controller sends a pulsing signal to the inlet vane actuator; this tells the actuator to adjust the guide vanes to compensate for the variance from setpoint. (The standard control point is adjustable between 35 and 55 F.)

The function control switch, labelled with LOAD/HOLD/UNLOAD/AUTO positions, governs the function of the capacity control module. It must be set at AUTO to provide normal unit operation, and is only readjusted to one of the other switch positions for service work. To the right of the function control switch are three pilot lights which indicate whether the chiller is loading, unloading, or limiting the chiller capacity based on current draw. If all three of these pilot lights are out, the three conditions they represent are presently satisfied and the unit is functioning normally (i.e., holding with no inlet vane movement).

NOTE: The unit safety controls can override the setting of the function control switch regardless of its position; this override capability ensures that the chiller is protected from most dangerous operating conditions; however, no safety device protects against surge!

In addition to the gauges, status lights, safety indicators, and electronic capacity control system, the unit AUTO/OFF and purge MAN/OFF/AUTO switches are also located on the unit control panel. The unit AUTO/OFF switch allows the chiller to be shut down manually; when positioned at AUTO, the chiller will operate in response to the unit controls and safeties. (Remember that the unit will not start automatically unless all of the start-up safety conditions have been satisfied and cooling is required.) This switch is usually left in the AUTO position when cooling is needed.

The purge MAN/OFF/AUTO switch governs the purge compressor's mode of operation. When the switch is positioned at OFF, the purge compressor will not operate; if it is adjusted to the AUTO position, the purge compressor will only operate when the chiller is running. To provide continuous operation of the purge compressor for maintenance purposes only, adjust the purge switch to the MAN (or manual) position. Continuous function of the purge system is not recommended during normal unit operation.

CAUTION: Do NOT operate the purge compressor in the manual mode unless there is water flow through the purge drum! If the purge switch is positioned at MAN WITHOUT water flow through the drum, refrigerant will be purged from the machine, resulting in excessive refrigerant loss.

ELECTRICAL SEQUENCE OF OPERATION

Be sure to refer to the typical wiring schematic provided in Figure 12 when reviewing the step-by-step electrical sequences of operation provided below.

CAUTION: The typical wiring diagram provided in Figure 12 is representative of "E"-design chillers, and is provided ONLY for general reference; it may not reflect the actual wiring of your unit. For specific electrical connection and schematic information, refer to the wiring diagrams which shipped with the chiller.

Electronic Capacity Control System

The electronic capacity control system used to govern chiller operation consists of six control devices; their functions are reviewed below:

Electronic Starter Overload Relay (A1) - This device monitors the compressor motor starting current, and initiates transition to full voltage when the current draw falls to 85 percent of motor RLA. Once transition is complete, it compares the motor current against a calibrated value of 107 percent of RLA; if the current reaches this value, the overload will trip to disconnect the motor.

Compressor Inlet Vane Actuator (A3) - The actuator end switch (see Line 26, Figure 12) is closed when the compressor inlet vanes are at the full closed position. A3's limit switch (see Line 38) is open whenever the inlet vanes are fully open, while a second A3 limit switch (Line 40) is open when the vanes are fully closed.

Anti-Recycle Timer (S4) - This timer (found on Line 34) limits the compressor to one start every 30 minutes, and also provides the "start" signal to the compressor motor starter (K1).

Oil Pump Timer (S9) - With a total timing cycle of four minutes, this control device allows the oil pump to provide a pre-lube cycle of approximately one minute and twenty seconds; at the end of the pre-lube interval, the anti-recycle timer (S4) energizes and the oil pump timer stops timing until the unit shuts down. At that point, S9's timing cycle resumes and will continue until the four-minute cycle is complete, thereby providing a compressor post-lube period of approximately three and one-half minutes.

Electronic Capacity Control Module (U1) - This device modulates the inlet vane actuator (A3; Line 39) by balancing the CONTROL POINT knob setting against the leaving chilled water temperature sensed by the leaving chilled water temperature sensor (U3; Line 38).

The U1 module also serves as a load limiting device as a result of an input signal received from the electronic overload relay (A1); the circuit between the control power fuse (F1) and Terminal 84 (on U1) must be complete before the module can open the compressor inlet vanes.






Compressor Motor Hi-Temperature Cutout (U2) - The M1-M2 contacts of this device (found on Line 35) close shortly after 115-volt control power is provided to Terminals T1 and T2, and will remain closed unless the

SCHEMATIC DIAGRAM

WARNING
DISCONNECT ELECTRICAL POWER
TO PREVENT INJURY OR
DEATH FROM ELECTRICAL SHOCK

CAUTION
Use copper conductors only
to prevent equipment damage

18



CONTACT CLOSED
 WITH REFERENCE
 VOLTAGE (120 VOLTS)
 TO TERMINALS
 T1 AND T2

**(CONTINUED ON
 NEXT PAGE)**

temperature of the compressor motor windings exceeds 265 ± 5 F. If the motor winding temperature exceeds this level, the M1-M2 contacts will open to shut down the machine; when the winding temperature drops to 235 F, these contacts will automatically reclose.

The motor temperature sensors B1R1, B1R2, and B1R3 are located on the ends of the motor windings at 2, 6, and 10 o'clock positions. These sensors are not replaceable.

NOTE: Be sure to refer to the legend provided when reviewing the electrical sequence of operation outlined in the paragraphs which follow.

LEGEND	
A1 Electronic Starter Overload	K8 Starter Fault-Trip Ckt.
A3 Compressor Vane Actuator	K9 Starter Fault-Arming Ckt./S4 Timer De-energized Ckt./Automatic Purge Operation
A8 Chilled Water Pump Overload (Field-Supplied)	K10 Start Pulse Signal/S4 Timer De-energized Ckt.
A9 Condenser Water Pump Overload (Field-Supplied)	K11 Hi Motor Temp. Trip Ckt.
A12 Free-Cooling Liquid Line Valve Actuator (Optional)	K12 Chilled Water Pump Starter
A13 Free-Cooling Gas Line Valve Actuator (Optional)	K13 Condenser Water Pump Starter
A14 Hot Gas Bypass Valve Actuator (Optional)	K14 Oil Pump (Manual Purge Ckt.)
B1 Compressor Motor	K15 Oil Pump Starter Relay
B2 Oil Pump Motor	K16 Electric Hot Gas Bypass Control Relay (Optional)
B3 Purge Compressor Motor	L1 Purge Solenoid
B1R1 Motor Temp. Sensor	L3 Load Solenoid (Pneumatic Option)
B1R2 Motor Temp. Sensor	L4 Unload Solenoid (Pneumatic Option)
B1R3 Motor Temp. Sensor	M1 Hour Meter
C1 Oil Pump Start Capacitor	M2 Start Counter
CB1 Low Oil Pressure Fault	S HGBP Valve Actuator Limit Switch (Opt.)
CB2 Hi Condenser Pressure Fault Indicator	S1 Hi Condenser Pressure Switch
CB3 Low Refrig. Temp. Fault Indicator	S2 Low Refrig. Temp. Switch
CB4 Hi Motor Temp. Fault Indicator	S3 Start-Stop Chilled Water Demand Switch
CB5 Starter Fault Indicator	S4 Anti-Recycle Timer
CB10 Starter Main Ckt. Breaker	S5 Evaporator Flow Switch
DS1 SAFETIES SATISFIED Indicator Light	S6 ON/OFF Switch
DS2 COOLING REQUIRED Indicator Light	S7 Condenser Flow Switch
DS3 RESTART TIME ELAPSED Indicator Light	S8 Oil Pressure Switch
DS4 CHILLED WATER Flow Indicator Light	S9 Oil Pump Post-Lube Timer
DS5 CONDENSER WATER Flow Indicator Light	S10 Oil Temp. (Heater) Switch
DS6 OIL PUMP Indicator Light	S11 Purge ON/OFF/AUTO Switch
DS7 SYSTEM Operating Indicator Light	S12 Guide Vane Linkage Limit Switch (HGBP Opt.)
F1 Control Power Fuse	S13 Purge Hi Pressure Switch
F2 Oil Pump Fuse	S14 Purge Timer
F3 Oil Heater Fuse	S15 Proof-of-Closure Switch (Pneumatic Opt.)
F4 Purge Unit Fuse	S22 Compressor Hi Discharge Temp. Switch (HGBP Opt.)
HR1 Oil Sump Heater	T1 Control Power Transformer
K1 Compressor Motor Starter	U1 Electronic Capacity Control Module
K3 Low Oil Pressure Arming Ckt.	U3 Leaving Chilled Water Temp. Sensor
K4 Condenser Pump Control Relay	2U3 Return Chilled Water Temp. Sensor
K5 Start Oil Pump Timer/Jump-Out Start Inhibit Circuit	
K6 Oil Pressure Arming Ckt./Start S4 Timer Motor	
K7 Prevent Voltage Feedback/De-energize Start Counter/Starter Fault-Arming Ckt.	

With the chilled water pump starter (K12; Line 13) energized, and the unit ON/OFF switch (S6; Line 26) set at AUTO, 115-volt control power flows through the string of safety controls and safety lockout contacts (Line 16). If all of the safeties are satisfied, the SAFETIES SATISFIED indicator light (DS1; Line 20) illuminates.

Current then flows to the chilled water demand switch (S3; Line 26), whose temperature-sensing element is located in the return water entering the chiller. When the return water temperature rises above the control point, S3 closes; this illuminates the COOLING REQUIRED indicator light (DS2; Line 20) and "feeds" current to the anti-recycle timer contacts (S4; Line 26). If a minimum of 30 minutes has elapsed since the last compressor start, S4's contacts allow the current to pass; this causes the RESTART TIME ELAPSED indicator light (DS3; Line 26) to illuminate, and current flows to the compressor inlet vane actuator (A3). If the inlet vanes are closed and the compressor is off, current flows through the compressor inlet vane end switch and the contacts of relay K7 to Terminal 8. The CHILLED WATER flow indicator light (DS4; Line 20) will then light, provided that the evaporator flow switch (S5; Line 26) verifies chilled water flow.

Notice that positioning switch S6 (Line 26) at AUTO also allows current to energize the condenser pump control relay (K4; Line 19); K4's contacts (Line 16) then close, energizing the condenser water pump starter (K13). If condenser water flow is proven, current flows through condenser flow switch S7 (Line 26), illuminates the CONDENSER WATER flow indicator light (DS5; Line 20), and energizes relay K5 (Line 21). One set of normally-open K5 contacts (Line 43) closes to energize the oil pump timer (S9). After the 40-second timing period has elapsed, S9's contacts (Line 44) close and oil pump motor B2 (Line 45) energizes.

The oil pump utilizes a capacitor-start/induction-run, single-phase motor; its current-sensitive starter relay (K15; Line 45) is wired in series with the pump motor's run winding, allowing it to switch from start to run. When the oil pump motor first starts, it draws locked rotor current; this high current draw causes relay K15 to close its contacts (Line 45). The start capacitor then energizes, and the motor start winding begins its rotation. Once the motor is fully accelerated, the current draw falls, causing K15's contacts (Line 45) to open and drop out of the start winding. The oil pump motor is now in its run configuration.

Once proper oil pressure is established, oil pressure switch S8 (Line 26) closes and the OIL PUMP indicator light (Line 22) illuminates. Relay K6 (Line 23) then energizes, and one set of its single-pole/double-throw contacts (Lines 14 and 15) switch to energize the low oil pressure arming circuit (K3; Line 14). (This occurs when K3's contacts--in Line 16--subsequently close to energize low oil pressure fault indicator CB1.)

A second set of normally-open K6 contacts (Line 34) closes to energize the anti-recycle timer (S4). Within 25 seconds, the S4 contacts in Line 33 close, while another set of S4 contacts in Line 28 closes 20 seconds later. With S4's contacts closed, the SYSTEM operating indicator light (DS7; Line 28) illuminates and relay K9 (Line 26) energizes. A compressor start is then initiated when compressor motor starter relay K1 energizes; one set of K1 "start" contacts (Line 29) closes to maintain power to the compressor starter, while a second set of "start" contacts (Line 34) closes to energize the start pulse signal relay (K10).

Notice that one set of single-pole/double-throw K10 contacts (Lines 32 and 34) switch immediately to ensure the the K10 relay remains energized for the duration of anti-recycle timer S4's timing period. Another normally-closed set of K10 contacts (Line 29) opens to interrupt the "start" signal to the compressor motor through the S4 contacts in Line 26. (NOTE: The original "start" signal sent through the S4 contacts in Line 26 is maintained just long enough to energize the "start" contactor of compressor motor starter K1. If K1 drops out of the circuit for any reason, it will remain de-energized until the anti-recycle timer (S4) completes its timing cycle.)

An additional set of normally-open K1 "start" contacts (Line 45) closes to ensure that the oil pump is energized as long as K1's contacts are closed.

When compressor motor starter K1 "converts" the compressor to the run configuration, K1's normally-open "run" contacts (Line 40) close to supply power to Terminal 84 of the capacity control module (U1). (However, the low refrigerant temperature switch (S2) must be closed for this to occur.) Control module U1 then opens the compressor inlet vanes as needed.

Remember that the "starter fault" safety circuit was armed at the same time that compressor motor starter K1--along with relay K9--was initially energized; a set of normally-closed K9 contacts in Line 25 opened to ensure that relay K8 (i.e., starter fault tripping circuit) remained de-energized. At that point, S4 contacts in Line 26 switched from 13-81 to 13-79 to energize relay K7 (Line 24). Normally-closed K7 contacts in Line 25 then closed, allowing relay K7 to remain energized and completing the arming of the "starter fault" circuit. If compressor motor starter K1 drops out of the circuit for any reason, the K1 contacts in Line 29 will open and relay K9 will de-energize. K9's normally-closed contacts (Line 25) will then reclose to energize the starter fault tripping circuit relay (K8) and cause its normally-open contacts (K8; Line 15) to close. This action trips the starter fault indicator (CB5) and locks the unit off.

When there is no longer a call for cooling--or if a safety opens, compressor starter K1 and relay K5 (i.e., oil pump timer/jump-out start inhibit circuit) are de-energized. A set of S9 contacts (Line 44) ensures that the oil pump post-lube timer (S9) and oil pump motor (B2) remain energized for three minutes to provide lubrication during compressor coast-down.

If there is a loss of oil pressure while the compressor is running, oil pressure switch (S8; Line 26) opens; this stops the compressor and de-energizes relay K6 (oil pressure arming circuit/start S4 timer motor; Line 23). Current is then routed from Terminal 12 (Line 26), through the K3 contacts in Line 16 and the normally-closed K6 contacts in Line 14. This trips the low oil pressure fault indicator (CB1), and the compressor is locked out.

NOTE: Alarm contacts (Line 56) for field connection are factory-wired using a set of auxiliary, normally-closed contacts on each of the control safety lockouts.

Control Options: Pneumatic Capacity Control System

In this control scheme, an analog (proportional) signal from a conventional pneumatic temperature controller (also optional) is fed into the pilot port (labelled "P" in Figure 13) of the pneumatic inlet vane actuator's pilot




FIGURE 13 - CVHE Pneumatic Control Interface

positioner. Notice that a jumper between Terminals TS1 and TS2 on the capacity control module (U1) is substituted for the electronic leaving chilled water sensor (U3) used in the electronic control scheme described in the preceding section.

When the compressor motor starter assumes the "run" configuration, K1's interlocking contacts close; the continuous circuit between TS1 and TS2 causes the module to transmit a repeated, pulsed loading signal to solenoid valve L3. Unlike the electronic capacity control system, the duration of this pulse is solely the function of motor current in terms of its relationship to the % CURRENT setting of the current limiter. The preselected 10 to 310-second time lapse is observed between successive load pulses.

During the load pulse, the normally-closed (NC) port of solenoid valve L3 opens, permitting the output air pressure from the pilot positioner to be transmitted through the normally-open (NO) and common (C) ports of solenoid valve L4 to the vane actuator. Within the time interval of the load pulse, the pneumatic temperature controller has the authority to open, close or hold the vane position.

When the system is shut down, opening the K1 contacts--or a low refrigerant temperature condition opens switch S2--control module U1 transmits a continuous unloading signal. This signal closes the normally-open (and opens the normally-closed) ports of valve L4 to exhaust the control air pressure from the actuator and close the vanes.

Load limiting within the pneumatic control system is handled in the same manner as the electronic control scheme: as motor current rises, the duration of the loading pulse decreases. At 100 percent of the % CURRENT setting, the pulse duration drops from 0.25 seconds to zero. At 103 percent, a 0.25-second unloading pulse is initiated, followed by a 10 to 310-second load-delay period; this represents an attempt to return the chiller to 100 percent of the demand limiter setting. Finally, at 105 percent, a continuous unloading pulse is established and is terminated only when the motor current is reduced to 95 percent of the demand limit setting. (Refer to Figure 13; a pressure-relief check valve is connected to the normally-open port of L4 to allow the unit to unload when motor current is between 100 and 103 percent of the % CURRENT setting and the chilled water set-point has been reached. This check valve also enables the pneumatic control to reduce the branch pressure on the actuator when the unit is under current limit and the chilled water setpoint has been reached.)

Notice that control air is supplied to--and exhausted from--the vane actuator through an orifice. This orifice is factory-adjusted to produce the same vane movement rate as that produced by the actuator used in the electronic capacity control system.

Finally, proof-of-closure switch S15, which closes on a drop in pressure, replaces and performs the same function as the end switch of the electric inlet vane actuator (A3; Figure 12 - Line 26).

The remaining circuitry of the pneumatic capacity control system is the same as that used in the electronic control scheme.

Control Options: Sequence Panel

NOTE: When reviewing the following operational sequence, be sure to refer to the appropriate wiring diagram in the wiring booklet which shipped with the unit. For more comprehensive installation and application information, refer to the submittal information which shipped with the panel.

To ensure that the system operates properly when power is applied, several adjustments must be made to the sequence panel and to the unit controls.

1. On the sequence panel:
 - a. Select the desired unit operating sequence, and set the sequence switch accordingly.
 - b. Use the knobs located on the mounting plate within the panel to set the load and unload thresholds.

Set the load threshold to the percentage of maximum load desired on the lead unit before the lag unit starts; a setting of 90 percent is recommended.




FIGURE 14 - Optional Sequence Panel

Set the unload threshold to that percentage of minimum load required with both units operating before the lag unit shuts down. To prevent cycling at this transition point, the setting must be less than half of the load setting; a setting of 40 percent is recommended. As a part of set-up, determine what the minimum current threshold is before adjusting the minimum set-point to insure that the motor will go to 40%.

- Adjust the controls of the lead (A) and lag (B) units. The power switches (labelled AUTO/OFF on the control panel of each unit) should be set at AUTO, and the temperature control adjustments should be set to the same desired control temperature.

Make sure that the knobs on the temperature controls are properly adjusted. The pointer of each should be aligned with the calibration mark on the dial when in the fully counterclockwise position.

In addition, adjust the current limit potentiometers to the fully clockwise position.

These are the only adjustments required for the successful operation of the system.

When control power is applied to a pair of chillers (pipel in parallel) utilizing the sequence panel control option, the operational characteristics of the system are the same as those described in the previous sections. Start-up is controlled by the sequence panel OFF/ON switch; refer to Figure 14 for an illustration of the sequence panel and possible panel applications. When the system switch is positioned at ON, its contacts close to the lead unit, and pilot light No. 1 illuminates. If all of the start sequence circuit interlocks are verified, the lead unit will start.

If the current draw of the lead unit exceeds the setting on the load selector, a 15-minute timer energizes. Once the timing cycle is complete, the second (or lag) unit starts and pilot light No. 2 illuminates. At this point, the lead unit begins to unload and the lag unit loads up. After a period of adjustment, the units stabilize, with each carrying half of the cooling load; any further change in cooling demand will be shared equally.

In some applications, the sequence panel is used in conjunction with a pair of chillers pipel in series with one chilled water pump; this changes the master/slave control scheme. When both units are on, the "B" (or lag) unit always operates with its temperature control in its current limit mode (i.e., the yellow light is on); its loading, however, tracks that of the "A" (or lead) unit. If the load decreases, the lag unit will shut down 15 minutes after reaching the setting on the unload selector. The remaining unit adjusts to carry the load.

Should it become necessary to run either or both chillers independently from the sequence panel, adjust the OFF/ON system switch on the sequence panel to the OFF position. Then, when the sequence panel's AUTO/MANUAL switch is set at MANUAL, the units will operate in response to their individual control adjustments.

NOTE: The sequence panel pilot lights indicate a call for the units' operation; they do NOT confirm unit operation.

Control Options: Free-Cooling

Free-Cooling, an accessory to CVHE CenTraVacs, adapts the basic chiller so it may function as a simple heat exchanger using refrigerant as the working fluid; however, it does not provide control of the leaving chilled water temperature. When condenser water is available at temperatures lower than the desired chilled liquid temperature, the free-cooling option can provide substantial nominal chiller capacity without operating the compressor, resulting in substantial energy cost savings.

The principle behind the free-cooling option is that refrigerant flows to the area of lowest temperature in the system. When condenser water is available at a temperature lower than the required leaving chilled water temperature, the operator manually stops the compressor and starts the free-cooling cycle by pressing a push button control located in the lower right-hand corner of the




FIGURE 15 - CVHE Unit Control Panel w/Free-Cooling Option

unit control panel. See Figure 15. Changeover from the free-cooling cycle to mechanical cooling is accomplished by pressing this same button.

To equip the chiller with the free-cooling option, several components are factory-installed or -supplied: a refrigerant gas line (including an electrically-actuated shutoff valve) installed between the evaporator and condenser; a valved liquid return line (including an electrically-activated shutoff valve) between the condenser sump and the evaporator; a liquid refrigerant storage vessel; additional refrigerant charge; and, a free-cooling selector switch (located on the unit control panel).

When the chiller operator initiates the changeover to the free-cooling cycle, the shutoff valves in the liquid and gas lines open, and a lockout circuit prevents the compressor from energizing. Liquid refrigerant then drains--by gravity--from the storage tank into the evaporator and floods the tube bundle. Since the temperature and pressure of the refrigerant in the evaporator are higher than in the condenser because of the difference in water temperature, the refrigerant in the evaporator vaporizes and flows to the condenser. This gaseous refrigerant then condenses as a result of the effects of the cooling tower water, and flows--again, by gravity--back to the evaporator. Refer to Figure 16 for an illustration of the free-cooling cycle.

The automatic refrigeration cycle described above is sustained as long as a temperature differential exists between the condenser and evaporator liquids. The cooling capacity provided by the free-cooling cycle is determined by the difference in temperature between the evaporator water and the condenser water which, in turn, determines the rate of refrigerant flow between the two shells.

If the system load exceeds the available free-cooling capacity, the operator must manually initiate changeover to the mechanical cooling mode by pressing the free-cooling switch on the unit control panel. The gas and liquid line valves then close and compressor operation begins. Refrigerant gas is drawn out of the evaporator by the compressor, and is then compressed and discharged to the condenser. Most of the condensed refrigerant initially follows the path of least resistance by flowing into the storage tank. The storage tank is vented to the economizer sump through a small bleed line; when the storage tank is full, liquid refrigerant must flow through the bleed line restriction.




FIGURE 16 - Free-Cooling Operation vs. Compressor Operation

Because the pressure drop through the bleed line is greater than that of the orifice flow control device, the liquid refrigerant flows normally from the condenser through the orifice system and into the economizer.

NOTE: During the changeover from free-cooling to mechanical cooling, the refrigerant transfer process is completed within three minutes. The loading ramp prevents carry-over by loading the machine slowly.

Control Options: Hot Gas Bypass

The hot gas bypass (i.e., HGBP) control system is designed to minimize machine cycling by allowing the CVHE unit control system to operate stably under minimum load conditions. In these situations, the guide vanes are locked at a preset minimum point and the unit capacity control function is performed by the HGBP valve positioner. Circuits are also provided to allow both the guide vanes and the HGBP valve to close for unit shutdown.

There are four control components associated with the hot gas bypass option:

1. Relay K16: This control device is located in the unit control panel (or mounted in a separate box for retrofit applications), and enables the closure of the HGBP valve and guide vanes at unit shutdown.
2. Switch S12: This single-pole/double-throw limit switch is mounted on the guide vane linkage, and operates when the vanes pass through a particular minimum setting.
3. Switch S: Mounted in the HGBP valve actuator, this single-pole/double-throw limit switch operates when the valve just begins to open. Notice that the "close" limit switch mounted in the valve actuator must be set to operate just after (i.e., valve more closed) Switch S operates.

4. Switch S22: This device is designed to shut the unit down if the discharge temperature exceeds 210 F, thereby preventing the unit from running at extremely low loads for extended periods of time.

NOTE: When reviewing the sequence of operation provided below, be sure to refer to the hot gas bypass schematic and connection diagrams included in the wiring booklet which shipped with the chiller.

At unit start-up, the HGBP control relay (K16) energizes, and load signals from M2 flow to the "open" terminal of the vane actuator. When the vanes open past the preset minimum operating point, the contacts of limit switch S12 switch so that any unload signals from M1 are routed to the vane actuator. From this point, the unit will load and unload normally throughout the range of guide vane positions. (If the vanes do not open past the preset minimum operating point, however, the unit will remain on inlet guide vane control only.)

When the unit unloads and the guide vanes reach a preset minimum point, Switch S12 energizes and passes unload signals from M1 to the "open" terminal of the HGBP valve actuator. When the HGBP valve opens, Switch S energizes and passes load signals from M2 to the "close" terminal of the HGBP valve actuator. Unit capacity is then controlled by the HGBP valve actuator with the guide vanes held at the minimum position. When the unit again loads, the HGBP valve closes; once it reaches the full-closed position, Switch S energizes and sends additional load signals to the vane actuator.

At unit shutdown, HGBP control relay K16 is de-energized and the unload signal from M1 passes through the normally-closed contacts of K16 to the "close" terminals of the vane and HGBP valve actuators. This operation prepares the unit for restart.

NOTE: Be sure to contact a qualified service organization for proper adjustment of the HGBP valve actuator limit switches.

Control Options: Demand-Limit Interface

The demand-limit interface control option--whether factory- or field-installed on the unit control panel--is designed to enable the chiller to be demand-limited from an external source. Once the demand-limit module is installed, the CVHE control system can accept a 0 to 1000-ohm potentiometer input (or equivalent). This resistive input limits the maximum current that the compressor motor can draw. Refer to Table 1 to determine the relationship between the potentiometer inputs and the resulting maximum current values.

Notice that as the maximum allowable current is decreased, the capacity controller decreases the inlet guide vane opening in an attempt to meet the maximum limit. Current draw with fully closed inlet guide vanes may range from 60 to 30 percent of the rated load amps (RLA), depending on the individual machine and the operating conditions. Once the vanes are fully closed, any additional signals input to further limit the maximum current will have no effect.

TABLE 1 - Demand-Limit Interface: Input vs. Current

POTENTIOMETER INPUT	MAXIMUM CURRENT
0 Ohms	100%
200 Ohms	88%
400 Ohms	76%
600 Ohms	64%
800 Ohms	52%
1000 Ohms	40%

To demonstrate chiller operation during demand-limiting, let's look at the example provided below:

A CVHE unit is drawing 60 percent current, and a 200-ohm potentiometer signal is inputted into the control system. This 200-ohm signal sets the maximum current draw at 88 percent; see Table 1. Since the actual current draw of 60 percent is less than the maximum allowable current draw of 88 percent, the unit will not respond with a capacity reduction at this time.

However, if the load current tries to rise above the maximum allowable current (i.e., 88 percent), demand-limiting will occur. The inlet guide vanes will modulate closed until the actual current draw equals the maximum current allowable.

If the maximum allowable current setting is raised, the inlet guide vanes open slowly, stopping at a position that corresponds to some current draw below the ceiling level.

NOTE: Make sure that the demand limiter dial on the front of the unit control panel is set at 100 percent. Any demand-limiting initiated with this dial is superimposed onto the external demand-limiting signal (e.g., a dial setting of 75 percent plus a 200-ohm potentiometer input yields a maximum allowable current of 62 percent).

NOTE: Demand-limiting a centrifugal chiller may cause the machine to temporarily operate in an unstable mode that produces refrigerant gas noise. Since job site conditions vary greatly, it is recommended that the rate of demand-limiting--as well as the maximum amount of demand-limiting--be determined on the job site at start-up.

Control Options: Chilled Water Reset Interface

NOTE: This control option is not compatible with the unit pneumatic capacity control system.

The chilled water reset interface option consists of a control module which is factory- or field-installed on the outside of the unit control panel. When

connected to a remote signal device (i.e., field-supplied and -installed), the interface control module will linearly reset the leaving chilled water control point to a maximum of 10 F above the unit control panel setting. (The reset interface control module is designed to accept signals of 0 to 10 VDC, 4 to 20 maDC, or 0 to 1000 ohms.)

Control Options: Chilled Water Reset

NOTE: This control option is not compatible with the unit pneumatic capacity control system.

Chilled water reset is designed for those applications where the system operates at part load, and does not require design chilled water temperature at part load. In these cases, the leaving chilled water temperature setpoint can be reset upward using the chilled water option.

The photograph shows a Trane Capacity Control Module. On the left side, there are four terminal connections labeled -V2, -V1, -TS3, and -TS2. At the top, there are two dip switches labeled 'DIP SWITCHES'. The module has a 'TRANE AIR CONDITIONING' logo in the center. The entire unit is housed in a dark metal casing.

RESET RATIO	DIP SWITCH NO. 1	DIP SWITCH NO. 2
None	Off	Off
1/2 : 1	On	Off
1 : 1	Off	On
2 : 1	On	On

NOTES:

1. These ratios represent the change in entering water temperature vs. the change in leaving water temperature.
2. The actual amount of temperature reset is dependent on 4 parameters: sensor "range", design delta-T, reset ratio, and cooling load.

FIGURE 17 - Capacity Control Module Dip Switch Adjustment for Chilled Water Reset Option

Using an additional temperature sensor field-installed in the return chilled water piping, the chilled water reset control option enables the capacity control module to sense the cooling load on the chiller. **NOTE:** Be sure to select the proper sensor, depending upon the full-load delta "T". As the unit unloads, the control module will raise the leaving water temperature according to one of three available ratios; refer to Figure 17. Each of the reset ratios is defined as the change in entering water temperature vs. the change in leaving water temperature. To select the desired reset ratio, adjust the "dip" switches located on the capacity control module found within the unit control panel. See Figure 17.

Once the proper reset ratio has been selected, the chilled water reset option operates automatically, raising the leaving water temperature as the cooling load decreases. No further adjustment or maintenance is required.

NOTE: The chilled water reset control can be enabled or disabled with the addition of a single, field-supplied, mercury-wetted relay. By short-circuiting the two wires that connect the sensor to the control panel, the capacity control module overrides the reset signal and returns to the control panel setpoint.

UNIT START-UP/SHUTDOWN PROCEDURES -----

DAILY UNIT START-UP

1. Check the oil tank oil level; the level must be visible in--or above--the lower sight glass. Also, be sure to check the oil tank temperature; normal oil tank temperature before start-up is 150 ± 5 F.
2. Adjust the unit AUTO/OFF switch to the OFF position.
3. Check for chilled water and condenser water flow.
4. If necessary, readjust the current limit control (labelled % CURRENT) to the desired position.
5. Check the position of the function control switch; it should be set at AUTO.
6. If necessary, readjust the chilled water temperature control (labelled CONTROL POINT) to the desired temperature.
7. Verify that the safety indicators are in the reset position. If any have tripped, be sure to diagnose and correct the cause of the trip-out.
8. Recheck the oil temperature; once it reaches 150 ± 5 F, start the unit by adjusting the unit switch to the ON position.

DAILY UNIT SHUTDOWN

1. Adjust the unit switch to the OFF position.
2. Shut down the chilled water pump if chilled water service is no longer required.

SEASONAL UNIT START-UP

1. Close all drain valves, and reinstall the drain plugs in the evaporator and condenser headers.
2. Service the auxiliary equipment according to the start-up/maintenance instructions provided by the respective equipment manufacturers.
3. Chiller Sizes 036 thru 125 Only: Open the manual valves in the oil cooler water circuit.
4. Vent and fill the cooling tower, if used, as well as the condenser and piping. At this point, all air must be removed from the system (including each pass). Then install the vent plugs in the condenser water boxes.
5. Close the city water valves to the purge condenser.
6. Open all of the valves in the evaporator and purge condenser chilled water circuits.
7. If the evaporator was previously drained, vent and fill the evaporator and chilled water circuit. When all air is removed from the system (including each pass), install the vent plugs in the evaporator water boxes.
8. Lubricate the external vane control linkage.
9. Check the refrigerant in the unit; to do this, the refrigerant must be drawn off and weighed back into the chiller. (If the unit is low on charge, be sure to contact a qualified service organization.)
10. Check the adjustment and operation of each safety and operating control.
11. Close all disconnect switches.

WARNING: USE CARE WHEN MEASUREMENTS, ADJUSTMENTS, OR OTHER SERVICE-RELATED OPERATIONS MUST BE MADE WITH THE POWER ON TO PREVENT INJURY OR DEATH DUE TO ELECTRICAL SHOCK OR CONTACT WITH MOVING PARTS.

12. Start the purge system.
13. Verify that each of the safety indicators on the unit control panel is in the reset position.
14. Check the oil tank level; the level must be visible in the lower sight glass. Also, be sure to check the oil tank temperature; normal oil tank temperature before start-up is 150 ± 5 F.

15. Verify that the unit AUTO/OFF switch is positioned at OFF; then energize the water pumps. Check for chilled water and condenser water flow.
16. If necessary, set the current limit control (labelled % CURRENT) at its minimum setting.
17. Check the position of the function control switch; it should be set at AUTO.
18. If necessary, adjust the chilled water temperature control (labelled CONTROL POINT) to the desired temperature.
19. Recheck the oil temperature; once it reaches 150 ± 5 F, start the unit by adjusting the unit switch to the ON position.

The system should now operate automatically.

SEASONAL UNIT SHUTDOWN

1. Stop the system at the chilled water push button station, or stop the chilled water flow by the means devised for this particular application.
2. Open all disconnect switches except the control power disconnect switch.

WARNING: USE CARE WHEN MEASUREMENTS, ADJUSTMENTS OR OTHER SERVICE-RELATED OPERATIONS MUST BE MADE WITH THE POWER ON TO PREVENT INJURY OR DEATH DUE TO ELECTRICAL SHOCK OR CONTACT WITH MOVING PARTS.

CAUTION: The control power disconnect MUST remain closed during the entire shutdown period to allow oil sump and separator (if applicable) heater operation. This will prevent refrigerant from condensing in the oil sump.

3. Drain the condenser piping and cooling tower, if used.
4. Remove the drain and vent plugs from the condenser headers to drain the condenser.
5. If the system will be subjected to freezing temperatures, vent and drain the evaporator, oil cooler, and all connecting piping.
6. Once the unit is secured for winter, perform the maintenance procedures described in the "Annual Maintenance" section of this manual.

NOTE: During shutdown, be sure to operate the purge unit for a 30-minute period every two weeks. This will prevent the accumulation of air and noncondensibles in the machine. To start the purge, position the water valves to circulate city water through the purge condenser; then adjust the purge switch to the manual (MAN) position.

PERIODIC MAINTENANCE -----

This section describes basic chiller preventive maintenance procedures, as well as the recommended intervals for the performance of these procedures. Remember that a periodic maintenance program is important to obtain the best possible performance and efficiency from the CenTraVac chiller. Proper maintenance also assures that minor problems are detected and resolved before they become major.

An important aspect of the chiller maintenance program is the regular completion of the CenTraVac operating log; refer to the last page of this manual for an example of this log. When filled out accurately by the operator, the completed logs can be reviewed to identify any developing trends in the chiller's operating conditions. If, for example, a gradual increase in condensing pressure is noted during a month's time, the operator can systematically check--then correct--the possible causes of this condition (e.g., fouled condenser tubes, noncondensibles in the system, etc.).

DAILY MAINTENANCE AND CHECKS

1. Check the chiller's evaporator, condenser and purge drum pressure, oil sump temperature, and net oil pressure. Compare the readings obtained with the values provided in Table 2.
2. Check the oil level in the chiller oil sump using the two sight glasses provided in the oil sump head. When the unit is operating, the oil level should be visible in the lower sight glass.

TABLE 2 - Normal Chiller Operating Characteristics

OPERATING CHARACTERISTIC	NORMAL READING
Evaporator Pressure	12 to 18" w.c. Hg (vacuum)
Condenser Pressure ¹	2 to 12 psig
Purge Drum Pressure	0 to 22 psig
Oil Sump Temperature: Unit Not Running Unit Running	150 ± 5 F 125 to 150 F
Net Oil Pressure ²	18 to 20 psid

NOTES:

1. Condenser pressure is dependent upon the temperature of the condensing water, and should equal the saturation pressure of R-11 at a temperature 5 to 10 F above that of the leaving condenser water at full load.
2. Net oil pressure (i.e., usable oil pressure) is determined by subtracting the oil sump pressure (i.e., evaporator pressure) from the oil pressure gauge reading.

EXAMPLE: Oil Pressure Gauge = 10 psig, and the evaporator pressure = 18" Hg (vacuum). First, convert 18" Hg to psig (i.e., $-18/2.03 = -8.87$ psig). Then, subtract -8.87 psig from 10 psig (i.e., $10 - (-8.87) = 10 + 8.87 = 18.87$ psid). In this example, the net oil pressure of 18.87 psid is within the acceptable limits.

WEEKLY MAINTENANCE

Check the purge drum sight glass for evidence of condensate. (Water condensed in the purge drum floats on the surface of the liquid refrigerant, creating a visible line of separation in the sight glass.)

To remove water from the drum, operate the purge compressor until a positive pressure of 5 to 10 psig is indicated on the purge drum pressure gauge. Then, shut down the purge compressor and open the manual blow-off valve (located on the water connection end of the drum) to release the water and other noncondensibles.

CAUTION: If frequent purging is required, identify and correct the source of the air or water leak as soon as possible. Moisture contamination caused by leakage can shorten the life expectancy of the machine.

NOTE: If the unit is operating in the cooling mode, close the manual shutoff valves on the heating condenser and open the valves on the cooling condenser. Reverse this procedure when the unit is operating in the heat-recovery mode. Be sure to purge only from the active condenser.

EVERY THREE MONTHS

WARNING: OPEN AND LOCK THE UNIT DISCONNECT TO PREVENT INJURY OR DEATH DUE TO ELECTRICAL SHOCK OR CONTACT WITH MOVING PARTS.

NOTE: Steps 1 through 3 below apply only to those CVHE units of "A" through "D" design. Check the tenth digit of the model number stamped on the unit nameplate to determine the design sequence of your unit.

1. Check the tension of the purge compressor drive belt, and adjust it if necessary. (When the belt is properly tensioned, it will depress approximately 1/2 to 3/4 inches under light hand pressure.)

If the belt tension must be adjusted, loosen the motor mounting bolts and slide the motor. Be sure to check the drive belt for excessive wear or damage. Specific instructions are provided in the "Maintenance Procedures" section of this manual.

2. Lubricate the purge compressor drive motor bearings with a good grade of SAE-20 nondetergent motor oil. The lubrication points are illustrated in Figure 18.
3. Check the purge compressor crankcase oil level through the crankcase sight glass; when the compressor is idle, the oil level should occupy 1/8 to 1/4




FIGURE 18 - Purge Motor
Lubrication Points

of the sight glass. If additional oil is required, add Texaco WF-68 or Mobil Whiterex No. 425.

CAUTION: If more than one-half pint of oil is required, it is possible that oil is not being returned to the compressor from the oil separator, or that excessive heat is vaporizing the oil. Do NOT operate the purge system until this condition is diagnosed and corrected, or serious damage to the purge compressor bearings may result.

4. Clean all water strainers in the CenTraVac water piping system.
5. Complete all recommended daily and weekly maintenance procedures. (Refer to the previous sections for details.)

EVERY SIX MONTHS

WARNING: OPEN AND LOCK THE UNIT DISCONNECT TO PREVENT INJURY OR DEATH FROM ELECTRICAL SHOCK OR CONTACT WITH MOVING PARTS.

1. Lubricate the vane control linkage bearings, ball joints, and pivot points; a few drops of light machine oil (e.g., SAE-20) is sufficient. Also, apply one or two drops of oil on the vane operator shaft and spread it into a very light film; this will protect the shaft from moisture and rust.
2. Lubricate the actuator motor bearings by inserting a long nozzle into the lubrication ports on the actuator. See Figure 19. Several drops of SAE-20 oil, or equivalent, is sufficient.

OFF-SEASON MAINTENANCE

During those periods of time when the chiller is not being operated, be sure to operate the purge unit for a 30-minute period every two weeks. This will prevent the accumulation of air and noncondensibles in the machine. Since the




FIGURE 19 - Compressor Inlet Vane Actuator

machine is not providing chilled water, cool water (i.e., less than 80 F) must be supplied to the purge condenser drum by adjusting the water valves to provide alternate water flow through the purge condenser.

CAUTION: If frequent purging is required, identify and correct the source of the air or water leak as soon as possible. Moisture contamination caused by leakage can shorten the life expectancy of the machine.

ANNUAL MAINTENANCE

WARNING: OPEN AND LOCK THE UNIT DISCONNECT TO PREVENT INJURY OR DEATH DUE TO ELECTRICAL SHOCK OR CONTACT WITH MOVING PARTS.

The Trane Company recommends that the chiller be shut down for inspection once each year to check the items listed below; for a more detailed inspection checklist, refer to the "Model CVHE CenTraVac Annual Inspection Checklist and Report" illustrated in Figure 20.

1. Inspect and clean the inside of the purge drum; step-by-step instructions are provided in the "Maintenance Procedures" section of this manual.
2. Change the oil in the purge compressor and oil sump.

NOTE: If an oil analysis program is being implemented, use the set procedures established with the program. The time between changes can be extended based on the analysis results.

3. Replace the oil system filter.

While other methods are commonly practiced in the field, the recommended procedure for removing the oil filter (or element filter in an oil cooler) from a unit under negative pressure requires the use of dry nitrogen to bring the unit up to atmospheric pressure. Once the old filter is replaced and reassembly completed, the unit must be purged.

NOTE: If the unit is under a positive pressure, the entering and leaving lines at the oil filter (or oil cooler) must be disconnected. Be sure to plug the open end of each line with a flare fitting plug to reduce refrigerant loss during the filter changeout procedure.

4. Inspect the condenser tubes for fouling; clean if necessary.
5. Measure the compressor motor winding resistance to ground; qualified service personnel should conduct this procedure to ensure that the findings are properly interpreted.
6. Contact a qualified service organization to leak-test the chiller; this procedure is especially important if the system requires frequent purging.

CAUTION: If frequent purging is required, identify and correct the source of the air or water leak as soon as possible. Moisture contamination caused by leakage can shorten the life expectancy of the machine.

Remember that if the system will be off for an extended period of time, the purge unit must be operated for approximately 30 minutes every two weeks to keep the chiller free of air and noncondensibles. Since the machine is not providing chilled water, cool water (i.e., less than 80 F) must be supplied to the purge condenser drum by adjusting the water valves to provide alternate water flow through the purge condenser.

OTHER MAINTENANCE RECOMMENDATIONS

1. Use a nondestructive tube test to inspect the condenser and evaporator tubes at three-year intervals.

NOTE: It may be desirable to perform tube tests on these components at more frequent intervals, depending upon chiller application. This is especially true of critical process equipment.

2. Depending upon chiller duty, contact a qualified service organization to determine when to conduct a complete examination of the unit to discern the condition of the compressor and internal components.

Conditions which may dictate shorter intervals between chiller inspections include:

- a. chronic air leaks, which can cause acidic conditions in the compressor oil and result in premature bearing wear; and,
 - b. evaporator or condenser water tube leaks. Water mixed with the compressor oil can result in bearing pitting, corrosion, or excessive wear.
3. Submit a sample of the compressor oil to a qualified laboratory for comprehensive analysis on an annual basis; such an analysis will determine the system moisture content, acid level and wear metal content of the oil, and can be used as a diagnostic tool.

**MODEL CVHE CENTRAVAC
ANNUAL INSPECTION CHECKLIST AND REPORT**

1. REVIEW UNIT WITH OPERATING PERSONNEL
2. COMPRESSOR MOTOR
 - MOTOR CONTINUITY CHECK GOOD OPEN
 - CHECK AND TIGHTEN MOTOR TERMINALS
 - MEG MOTOR PHASE 1 PHASE 2 PHASE 3
 - CHECK NAMEPLATE AMP RATING AMPS
3. STARTER
 - CHECK OVERLOAD SETTING TRIP POINT, AMPS
 - TIGHTEN ALL TERMINALS
 - CHECK CONDITION OF STARTER CONTACTS GOOD FAIR REPLACE
4. OIL SUMP
 - CHANGE OIL GALLONS (7 GALLONS REQUIRED)
 - (IF OIL ANALYSIS, REFER TO PROGRAM PROCEDURES)
 - CHECK OIL CONDITION GOOD FAIR POOR
 - CHECK OIL TEMPERATURE CONTROL SETTING °F
 - OIL PUMP MOTOR CONTINUITY TEST GOOD OPEN
 - OIL PUMP MOTOR GROUND CHECK GOOD BAD
 - CHECK MOTOR TERMINALS, TIGHTEN
 - CHECK MAGNETIC STARTER
 - CLEAN ALL STRAINERS
 - CHANGE HI-DENSITY FILTER
5. CONTROL CIRCUITS
 - LOW TEMPERATURE CONTROL CALIBRATION
 - SETPOINT TRIP-POINT (ICE WATER)
 - HIGH PRESSURE CONTROL CALIBRATION
 - SETPOINT TRIP-POINT (USE OIL-PUMPED DRY NITROGEN TO CHECK)
 - OIL PRESSURE CONTROL CALIBRATION
 - CUT-OUT CUT-IN
 - CHECK ADJUSTMENT AND OPERATION OF DAMPER MOTOR
6. CONDENSER
 - VISUALLY INSPECT FOR SCALING IN TUBES, NOTE FINDINGS AND MAKE RECOMMENDATIONS
7. LEAK TEST CHILLER
8. REFRIGERANT AND OIL ANALYSIS FOR ACID CONTENT (ATTACH COPY OF ANALYSIS TO NEXT MONTHLY INSPECTION REPORT)
 - SAMPLE REFRIGERANT AND OIL FOR LABORATORY ANALYSIS
9. PURGE UNIT
 - CHANGE OIL IN PURGE COMPRESSOR
 - CONDITION OF OIL CLEAR DIRTY WET
 - CHECK CONDITION AND LEVEL OF FLOAT VALVE
 - MEG PURGE UNIT MOTOR TO GROUND
 - MOTOR CONDITION CLEAN DIRTY
 - ADJUST BELT AND PULLEY REPLACED BELT
 - LUBRICATE MOTOR
 - MAKE LEAK CHECK
 - CHECK AIR RELIEF SETTING
 - CHECK COMPRESSOR EFFICIENCY
 - DISASSEMBLE AND CLEAN PURGE TANK AND COIL
10. COVER LOGS AND LOGGING SYSTEM WITH OPERATOR
 - REVIEW PROPER LOGGING PROCEDURES WITH OPERATOR
11. COMMENTS

12. RECOMMENDATIONS

FIGURE 20 - CVHE Annual Inspection Checklist and Report

MAINTENANCE PROCEDURES

PURGE UNIT MAINTENANCE

Before conducting the purge maintenance procedures described in the following paragraphs, shut down purge unit operation.

WARNING: BEFORE ATTEMPTING TO PERFORM ANY MAINTENANCE ON THE PURGE UNIT, DISCONNECT THE ELECTRICAL POWER SUPPLY TO THE PURGE UNIT HEATER AND PURGE COMPRESSOR DRIVE MOTOR. TO PREVENT INJURY OR DEATH DUE TO ELECTRICAL SHOCK OR CONTACT WITH MOVING PARTS, VERIFY THAT ALL POWER SWITCHES ARE LOCKED OR SAFETIED IN THE "OFF" POSITION.

Drive Belt (CVHE Units thru "D"-Design Only)

NOTE: This procedure is not applicable for CVHE units of "E" and subsequent designs since the purge units on these chillers do not use drive belts.

Check and adjust the purge compressor drive belt tension every three months. See Figure 21. Notice that the belt should depress approximately 1/2 to 3/4 inches under light hand pressure when properly tensioned. To readjust the drive belt tension:

1. Remove the purge compressor drive belt guard.
2. Loosen the four motor mounting bolts at the base of the purge compressor motor.
3. Check the drive belt for excessive wear or damage; replace it if necessary.
4. Slide the motor away from the compressor to achieve the proper belt tension.
5. Retighten the motor mounting bolts.
6. Reinstall the drive belt guard.




FIGURE 21 - Checking Purge Compressor Drive Belt Tension (CVHE Units thru "D"-Design Only)

Purge Unit Oil Change (CVHE Units thru "D"-Design Only)

NOTE: This procedure is not applicable for CVHE units of "E" and subsequent designs since the purge compressors on these chillers do not use oil.

The purge unit must be isolated from the rest of the CenTraVac system while changing the oil. To accomplish this, close the purge outlet valve located on the side of the evaporator. Then follow the step-by-step instructions provided below to remove and change the purge unit oil.

1. Loosen the compressor discharge line connection at the top of the oil separator shell to relieve the pressure. Move the line enough to gain access to the oil separator.
2. Pour one pint of Texaco WF-68 or Mobil Whiterex No. 425 into the oil separator.
3. Reinstall the compressor discharge line and fitting removed in Step 1.
4. Disconnect the oil return line connection at the compressor crankcase.
5. Cap the crankcase fitting and install a two- or three-foot piece of tubing on the open end of the oil return line. Place the open end of the tubing in a container.
6. With all of the control panel switches positioned at OFF, disconnect the purge heater and adjust the purge compressor switch to the MANUAL position to start the purge compressor. As the purge compressor operates, oil will flow from the separator into the container. When the flow of oil ceases, stop the purge compressor.

Repeat Steps 1 through 6, adding new oil each time, until the separator is thoroughly flushed.

7. After completing the flushing procedure, tighten the discharge line connections and reconnect the oil return line at the compressor crankcase.




FIGURE 22 - Purge Unit Components (CVHE Units thru "D"-Design Only)

8. Slowly remove the oil filler plug (shown in Figure 22) from the purge compressor crankcase to relieve the pressure in the system.
9. Siphon the oil from the purge compressor crankcase.
10. Refill the crankcase with either Texaco WF-68 or Mobil Whiterex No. 425 oil.

Purge Drum Cleanup (All CVHE Units)

The purge drum should be disassembled annually for cleaning and maintenance. Use the procedure outlined below to remove the purge drum from the chiller.

WARNING: OPEN AND LOCK UNIT DISCONNECT TO PREVENT INJURY OR DEATH DUE TO ELECTRICAL SHOCK OR CONTACT WITH MOVING PARTS.

1. Close the purge liquid return line valve at the bottom of the evaporator.
2. After stopping purge unit operation, break and cap the oil separator connection that supplies the purge drum; this will prevent refrigerant loss.

NOTE: To check operation of the purge compressor solenoid valve before breaking the oil separator connection, relieve purge drum pressure and check the purge drum pressure gauge. If the pressure does not increase, the solenoid valve is closed and holding; if the pressure does increase, the valve is not holding its closed position and should be replaced.

3. Close all of the water supply and return valves to the purge drum; then, disconnect the water connections at the drum. Refer to Figure 23 for an illustration of the purge drum.




FIGURE 23 - Purge Drum




FIGURE 24 - Removing Drum End Plate, Including Water Coil and Gasket

4. Disconnect the evaporator liquid return line connection at the purge drum.
5. Detach the purge drum gas inlet line.
6. Remove the four purge drum base plate retaining screws.
7. Clean the purge drum water coil using the step-by-step instructions provided below:
 - a. Remove the six end plate retaining screws from the water connection end of the purge drum; see Figure 23.
 - b. Remove the end plate with attached coil and gasket. Refer to Figure 24.
 - c. Clean the outside of the water coil with a brush or solvent.

CAUTION: To prevent damage to the water coil, do NOT use a wire brush to clean the coil surface.
 - d. Clean the inside of the purge drum with a solvent. (Again, do not use a wire brush or the interior surface of the drum may be damaged.)
 - e. Clean the small vent hole at the top of the divider plate; this hole must be open. Refer to Figure 25 for vent hole location.
 - f. Circulate a chemical cleaning solution through the water coil to remove scale from the interior surfaces.




FIGURE 25 - Interior of Purge Drum (Viewed from Either End)




FIGURE 26 - Float Valve Assembly and Gasket

8. Use the procedure outlined below to remove and clean the float valve assembly:
 - a. Remove the six end plate retaining bolts from the refrigerant connection end of the purge drum.
 - b. Remove the end plate and gasket shown in Figure 26.
 - c. Clean the inside of the purge drum with a solvent; do not use a wire brush or the interior surface of the drum may be damaged.

Be sure to check the small hole at the top of the drum divider plate and the slot at the bottom--both should be open.
 - d. Remove the cotter pin from the float valve assembly; see Figure 27.
 - e. Clean or replace the float valve seat shown in Figure 28. (To remove the seat, remove the 1/4-inch angle fitting and the float seat retaining nut.)
 - f. Examine the rubber valve identified in Figure 29; if it is cracked or hardened, replace it.
 - g. Check the condition of the float; if necessary, it can be detached for replacement by removing the retaining screw.
9. Reassemble the purge drum by reversing the order of disassembly. Be sure to use new gaskets on the end plates, but do not use oil or grease on the gaskets and flanges. Tighten the end plate bolts evenly until the gaskets just begin to protrude between the flanges.
10. Pressure test all joints at 30 psig using dry nitrogen and R-12 as a tracer.
11. Reconnect the purge heater (i.e., which was disconnected during the purge unit oil change).




FIGURE 27 - Float Valve Cotter Pin




FIGURE 28 - Float Valve Seat




FIGURE 29 - Viton Valve

Purge Drum Water Elimination

Water condensed in the purge drum floats on the surface of the liquid refrigerant. Normally, a line of separation can be seen through the purge drum sight glass.

When water is observed, turn off the purge compressor and open the blow-off valve (Figure 22) until all of the water has drained away.

CAUTION: If frequent purging is required, identify and correct the source of the air or water leak as soon as possible. Moisture contamination caused by leakage can shorten the life expectancy of the machine.

LUBRICATION

The only components of the CVHE CenTraVac that require periodic lubrication--other than the purge compressor motor--are the bearing surfaces of the external vane linkage assembly.

Lubricate the vane shaft bearings and the rod end bearings on the vane linkage with a few drops of light machine oil.

REFRIGERANT CHARGE

To determine the refrigerant charge in the chiller, it is necessary to draw off the refrigerant and weigh it back into the machine. If the unit is low on refrigerant, contact a qualified service organization to ensure that the proper amount of refrigerant is added.

WARNING: DO NOT ALLOW REFRIGERANT TO COME IN CONTACT WITH SKIN OR INJURY MAY RESULT FROM FROSTBITE.

CLEANING THE CONDENSER

CAUTION: Do NOT use untreated or improperly treated water, or equipment damage may occur.

Condenser tube fouling is indicated when the approach temperature (i.e., the difference between the refrigerant condensing temperature and the leaving water temperature) is higher than predicted. If the annual condenser tube inspection indicates that the tubes are fouled, two cleaning methods--mechanical and chemical--can be used to rid the tubes of this foreign matter.

Use the mechanical cleaning method to remove sludge and loose material from the condenser tubes:

1. Remove the retaining nuts and bolts from the water box covers at each end of the condenser. Use a hoist to lift the covers off the water box. (A threaded connection is provided on each water box cover to allow the insertion of an eyebolt.)
2. Work a round nylon or bristle brush (attached to a rod) in and out of each of the condenser water tubes to loosen the sludge.
3. Thoroughly flush the condenser water tubes with clean water.

Scale deposits are best removed by chemical means. Be sure to consult any large chemical house in the area (i.e., since they will know the chemistry of the water) for a recommended cleaning solution suitable for the job. (Remember that the standard condenser water circuit is composed solely of copper, cast iron and steel.) Refer to Figure 30 for an illustration of a typical chemical cleaning setup.

All of the materials used in the external circulation system, the quantity of the solution, the duration of the cleaning period, and any required safety precautions should be approved by the company furnishing the materials or performing the cleaning. Remember, however, that whenever the chemical tube




FIGURE 30 - Typical Chemical Cleaning Setup

cleaning method is used, it must be followed up with mechanical tube cleaning. The Trane Company assumes no liability for equipment damage caused by improper chemical cleaning procedures.

NOTE: Since the evaporator is typically part of the closed circuit, it does not accumulate appreciable amounts of scale or sludge. However, if cleaning is deemed necessary, use the same cleaning methods described above for the condenser tube bundle.

CLEANING THE AUXILIARIES

If the coils of the purge unit are supplied with water from the same source as that used by the evaporator, they will be subjected to the same type of scaling. When cleaning is required, use the same chemical cleaning method described for the condenser; be sure to thoroughly flush the chemically-cleaned parts with clear water before connecting them to the remainder of the water circuit.

NOTE: If the auxiliaries are piped into the chilled water circuit only, cleaning is usually not necessary.

CAUTION: Do NOT use untreated or improperly treated water, or equipment damage may result.

COMPRESSOR OIL

CAUTION: To prevent the possible burnout of the oil sump heater, be sure to open the control panel disconnect switch before draining the sump.

Approved oils for CVHE CenTraVac chillers are Mobil Whiterex No. 425 and Texaco WF-68; the design oil charge for all units is seven gallons. If these oils cannot be obtained, contact your local Trane representative for recommendations.

NOTE: An oil transfer pump can be used to change the compressor motor oil incidentally of machine pressure.

Draining the Oil Sump

The saturation pressure of R-11 is less than atmospheric pressure at temperatures below 75 F, and greater than atmospheric pressure at temperatures above 75 F. If the ambient temperature is 75 F or above and the evaporator pressure gauge indicates a positive pressure, open the oil sump charging valve located at the rear of the oil sump and drain the oil into a suitable container.

If the ambient temperature is less than 75 F and the evaporator pressure gauge indicates a negative pressure, the oil must be pumped and drawn from the sump. To do this:

1. Connect a line from an auxiliary oil pump to the oil charging valve located at the rear of the oil sump.

2. Operate the auxiliary oil pump and open the charging valve.
3. After the oil is removed from the sump, close the charging valve.

NOTE: In lieu of an auxiliary pump, the oil can also be forced from the sump by using dry nitrogen to build a slight positive pressure in the unit.

Filling the Oil Sump

NOTE: The procedure described below is only applicable if the system is under a vacuum. If the ambient temperature conditions and evaporator pressure gauge reading indicate a positive pressure, pump the oil into the system.

Use the procedure outlined below to fill the oil sump. Be sure to charge the oil directly from the container in which it was shipped to prevent dirt and other foreign matter from entering the sump.

1. Connect a clean piece of clear Tygon vacuum tubing to the oil charging valve.
2. Submerge the open end of the tubing in the container of oil.
3. Open the oil charging valve; if the system is under a vacuum, the oil will be drawn readily from the container.

CAUTION: To prevent the entry of air into the oil sump make certain that the open end of the tube remains submerged in the oil during the entire charging process. Close the charging valve before raising the tube above the surface of the oil.

4. After the sump is full, close the control panel disconnect switch to energize the oil sump heater.

CONTROL SETTINGS AND ADJUSTMENTS

For your reference, a list of the CVHE controls and their settings is provided in Table 3. For control calibration and checkout procedures, contact a qualified service organization.

TABLE 3 - CVHE Control Settings

CONTROL	SETTING
High Pressure Control (S1) ¹	15 psig cutout, 5 psi differential
Low Refrigerant Temp. Control (S2)	Opens as necessary on a fall in refrigerant temperature; adjustable
Chilled Water Demand Control (S3)	As Required
Oil Pressure Control (S8)	Cut-in = 15 psid Cutout = 8 psid
Oil Temperature Control (S10)	150 F setpoint, 5 F differential
Purge High Pressure Control (S13)	30 psig cutout, 10 psi differential
Purge Oil Separator Heater Control (S14) ²	135 F setpoint, 8 F differential

NOTES:

1. If the ASME construction stamp appears on the chiller, the HPC cutout point is 25 ± 5 psig.
2. Used on CVHE units of "A" through "D"-design only.

TROUBLE ANALYSIS -----

To use the troubleshooting charts provided on the following pages, use the instructions outlined below:

1. Locate the chart that pertains to the general category of the problem experienced (i.e., Chart A = Unit Start-Up, Chart B = Unit Operation, Chart C = Lubrication System, and Chart D = System Temperatures and Pressures).
2. After locating the proper chart, determine which of the problem types listed horizontally across the top of the chart is applicable.
3. Use the symptoms listed on the slanted lines to pinpoint the specific problem being experienced. (Legends identifying the control panel lights and circuit breakers are provided on Chart A for your reference.)
4. Trace down the vertical column directly beneath the problem identified in Step 3 to the numbered boxes. The horizontal lines on which the numbered boxes occur indicate the possible causes (left-hand side) and the recommended actions (right-hand side).

The numbers in the boxes indicate the order of probability in which these causes are likely to occur, and the sequence in which the recommended actions should be checked.

NOTE: These troubleshooting charts are provided solely as a guide for determining the cause of mechanical failure or equipment malfunction. When operational problems do occur, be sure to contact a qualified service organization to ensure proper diagnosis and repair of the unit.

CHART A: Trouble Analysis: Unit Start-Up

Panel Light Legend
 DS1 Safeties Satisfied
 DS2 Cooling Required
 DS3 Restart Time Elapsed
 DS4 Chilled Water
 DS5 Condenser Water
 DS6 Oil Pump
 DS7 System

Circuit Breaker Legend
 CB-1 Low Oil Pressure
 CB-2 Hi Cond. Pressure
 CB-3 Low Refrig. Temp.
 CB-4 Hi Motor Temp.
 CB-5 Starter Fault
 CB-6 Hi Oil Temp.

Panel Light On	Unit Will Not Start									
	Compressor Motor Starter Will Not Pull In									
	Oil Pump Will Not Run					Oil Pump Runs				
Symptom	None	DS1 ON	DS2	DS3	DS4	DS4	DS6	DS7	DS7	
No Voltage To F1 Side of DS1 Light										
No Voltage to F1 Side of DS2 Light										
No Voltage to F1 Side of DS3 Light										
No Voltage to F1 Side of DS3										
No Voltage to F1 Side of DS4										
No Voltage to F1 Side of DS6										
No Voltage to F1 Side of DS6										
No Voltage to F1 Side of DS7										
No Voltage to K23-24 Relays in Comp. Motor Starter										
Comp. Motor Starter Pulls In, To Transition or Immediate CB-5 Trip										

POSSIBLE CAUSE

RECOMMENDED ACTION

Main Disconnect Open	2										Close Main Disconnect
No Control Voltage	3										Check Control Circuit Fuse
Safety Tripped	4										Reset Safety Control Circuit Breakers (See Charts C & D For Causes)
Loose Wiring or Connectors	5	2	2	6		2	3	1			Check Wiring
S3 - Start-Stop Thermostat Open		1									No Call For Cooling
S4 Program Timer Open			1								Restart Time Not Elapsed
A3 Vane Actuator end Switch Open				1							Check Vane Position
S10 Low Oil Sump Temp. Thermostat Open				5							Check Oil Sump Temperature
S1 High Cond. Press. Switch Contacts Not Closed				4							Check S1 Switch Contacts
K9 Normally Closed Contacts Open				2							Check Relay Contacts
S5 Evap. Chilled Water Flow Switch Open				3							Check Evap. Water Flow
S6 Switch (S-6) In Off Position					1						Check Switch Position
S8 Oil Pressure Switch Not Closed						1					Check Oil Pressure (Oil Filter, Pressure, Regulator, Oil Pump Defective).
S4 Program Timer Holding Unit Off							1				Check S4 Contacts 13-81 and 81-82
K10 Normally Closed Contact Open.							2				Check S4 Timer. Check For Defective K10 Contacts
Not Energizing					3						Check For Defective K1 Contacts, S9 Contacts, F2-21 Open, or Defective K-5
Oil Pump Motor Defective					2						Meg Oil Pump Motor
Compressor Motor Starter Defective									1		Contact a Qualified Service Organization
Compressor Motor Defective									2		Contact a Qualified Service Organization
Main Electrical Power Distribution	1								3		CONTACT POWER COMPANY

CHART B: Trouble Analysis: Unit Operation

POSSIBLE CAUSE	COMPLAINT												RECOMMENDED ACTION						
	Symptom	Safety CKT Breakers Open	Demand Switch 3-3	Close and Opens Starter Overloads	Trip Out	No Apparent Symptoms	Does Not Lower Water Temperature	Slightly High Condenser Pressure	Low Evaporator Pressure	Leads and Unloads Continuously	Disch and Suction Temp. Low	Amphmeter Reading Not Steady		Unit Runs For A While Then Stops	Unit Runs Without Stopping	Unit Surges (Squealing or Buffering Sound From Compressor)	Unit Hunts	Unit Carries Over	Fluctuating Amps
Unit Shutdown On Safety Controls	1																		Refer to "Unit Starting" Chart A
Low Load On System		1															4		Normal Operation. Lower Cut-Out Point and Widen Differential to Reduce Cycling
Chilled Water Demand Switch Faulty or Improperly Set		2							3										Contact a Qualified Service Organization
Temp. Controller Faulty or Improperly Set		3				1	2		2	6							1		Contact a Qualified Service Organization
Low Water Flow Through Evap. Air In Water Circuit		4															4		Check Water Pumps, Strainers, Valves
Motor Overload Out of Adj.			1																Contact a Qualified Service Organization
Low Voltage To Unit			2																Contact Power Company
Current Control Faulty or Improperly Adjusted			3																Contact a Qualified Service Organization
Vane Operator Faulty or Out of Adjustment			4																Contact a Qualified Service Organization
Compressor Motor Faulty			5																Contact a Qualified Service Organization
Interlocks Faulty				1															Check Opr. of Water Pumps, Flow Switches, etc.
Fluttering Flow Switches				3															Check Location of Switches. Bleed Air From Water Circuit
Auxiliary Run Contacts On Starter Faulty					2	4													Clean or Replace
Low Refrigerant Charge					3	5			6	2									Contact a Qualified Service Organization
Air In Water Circuit				2	4	6	2	4	5										Vent Air From Water Circuit
Loose Wiring or Connections				4	5	7													Check Continuity of Circuit to Locate - Repair
Oil In Evaporator					6	9					2								Run Unit at Part Load to Bring Oil Back to Sump. Check For Blocked or Loose Oil Lines. Check Distill System
Load Too Great For Unit						1													Check Building for Excessive Heat Load
Current Control Switch Set Too Low					7	3													Raise Setting
Evaporator Tubes Fouled						8													Clean Tubes - Check Water Treatment
High Condenser Pressure							1												See Chart D
Low Evaporator Pressure									1										See Chart D
Overcharge of Refrigerant											1								Contact a Qualified Service Organization
Blocked Orifice Plates									5										Contact a Qualified Service Organization
System Water Returning to Unit Too Warm											3								Reduce Current Control Setting if Just Starting Unit. Check Bldg. for Excessive Heat Load
Unit Carrying Over											3					2			See Column On "Unit Carries Over"
Unit Surging																3			See Column On "Unit Surges"
Low Press. Override Faulty or Improperly Set											1								Contact a Qualified Service Organization

CHART C: Lubrication

POSSIBLE CAUSE	COMPLAINT										RECOMMENDED ACTION			
	SYMPTOM	Unit Trips on Low Oil Pressure	Oil Pressure Too High	Oil Sump Too Cold	Oil Sump Too Hot	Unit Loses Oil	Excess Refrig. In Oil	CB1 Trips	Mer Oil Pressure Above 35 PSIG	Sump Temp. Below 125 F.		Sump Temp. Above 160 F.	Oil Level Below Lower Sight Glass	Oil Sump Foams Excessively
Oil Filter Dirty	1													Change Filter Element
Oil Cold - Refrig. In Oil	2													Check "Oil Sump Too Cold" Column
Oil Press. Control Faulty Or Out of Adjustment	3													Contact a Qualified Service Organization
Oil Press. Regulator Faulty or Out of Adjustment	4													Contact a Qualified Service Organization
Low Oil Level In Sump	5													See Column on "Unit Loses Oil"
Faulty Oil Pump	6													Replace
Improper Oil	7	1												Change Oil and Use Recommended Oil Only
Faulty Gauge	8	2	5											Contact a Qualified Service Organization
Temp. Control Faulty or Out of Adjustment			1											Contact a Qualified Service Organization
Faulty Oil Heater			2											Check Operation of Heater
Excessive Refrig. In Oil			3											See Column on "Excess Refrig. In Oil"
Oil Pump Continues to Run When Unit Stops			4		2	3								If Pump Runs More Than 3 Min., Check for Defective K5 Contacts, S9 Timer, or K1 Contacts
Oil Sump Too Cold					3	2								See "Oil Sump Too Cold" Column
Loose or Blocked Oil Lines					1									Check External Line For Leaks Contact a Qualified Service Organization to Inspect Internal Lines
Oil Sump Vent Open Too Far	10		7											Contact a Qualified Service Organization
Oil Sump Vent Not Open Far Enough				2	5	5								Contact a Qualified Service Organization

CHART D: Trouble Analysis: System Temperatures and Pressures

POSSIBLE CAUSE	COMPLAINT								RECOMMENDED ACTION
	SYMPTOM	High Cond. Pressure	Low Cond. Pressure	Low Evap. Pressure	High Evap. Pressure	Low Oil Pressure or Temperature	High Oil Pressure or Temperature	Motor Temp. High	
	CB2 TRIPS Condenser Excessively Cool	CB3 TRIPS Evaporator Excessively Warm	See Chart C	See Chart C	CB4 TRIPS				
Condenser Dirty	1								See "Cleaning Condenser"
Air In Water Circuit	2	7							Vent Air From Circuit
High Press. Control Faulty or Out of Adjustment	3								Contact a Qualified Service Organization
Safety Control Relay Faulty	4								Replace
Loose Wiring or Connections	5								Check Continuity of Circuits - Repair
Temp. Control Faulty or Improperly Set		1							Contact a Qualified Service Organization
Vane Operator Faulty or Out of Adjustment		2							Contact a Qualified Service Organization
Low Water Flow Through Evaporator		3							Check Water Pumps, Strainers and Valves
Chilled Water Demand Switch Faulty or Improperly Set		4							Contact a Qualified Service Organization
Low Refrigerant Charge		5							Contact a Qualified Service Organization
Low Press. Control Faulty or Improperly Set		6							Contact a Qualified Service Organization
Blocked Orifice Plates		8							Contact a Qualified Service Organization
Light Load on Unit		1	1						Normal Operation
Unit Not Lowering Water Temperature			2						See Chart B "Unit Runs Without Stopping"
Blocked Motor Cooling Line						1			Check Motor Cooling Sight Glass For Flow - Clean Strainer Make Sure Service Valves are Open
Motor Temp. Control Faulty						2			Replace
Voltage Imbalance In Power Circuit						3			Contact Power Company to Correct
Compressor Motor Faulty						4			Contact a Qualified Service Organization

CENTRAVAC OPERATING LOG



Unit Designation _____ Unit Serial No. _____ Date _____

Operator _____ Time Started _____ AM _ PM _

STATION	READING	HOUR OR LOGGING TIME							
		1	2	3	4	5	6	7	8
	Voltage								
	Amperage								
	Oil Temp-Sump °F								
	Oil Level								
	Oil Gauge Pressure psig								
	Evap. Gauge Pressure psig								
	Cond. Gauge Pressure psig								
	Purge Drum Pressure (if operating) psig								
	Condenser Water Pressure Difference - psig								
	Condenser Water - In °F								
	Condenser Water - Out °F								
	Refrigerant Liquid Temp. Condenser - °F								
	Chilled Water Pressure Difference - psig								
	Chilled Water In - °F								
	Chilled Water Out - °F								
	Refrigerant Liquid Temperature Evaporator °F								
	% current								

OPERATORS REPORT

ENTER ALL STARTS-STOPS-PERIODIC MAINTENANCE CHECKS, MALFUNCTIONS, ETC.

PERIODIC MAINTENANCE CHECKS

WEEKLY

- _____ Operate Purge as needed
- _____ Check Purge drum for water

QUARTERLY

- _____ Check oil in Purge Comp.
- _____ Oil Purge comp. motor
- _____ Check Purge belt tension
- _____ Clean all water strainers

FOR ANNUAL SERVICE INSPECTION

**Contact a Qualified
Service Organization**

Refer to your Trane Operation & Maintenance Manual for Complete Recommendations and Procedures.