



ECO² ROOFTOP UNITS - ALL MODELS STATIC PRESSURE PROBE

INSTALLATION INSTRUCTIONS

Supersedes: Nothing

Form 100.50-N1 (203)

KIT CONTENTS		
ITEM	DESCRIPTION	YORK P/N
1	PRESSURE PROBE, OUTDOOR STATIC	025-36186-000
2	SUPPORT, STATIC PRESSURE PROBE	085-00510-000
3	SCREW, 1/4 x 3/4 LG	
4	SCREW, 1/4 - 20 x 3/4 LG	
5	WASHER, PLAIN 5/16 x 3/4	
6	LOCKWASHER, 1/4	
7	NUT, HEX 1/4 -20	
8	TUBING, LDPE 5/32 x .106	
11	CABLE STRAP, PUSH-IN	

INSTALLATION

1. Attach probe (1) to bracket (2) using supplied hardware (4, 5, 6, &7)
2. Attach bracket (2) to rear of unit using supplied hardware (3)
3. Route tubing (8) as shown below.
4. Use wire ties (11) to secure tubing to bracket.

